

Introduction

The ZoomX Pro 5K Camera is a state-of-the-art device designed for photography enthusiasts and professionals. Equipped with cutting-edge technology, it offers stunning image quality and a wide range of features that cater to both beginners and advanced users.

Key Features

- 5K Video Recording
- Built-in Wi-Fi for seamless photo transfer
- 60-megapixel high-resolution sensor
- Advanced Image Stabilization
- Variety of shooting modes, including Portrait, Night, and Sports

Setup Guide

Unboxing

Upon receiving your ZoomX Pro 5K Camera, ensure that the following items are included in the package: - ZoomX Pro 5K Camera Body - 24-70mm Lens - Instruction Manual - USB Charging Cable - Battery Pack - Memory Card (64GB)

Assembling

1. Attach the lens to the camera body by aligning the white dots on both components and rotating clockwise until it clicks into place.
2. Insert the battery pack into the designated slot and close the compartment.
3. Insert the memory card into the corresponding slot.

Initial Configuration

1. Power on the camera by pressing the power button.
2. Select your preferred language and set the date and time.

3. Connect to Wi-Fi by navigating to the settings menu and entering your network credentials.

Features and Functions

5K Video Recording

The camera supports various video resolutions: - 5K at 30fps - 4K at 60fps - 1080p at 120fps

Adjust the video settings in the menu to suit your recording needs.

Connectivity Options

With built-in Wi-Fi, you can quickly transfer photos to your smartphone or computer. Download the ZoomX App for Android or iOS to manage your media files easily.

Shooting Modes

- **Portrait Mode:** Best for capturing clear and vibrant portraits.
- **Night Mode:** Enhances low-light performance.
- **Sports Mode:** Captures fast-moving subjects with precision.

Using the Camera

Capturing Photos and Videos

1. Use the mode dial to select the desired shooting mode.
2. Frame your subject using the viewfinder or LCD screen.
3. Press the shutter button halfway to focus and fully to capture.
4. To record video, switch to video mode and press the dedicated record button.

Transferring Files

1. Open the ZoomX App on your mobile device.
2. Use the 'Transfer' feature to import files wirelessly.

Maintenance and Care

- Regularly clean the lens with a microfibre cloth.
- Avoid exposing the camera to excessive heat or moisture.
- Store the camera in a padded bag when not in use.

Troubleshooting

Common Issues

- **Wi-Fi Connectivity Problems:** Restart the camera and ensure the Wi-Fi network is functioning correctly.
- **Focus Errors:** Clean the lens and ensure it is correctly mounted.
- **Power Issues:** Ensure the battery is charged and correctly inserted.

FAQs

- **Can I use third-party lenses?** Yes, the camera is compatible with a range of third-party lenses.
- **How do I update the firmware?** Regular updates are available through the ZoomX App.

Warranty and Support

The ZoomX Pro 5K Camera comes with a one-year limited warranty covering hardware defects. For support, contact our customer service team via the ZoomX website or app.

This documentation aims to provide all necessary information to enhance your experience with the ZoomX Pro 5K Camera. For any further assistance, do not hesitate to reach out to our support team.