
## Adafruit Metro M4 Express

https://www.adafruit.com/product/3382

RESET -

GND

TCC1[3] TCC0[7] TC2[1]-S4.0-S2.1-13-PA13-25 SCK



26 PA12 12 S2.0 S4.1 TC2[0] TCC0 6 TCC1[2] SDCD DEN1