

Operating manual

Spare parts

Spare parts-1-en-us
2012-11-21

BUHLER About ... | Logout


Home Catalog Shopping cart Search Profile g.t.c. Impressum

Article no. / Description

Navigation tree

- 10 000 000
 - CARAT 130 compact
 - die casting machine compl.
 - injection unit compl.**
 - casting base plate compl.
 - connecting group compl.
 - injection cylinder compl.
 - control block compl.
 - accumulator unit
 - covering compl.
 - coupling group
 - Pivot joint DN32
 - Injection unit without
 - Covering
 - transport device
 - die casting machine
 - connecting element
 - central lubrication system compl.
 - foundations pieces
 - water cooling left
 - safety device

Overview



Information

Injection cylinder compl.
(GCAR-00002-331)

Article no.: GCAR-00002-331
Description: injection cylinder compl.

Item no.	Article no.	Description	Quantity	Selling Unit
1	GCAR-00000-323	casting base plate compl.	1	ST
2	GCAR-00000-325	connecting group compl.	1	ST
3	GCAR-00002-331	injection cylinder compl.	1	ST
4	GCAR-00001-955	control block compl.	1	ST
5	GCAR-00002-541	accumulator unit	1	ST
6	GCAR-00002-475	covering compl.	1	ST

powered by CATALOGcreator®

Table of contents

1	Important information	3
1.1	Contact	3
1.2	Scope of delivery	3
2	Safety	4
2.1	Spare parts	4
3	Installation and configuration	5
3.1	System requirements	5
3.2	Installation	5
	3.2.1 Installing the catalog	5
	3.2.2 Install the Viewer	5
4	Description	7
4.1	Overview	7
4.2	Header	7
4.3	Menu bar	8
4.4	Navigation area	8
4.5	Main area	9
	4.5.1 Home	9
	4.5.2 Catalog	9
	4.5.3 Shopping cart	12
	4.5.4 Search	12
	4.5.5 Profile	13
	4.5.6 g.t.c.	13
	4.5.7 Imprint	13
4.6	Information area	14
5	Operation	15
5.1	Start the catalog	15
5.2	Set the language	15
5.3	Select the assembly group and parts	15
	5.3.1 Select the assembly group in the navigation area	16
	5.3.2 Select the assembly group in the 3D model of the catalog view ...	17
	5.3.3 Select the assembly group or the part in the table of the catalog view	18
5.4	Place the assembly group in the shopping cart.	18

1 Important information

1.1 Contact

- ▶ Should you have any questions, please contact the manufacturer's regional subsidiary.
- ▶ Have the operating manual handy.

1.2 Scope of delivery

The spare parts catalog is shipped in electronic form on the accompanying data medium. The electronic spare parts catalog contains information on all the parts of the die casting machine as has been built in keeping with the purchase order.

The following data are present on the data medium:

- HTML spare parts catalog
- SVG-Viewer (2D-Viewer)
- XVL-Player (3D-Viewer)
- Operating instructions
- Electric wiring diagram
- Dimensional drawings

2 Safety

2.1 Spare parts

Operating the machine with replacement parts that do not meet the requirements can result in risk of injury or damage to property.

- Only use original spare parts from Bühler AG. (See spare parts catalogue)

3 Installation and configuration

3.1 System requirements

General	The handling of the 3D models is being improved with a powerful system.
Screen resolution	minimum 1024 x 768 pixels
Operating system	Microsoft Windows from Windows XP or later
Space on hard disk	depending on the catalog size, at least 100 MB
Browser	Internet Explorer Version 7 and later: ■ Enable cookies ■ Enable JavaScript
Plugins	■ Plugins for 2D- and 3D-Viewer (part of the supplied kit) ■ Adobe Reader Version 5 onwards (available free on the Internet)

3.2 Installation

The software on the data carrier is license-free and free of cost.

Administrator rights are required for installing the Viewer.


3.2.1 Installing the catalog

1. Open the data medium.
2. Copy the folder "Catalog" to the hard disk of the computer.

3.2.2 Install the Viewer

Prerequisites:


- Log in to the PC with Administrator rights



1. Start the catalog. See Chapter 5.1 “Start the catalog”.
2. Start the installation by clicking “SVG Viewer” and “XVL Player” and follow the instructions.

4 Description

4.1 Overview



Item	Name	Symbol	Function
1	Header		The header contains the following elements: ■ Logo ■ Link to the “About...” page ■ “Logout” button
2	Menu bar		The menu bar contains tabs for switching to the different menus.
3	Navigation area		The navigation area contains the following fields: ■ Quick search ■ Navigation
4	Main area		The main area displays the contents that were selected in the menu bar.
5	Information area		The information area contains an overview and information on the selected spare parts.

4.2 Header




About ... | Logout

Item	Name	Symbol	Function
	About...		Displays the software version.
	Logout		Logs out the user.

4.3 Menu bar

Item	Name	Sym- bol	Function
	Home		In the main area, displays the setting and navigation options of the Home menu.
	Catalog		Displays the catalog contents in the main area.
	Shopping cart		Displays the shopping cart in the main area.
	Search		Displays the various search options in the main area.
	Profile		Displays, in the main area, a selection of settings that can be saved in the browser.
	g.t.c		Displays the general T&Cs in the main area.
	Imprint		Displays imprint information in the main area.
	<< Language se- lection		Opens the language selection.

4.4 Navigation area




Item	Name	Symbol	Function
			Initiates a search for the input term or the input item number.
			Displays the entire navigation, if the navigation was previously confined to a particular assembly group.
			Restricts the navigation to the assembly group selected in the navigation area.
			Restricts the search to the assembly group selected in the navigation area.
			Opens a text field for filtering the displayed catalogs.

Item	Name	Symbol	Function
			Hides all inactive catalogs.
			Depicts the navigation structure. Allows navigation within assembly groups and the selection of assembly groups.

4.5 Main area

4.5.1 Home




Item	Name	Symbol	Function
	System requirements		Contains the system requirements for the installation of the electronic spare parts catalog. ■ “Data sheet”: Data sheet with system requirements on which the electronic spare parts catalog is to be installed. ■ Link for installing the “SVG Viewer” for the 2D depiction of models ■ Link for installing the “XVL Player” for the 3D depiction of models
	Quick selection		Allows quick switching to the following screens: ■ Catalog ■ Shopping cart ■ Search ■ Profile
	Functional view		Allows switching between the standard and extended view.
	Overview		Contains a link to the total machine in the catalog.

4.5.2 Catalog

This screen is divided into 2 areas:

- The assembly groups are shown in the upper area. These assembly groups can be differently visualized with the operating elements of the toolbar.

- The subordinate assembly groups or, as the case may be, the parts that belong to the assembly group selected in the navigation area are shown in the lower area. The subordinate assembly groups can be opened and parts placed in the shopping cart.



Item	Name	Symbol	Function
	... \... \ injection unit compl. (GCAR-00003-649) <<		Displays the description and the item number of the depicted assembly group.
			Resets all the functions that were initiated with the operating elements of the toolbar.
			Switches to the 2D- or 3D depiction of the assembly group.
			Hides a part. (only for 3D depiction)
			Displays all the parts. (only for 3D depiction)
			Focuses on the selected part.
			Focuses on the entire assembly group.

Item	Name	Symbol	Function
			Depicts all the parts not selected transparently. (only for 3D depiction)
			Shows the selected part in the main area and the assembly group in the information area. (only for 3D depiction)
			Hides the table.
			Hides the depiction of the assembly group.
			Opens a dialog for displaying and hiding table columns.
			Allows the filtering of table columns.
			Switches the maximized view on or off.
			Exports the currently shown table to a text file (comma-separated).
			Generates a PDF file with drawings and the currently displayed table.
			Prints the current view.
			Moves the drawing area. (only for 2D depiction)
			Enlarges or reduces the drawing area, as the case may be. (only for 2D depiction)
			Enlarges the selected area. (only for 2D depiction)
			Places the part in the shopping cart.
			The part is already in the shopping cart.

4.5.3 Shopping cart

Shopping cart   

1. Overview 2. User data 3. Finalize

▼ 10 000 000 (2)  

Article no. ↕	Description ↕	Assembly ↕	Amount ↕	Price (\$) ↕
UNN -44040-350	Rod seal D=100 with O-ring	control block compl.	1	o.r. 
UNS -16065-002	Magnetic seat valve 3/2-way DN6	control block compl.	1	o.r. 

All round price: o.r.

Select all 

Delete 

Back Next

Item	Name	Symbol	Function
			Copies the shopping cart to the clipboard (comma-separated).
			Exports the shopping cart to a text file (comma-separated).
			Loads the saved shopping cart.

4.5.4 Search

Search

Quick search Enhanced search Search examples

Article no.:

Description:

Betriebsmittel:

Search level: ▼


10 000 000

Search Reset History

Item	Name	Sym- bol	Function
	Quick search		Extended search
	Enhanced search		Initiates a search according to Bühler number, description or operating equipment. When this search is initiated, the search level (e. g. "In the current catalog") can also be selected.
	Search exam- ples		Describes the search operators.

4.5.5 Profile

The selection of which current settings are to be saved as browser cookies is made on this screen. The settings are available when the browser is started the next time.



Profile

Please select all settings you want to save:


Your settings will set inside a Cookie. Your Browser needs to accept Cookies.

- ☒ Current catalog and language(s)
- ☒ User data
- ☒ Size of the navigation tree, BOM and the info area
- ☒ Sort sequence of BOM
- ☒ Hidden attribute columns
- ☒ Current function view

Reset Save


4.5.6 g.t.c.

The general terms and conditions of business are displayed on this screen.




4.5.7 Imprint

The general terms and conditions of business are displayed on this screen.



4.6 Information area




Item	Name	Symbol	Function
			Displays the properties of the current assembly group.
			Displays details on the current part.
			Searches in the current catalog for the part and lists the assembly groups in which the part is fitted.
			Searches for an item number. If the item number is not found, it can still be added to the shopping cart through this procedure.
			Displays the contents of the shopping cart.
			Displays the saved favorites.
			Places the part in the shopping cart.
			Saves the part among the favorites.

5 Operation

5.1 Start the catalog

1. In Windows Explorer, go to the folder "Catalog":
 - ▶ Folder on the hard disk, See Chapter 3.2.1 "Installing the catalog".
 - ▶ Alternatively: folder on the data medium on which the electronic spare parts catalog was supplied
2. Double-click the file "Start.exe".
 - The catalog opens in Internet Explorer.

5.2 Set the language



1. In the menu bar, click "<< Language selection".
 - Language selection is opened.
2. Select the language.
 - ▶ In the menu "UI language", select the language of the user interface.
 - ▶ In the menu "Catalog content", select the language of the catalog content.
3. Confirm the input.



→ The language is changed.


5.3 Select the assembly group and parts

To call information on an assembly group or a part, the assembly group or the part must be selected.

The following steps may be required for selecting:


- Select the assembly group in the navigation area
- Select the assembly group in the 3D model of the catalog view
- Select the assembly group or the part in the table of the catalog view

5.3.1 Select the assembly group in the navigation area



1. Open the tree structure in the navigation area.
 - Subordinate assembly groups are displayed.
2. Click on a subordinate assembly group.
 - The assembly group is selected.
 - The assembly group is displayed in the main area.

5.3.2 Select the assembly group in the 3D model of the catalog view



1. Position the 3D model in such a way that the zone in which the sought assembly group is fitted is displayed.
 - ▶ Zooming: With the mouse wheel.
 - ▶ Rotating: By keeping the left mouse button pressed down and moving the mouse.
 - ▶ Moving: By keeping the mouse wheel pressed down and moving the mouse.
 - ▶ Use the operating elements of the “Catalog” page for visualization. See Chapter 4.5.2 “Catalog”.
2. In the 3D model, double-click the assembly group in which the sought assembly group is fitted.
 - Subordinate assembly group is displayed.
3. Continue the process till the sought assembly group is isolated or there are no more subordinate assembly groups present.
4. Click the assembly group / part.
 - Assembly group / part is selected and is highlighted in the 3D-model. Assembly group / part is highlighted in the table and displayed in the information area.

5.3.3 Select the assembly group or the part in the table of the catalog view

	Item no. ↕	Article no. ↕	Description ↕	Quantity ↕	Selling U	
	1	GCAP-00000-323	<u>casting base plate compl.</u>	1	ST	▲
	2	GCAP-00000-325	<u>connecting group compl.</u>	1	ST	■
	3	GCAR-00002-331	<u>injection cylinder compl.</u>	1	ST	▼
	4	GCAR-00001-955	<u>control block compl.</u>	1	ST	
	5	GCAR-00002-541	<u>accumulator unit</u>	1	ST	
	6	GCAR-00002-475	<u>covering compl.</u>	1	ST	

1. If the name of a assembly group is underlined in the column “Description”, click the name.
→ Subordinate assembly group is opened.
2. Click the row in the table.
→ Assembly group / part is selected and is highlighted in the 3D-model.
Assembly group / part is displayed in the information area.

5.4 Place the assembly group in the shopping cart.

1. Select the assembly group. See Chapter 5.3 “Select the assembly group and parts”.
2. Click the shopping cart in the table of the main area or in the information area.



- The assembly group is in the shopping cart.



Bühler AG
CH-9240 Uzwil, Schweiz
+41 71 955 11 11
+41 71 955 33 79
www.buhlergroup.com

