D878UV[D878UV:UHF...

^ 🖅 @ √x 🔷 SWE 09:49 🔲

Ⅱ 20 計 👼 🦂 💁

🖒 SA7TOR (Tord Hallenb... 🤌 👿 Dokument1 - Word

This screen allows you to select the Alert Tone options and Tone Frequencies for various Alerts in the D878UV radio.

The programming also allows you to program the tone frequency for the Idle Channel Tone, the Call Tone and the Call Reset Tone as well as the duration of those tones.



D878UVID878UV:UHF...

^ = @ √x ● SWE 09:50 □

= Po벍 **=** 👶 💁

🝅 SA7TOR (Tord Hallenb... 🧷

W Dokument1 - Word































N D878UV[D878UV:UHF...

^ 🖅 @ √x 🔷 SWE 09:50 🔲

N D878UV[D878UV:UHF...

^ 🖅 @ √x 🔷 SWE 09:51 🔲




























D878UV[D878UV:UHF...

^ 🔄 🦟 ➪× 👛 SWE 09:47 📮



This screen allows you to select the options for power save.



























This screen allows you to select the various radio options as listed.

























