РУКОВОДСТВО ПО СБОРКЕ СТАНЦИЙ

Station assembly guide

Конфигурация / Configuration	EVT-PRE-20
Ревизия / Revision	REV_D7
Дата / Date	16.10.2026
Статус / Status	ГОТОВ К ПЕРЕДАЧЕ / READY FOR HANDOFF
Объём / Scope	1 управляемый лот, 20 станций / one controlled lot, 20 stations

1. Входной контроль / Incoming inspection

RU: До сборки сверить ревизию, MPN, количество, упаковку, ESD/MSL, механические размеры, сертификаты и результаты фабричного контроля. Несоответствие изолировать с NCR. **EN:** Before assembly verify revision, MPN, quantity, packaging, ESD/MSL, mechanical dimensions, certificates and factory inspection results. Segregate nonconforming material under NCR.

2. Последовательность / Sequence

Шаг	Операция / Operation	Критерий / Acceptance
MFG-010	Verify released manufacturing bundle	All hashes match and no OPEN blocker authorized for build
MFG-020	Verify materials and deviations	All items accepted or deviation signed
MFG-030	Select lot and assign serials travellers and housing plan	DIO-EVT-001 through DIO-EVT-020 assigned with no duplicates; all primary housings vacuum cast; 3D fallback controlled
MFG-040	Stencil paste placement and reflow	Profile within frozen paste limits and traceable batch
MFG-050	AOI visual and X-ray	IC-004 and IC-005 accepted
MFG-060	Bare power resistance check	No rail-to-ground short against released limits
MFG-070	First power with current limit	No latch-up overheating or current limit event
MFG-080	Program immutable boot foundation	Readback version and protection state match release
MFG-090	Program station and coprocessor test builds	Hashes and versions match selected release
MFG-100	PCB_MAIN boundary scan and interface self-test	All fitted interfaces including both SIM slots enumerate and test points pass
MFG-110	PCB_PWR load and protection test	All rails protection and temperature within frozen limits
MFG-120	PCB_MIC individual acoustic test	Identity sensitivity noise and phase within frozen limits
MFG-130	Build and verify harnesses	100 percent continuity polarity labels and length pass
MFG-140	Install PCB and antennas in electronics module	No interference; antennas and coax routing match drawing
MFG-150	Assemble four-microphone geometry	Triangle sides and MIC4 offset within released tolerance
MFG-160	Install seals membranes and vents	Correct lot orientation compression and clean acoustic ports

3. Критические правила / Critical rules

- Серийный номер и traveller назначаются до начала сборки. / Assign serial number and traveller before assembly starts.
- RF порты не включать без согласованной нагрузки/антенны. / Do not transmit into an unloaded RF port.
- Соблюдать полярность батареи, предохранитель у батареи и запрет заряда ниже 0 °C. / Observe battery polarity, battery-side fuse and the below-zero charging prohibition.
- Четыре MIC-жгута одинаковой длины; лишнюю длину укладывать сервисной петлёй. / All four MIC harnesses have equal length; place surplus in a service loop.
- После любого ремонта повторить затронутый тест и полный регрессионный EOL. / After rework repeat the affected test and the full regression EOL.

4. Запись результатов / Records

RU: Для каждого шага фиксируются исполнитель, дата, оборудование, версия процедуры, результат, ссылка на фото/измерения и хеш evidence. Пустое обязательное поле блокирует PASS. **EN:** For each step record operator, date, equipment, procedure revision, result, photo/measurement reference and evidence hash. A blank mandatory field blocks PASS.