


D3 and D4 are special pins that needs to be LOW on startup

D8 is special pin that needs to be LOW on startup



BUZ11

2 White LED Controller