LED-ek vezérlése shift regiszterrel

MICLAB-07

Név: Stefán Kornél Dátum: 2024. 10. 21. Mérőhely: 7 bal

Bevezetés

Az interrupt használatának megismerése.

Ajánlott irodalom

- A házi feladatban találhatók
- Honlap: http://www.inf.u-szeged.hu/noise/Education/MicLab/

Jegyzőkönyv készítése

A jegyzőkönyvek az órán végzett munka dokumentálására szolgálnak. A letölthető minta jegyzőkönyvet kell kiegészíteni a megfelelő információkkal: név, dátum, mérőhely (pl. 3. jobb), a feladatokhoz tartozó esetleges kifejtendő válaszokkal, valamint a kódok lényeges részével.

A jegyzőkönyveket a CooSpace-en kell feltölteni, külön pdf formátumban csatolni kell a jegyzőkönyvet (a fájl neve a következő mintát kövesse: NagyJ.KissB.03.pdf), egy külön zip fájlban pedig a kódokat (*.c, *.cwg). Amennyiben probléma merül fel a beadás során, az anyagokat az oktató e-mail címére kell elküldeni, levél tárgya legyen pl. MicLab 03.

1. feladat – LED1 és LED7 bekapcsolása

Kapcsolja be a kiegészítő panelen lévő LED1 és LED7 nevű LED-eket. (Kövesse az órai ppt-t és használja a MicLab-utmutato.pdf-ben lévő kapcsolódó részeket.)

Konfigurálja az SPI-t az órai diasor segítségével. A Clock Phase és a Clock Polarity beállításaival 4 eset lehetséges az adat (MOSI) és az órajel (SCK) viszonyára. Válassza ki a Clock Phase és a Clock Polarity helyes kombinációját a shift regiszter idődiagramja és a Laboratory Practicals pdf 7.7-es ábrája alapján. Az SPI 3 vezetékes módban legyen és az órajele legyen ~1,5 MHz.

Az SPI **polling módon** történő használatával töltse fel a shift regisztert. A shift register írásához készítsen egy saját függvényt. Ne feledje, hogy a shift register csak akkor adja ki a kimeneteire a beleírt byte-ot, ha az OE_RCLK vonalon egy felfutó élt kap.

A program részekre bontott forráskódja (Config, Main.c, Interrupts.c, ha van):

Config

```
<property object="CROSSBAR0" propertyId="xbar0.spi0.clockdata" value="Enabled"/>
    cproperty object="DefaultMode" propertyId="mode.diagramLocation" value="100, 100"/>
cproperty object="INTERRUPT_0" propertyId="ABPeripheral.included" value="true"/>
cproperty object="INTERRUPT_0" propertyId="interrupt.interruptenable.enableallinterrupts"
value="Enabled"/>
    cyroperty object="P0.0" propertyId="ports.settings.iomode" value="Digital Push-Pull Output"/>
   <property object="SPI_0" propertyId="ABPeripheral.included" value="true"/>
    <property object="SPI_0" propertyId="spi.configuration.clockphase" value="Data sample on second</pre>
edge"/>
    mode"/>
    <property object="SPI_0" propertyId="spi.control.spienable" value="Enabled"/>
<property object="SPI_0" propertyId="spi.view.view" value="Advanced"/>
<property object="WDT_0" propertyId="ABPeripheral.included" value="true"/>
<property object="WDT_0" propertyId="wdt.watchdogcontrol.wdtenable" value="Disable"/>
  </mode>
    value="DefaultMode"/>
  </modeTransition>
</device:XMLDevice>
Main.c
// Includes
#include <SI_EFM8BB1_Register_Enums.h>
                                                        // SFR declarations
#include "InitDevice.h"
// $[Generated Includes]
// [Generated Includes]$
#define DispClock P0_B0
#define DispData P0 B2
#define DispOutEnable P0 B3
#define DecoderA P1_B1
#define DecoderB P1 B2
#define DecoderC P0_B4
// Displays
enum {
 LED T1,
  LED_T2,
  LED_T3,
 LED_T4,
 LED_LEDS
// Leds on display
enum {
    LED_7 = 1,
  LED\_1 = 2,
  LED_2 = 4
  LED 3 = 8,
  LED 6 = 16,
  LED 5 = 32,
 LED_4 = 64,
```

```
#define LEDS_TO_ACTIVE ~(LED_1 | LED_7)
// SiLabs_Startup() Routine
// This function is called immediately after reset, before the initialization
// code is run in SILABS_STARTUP.A51 (which runs before main() ). This is a
// useful place to disable the watchdog timer, which is enable by default
// and may trigger before main() in some instances.
void SiLabs_Startup (void)
{
 // $[SiLabs Startup]
  // [SiLabs Startup]$
// Enable selected display.
// Tudom hogy most overkill, de hasznos lehet még
void select_display(uint8_t display)
  switch (display) {
   case LED_T1:
     DecoderA = 0;
     DecoderB = 0;
     DecoderC = 0;
     break;
    case LED T2:
     DecoderA = 1;
     DecoderB = 0;
     DecoderC = 0;
     break;
   case LED T3:
     DecoderA = 0;
     DecoderB = 1;
     DecoderC = 0;
     break;
    case LED T4:
     DecoderA = 1;
     DecoderB = 1;
     DecoderC = 0;
     break;
    case LED_LEDS:
     DecoderA = 0;
     DecoderB = 0;
     DecoderC = 1;
     break;
   default:
     break:
 }
void write_to_spi(uint8_t data_to_send) {
  SPI0CN0_SPIF = 0;
  SPI0DAT = data_to_send;
  // Wait until data is sent out
 while(!SPI0CN0_SPIF);
 SPI0CN0_SPIF = 1;
// main() Routine
                    ______
int main (void)
  // Call hardware initialization routine
```

```
enter_DefaultMode_from_RESET();
select_display(LED_LEDS);
while (1)
{
    // $[Generated Run-time code]
    // [Generated Run-time code]$

    // disable leds
    DispOutEnable = 1;

    //write to spi
    write_to_spi(LEDS_TO_ACTIVE);

    //send signal to bit shifter.
    DispOutEnable = 0;
}
```

Az elkészült programot be kell mutatni!

A gyakorlatvezető ellenőrizte:

- Igen
- Nem

A program működött:

- <u>Igen</u>
- Nem

2. feladat – Elektronikus dobókocka megvalósítása

Írjon egy olyan programot, ami a 7db LED segítségével meg tudja jeleníteni egy 6 oldalú dobókocka oldalait. Amíg a kiegészítő panelen lévő SW1 nyomógomb le van nyomva, addig léptesse a főprogramban a dobókocka oldalait. Mivel a léptetés nagy sebességgel történik, így teljesíthető a véletlenszerűség, ami egy kockadobásnak tekinthető.

A program részekre bontott forráskódja (Config, Main.c, Interrupts.c, ha van):

config

```
<property object="P1.1" propertyId="ports.settings.outputmode" value="Push-pull"/>
  cyproperty object="PBCFG_0" propertyId="pbcfg.settings.enablecrossbar" value="Enabled"/>
  edge"/>
  mode"/>
   <property object="SPI_0" propertyId="spi.control.spienable" value="Enabled"/>
  <modeTransition>
  value="DefaultMode"/>
 </modeTransition>
</device:XMLDevice>
Main.c
// Includes
#include <SI_EFM8BB1_Register_Enums.h>
                                     // SFR declarations
#include "InitDevice.h"
// $[Generated Includes]
// [Generated Includes]$
#define DispClock P0_B0
#define DispData P0 B2
#define DispOutEnable P0_B3
#define DecoderA P1_B1
#define DecoderB P1_B2
#define DecoderC P0_B4
#define SW1 P0_B1
#define DICE_SIDES 6
#define PERGES_COUNT 250
// Displays
enum
{
     LED_T1, LED_T2, LED_T3, LED_T4, LED_LEDS
};
// Leds on display
enum
{
     LED 7 = 1,
     LED_1 = 2,
     LED_2 = 4,
     LED_3 = 8,
     LED\_6 = 16,
     LED_5 = 32,
     LED 4 = 64
};
enum
{
     PRESSED, UNPRESSED,
};
uint8_t currentNumber = 0;
// <u>szorgalmi pergés</u> <u>mentesítés</u>
```

```
uint8_t lastPressStatus = UNPRESSED;
uint8_t pressCount = 0;
uint8_t buttonStatus = UNPRESSED;
// SiLabs_Startup() Routine
// This function is called immediately after reset, before the initialization
// code is run in SILABS_STARTUP.A51 (which runs before main() ). This is a
// useful place to disable the watchdog timer, which is enable by default
// and may trigger before main() in some instances.
void SiLabs_Startup(void)
{
        // $[SiLabs Startup]
        // [SiLabs Startup]$
}
// Enable selected display.
// <u>Tudom hogy</u> most overkill, <u>de hasznos lesz még kövi gyakon</u>.
void select_display(uint8_t display)
{
        switch (display)
        case LED_T1:
                DecoderA = 0;
                DecoderB = 0;
                DecoderC = 0;
                break;
        case LED_T2:
                DecoderA = 1;
                DecoderB = 0;
                DecoderC = 0;
                break;
        case LED T3:
                DecoderA = 0;
                DecoderB = 1;
                DecoderC = 0;
                break;
        case LED T4:
                DecoderA = 1;
                DecoderB = 1;
                DecoderC = 0;
                break;
        case LED LEDS:
                DecoderA = 0;
                DecoderB = 0;
                DecoderC = 1;
                break;
        default:
                break;
        }
        DispOutEnable = 0;
}
void write_to_spi(uint8_t data_to_send)
{
        SPI0CN0_SPIF = 0;
        SPI0DAT = data to send;
        // Wait until data is sent out
        while (!SPI0CN0_SPIF)
                ;
        SPI0CN0_SPIF = 1;
}
```

```
uint8_t get_data_from_number(uint8_t num)
        switch (num)
        case 0:
                return ~(LED_7);
        case 1:
                return ~(LED_1 | LED_6);
        case 2:
                return ~(LED_1 | LED_7 | LED_6);
        case 3:
                return ~(LED_1 | LED_4 | LED_3 | LED_6);
        case 4:
                return ~(LED_1 | LED_4 | LED_3 | LED_6 | LED_7);
        case 5:
                return ~(LED_1 | LED_2 | LED_4 | LED_3 | LED_5 | LED_6);
        default:
                return ~0;
        }
}
// main() Routine
int main(void)
{
        // Call hardware initialization routine
        enter_DefaultMode_from_RESET();
        // Shift register beállítása
        // Decoder beállítása
        select_display(LED_LEDS);
        // set with invalid
        write_to_spi(get_data_from_number(111));
        while (1)
        {
                // $[Generated Run-time code]
                // [Generated Run-time code]$
                if (!SW1)
                         if (lastPressStatus == UNPRESSED)
                         {
                                 lastPressStatus = PRESSED;
                                 pressCount = 0;
                         }
                         else
                         {
                                 if (pressCount < PERGES_COUNT)</pre>
                                 {
                                         ++pressCount;
                                 }
                                 else
                                 {
                                         buttonStatus = PRESSED;
                                          // Hide number when pressing
                                         DispOutEnable = 1;
                                 }
                         }
                }
                else
                {
                         if (lastPressStatus == PRESSED)
```

```
lastPressStatus = UNPRESSED;
                                  pressCount = 0;
                         else
                         {
                                  if (pressCount < PERGES_COUNT)</pre>
                                          ++pressCount;
                                 else
                                  {
                                          buttonStatus = UNPRESSED;
                                          // Show number when released
                                          DispOutEnable = 0;
                                 }
                         }
                 }
                 if (buttonStatus == PRESSED)
                         //write to spit
                         write_to_spi(get_data_from_number(currentNumber));
                         // increment data
                         currentNumber = (currentNumber + 1) % DICE_SIDES;
                 }
        }
}
```

Az elkészült programot be kell mutatni!

A gyakorlatvezető ellenőrizte:

- Igen
- Nem

A program működött:

- Igen
- Nem

Szorgalmi feladat – LED-ek léptetése timerrel (futófény)

Valósítson meg futófényt, amely a kiegészítőpanelen található LED-ek sorszáma szerint növekvő sorrendben be-, majd kikapcsolja a LED-eket. A LED-ek léptetését egy timerrel valósítsa meg, aminek a túlcsordulási rátája 35 Hz legyen.

Valósítson meg irányváltási funkciót is, amennyiben a kiegészítő panelen található SW1-es nyomógomb lenyomásra kerül a futófény a LED-ek sorszáma szerinti csökkenő sorrendben folytatódjon. (Újbóli lenyomás esetén természetesen ismét növekvő sorrendben.). Irányváltás csak a nyomógomb felengedésére történjen!

A program részekre bontott forráskódja (Config, Main.c, Interrupts.c, ha van):

config

```
<property object="CROSSBAR0" propertyId="xbar0.spi0.clockdata" value="Enabled"/>
   cproperty object="DefaultMode" propertyId="mode.diagramLocation" value="100, 100"/>
cproperty object="INTERRUPT_0" propertyId="ABPeripheral.included" value="true"/>
cproperty object="INTERRUPT_0" propertyId="interrupt.interruptenable.enableallinterrupts"
value="Enabled"/>
   <property object="INTERRUPT_0" propertyId="interrupt.interruptenable.enabletimer2interrupt"</pre>
value="Enabled"/>
  <property object="PBCFG_0" propertyId="pbcfg.settings.enablecrossbar" value="Enabled"/>
   <property object="SPI_0" propertyId="ABPeripheral.included" value="true"/>
<property object="SPI_0" propertyId="spi.configuration.clockphase" value="Data sample on second</pre>
edge"/>
   <property object="SPI_0" propertyId="spi.configuration.enablemastermode" value="Enable"/>
   cproperty object="SPI_0" propertyId="spi.configuration.spimode" value="Master"/>
   mode"/>
   <property object="SPI_0" propertyId="spi.control.spienable" value="Enabled"/>
<property object="SPI_0" propertyId="spi.view.view" value="Advanced"/>
   Running"/>
   cproperty object="TIMER16_2" propertyId="timer16.initandreloadvalue.targetoverflowfrequency"
value="10"/>
   value="40015"/>
   cproperty object="WDT_0" propertyId="ABPeripheral.included" value="true"/>
   <property object="WDT_0" propertyId="wdt.watchdogcontrol.wdtenable" value="Disable"/>
 </mode>
 <modeTransition>
   value="DefaultMode"/>
 </modeTransition>
</device:XMLDevice>
Main.c
// Includes
#include "InitDevice.h"
// $[Generated Includes]
// [Generated Includes]$
#define DispClock P0_B0
#define DispData P0 B2
#define DispOutEnable P0 B3
#define DecoderA P1_B1
#define DecoderB P1 B2
#define DecoderC P0 B4
```

#define SW1 P0_B1

```
#define LED_COUNT 7
enum
{
        LED_T1, LED_T2, LED_T3, LED_T4, LED_LEDS
};
enum
{
        LED 7 = 1,
        LED_1 = 2
        LED_2 = 4,
        LED_3 = 8,
        LED_{6} = 16,

LED_{5} = 32,
        LED 4 = 64,
};
enum
{
        BUTTON_PRESSED, BUTTON_RELEASED
};
enum
{
        DIRECITON_RIGHT, DIRECTION_LEFT,
};
enum
{
        INCREMENT_HANDLED, INCREMENT_UNHANDLED,
};
uint8_t currentNumber = 0;
uint8_t currentDirection = DIRECITON_RIGHT;
uint8_t currentButtonState = BUTTON_RELEASED;
volatile incrementHandleStatus = INCREMENT HANDLED;
// SiLabs_Startup() Routine
// This function is called immediately after reset, before the initialization
// code is run in SILABS STARTUP.A51 (which runs before main() ). This is a
// useful place to disable the watchdog timer, which is enable by default
// and may trigger before main() in some instances.
void SiLabs_Startup(void)
{
        // $[SiLabs Startup]
        // [SiLabs Startup]$
}
// Enable selected display.
// Tudom hogy most overkill, de hasznos lesz még kövi gyakon.
void select_display(uint8_t display)
        switch (display)
        {
        case LED_T1:
                DecoderA = 0;
                DecoderB = 0;
                DecoderC = 0;
                break;
        case LED_T2:
                DecoderA = 1;
                DecoderB = 0;
                DecoderC = 0;
                break;
        case LED_T3:
                DecoderA = 0;
                DecoderB = 1;
                DecoderC = 0;
```

```
break;
        case LED_T4:
                DecoderA = 1;
                DecoderB = 1;
DecoderC = 0;
                break;
        case LED_LEDS:
                DecoderA = 0;
                DecoderC = 1;
                break;
        default:
                break;
        }
        DispOutEnable = 0;
}
void write_to_spi(uint8_t data_to_send)
        SPI0CN0_SPIF = 0;
        SPI0DAT = data_to_send;
        // Wait until data is sent out
        while (!SPI0CN0_SPIF);
        SPI0CN0_SPIF = 0;
}
uint8_t get_data_from_number(uint8_t num)
        switch (num)
        case 0:
                return ~LED_1;
        case 1:
                return ~LED_2;
        case 2:
                return ~LED_3;
        case 3:
                return ~LED_4;
        case 4:
                return ~LED_5;
        case 5:
                return ~LED_6;
        case 6:
                return ~LED_7;
        default:
                return 0;
        }
}
// main() Routine
int main(void)
        // Call hardware initialization routine
        enter_DefaultMode_from_RESET();
        select_display(LED_LEDS);
        while (1)
```

```
{
                // $[Generated Run-time code]
                // [Generated Run-time code]$
                DispOutEnable = 1;
                //write to spit
                write_to_spi(get_data_from_number(currentNumber));
                //send signal to bit shifter.
                DispOutEnable = 0;
                if (incrementHandleStatus == INCREMENT_UNHANDLED)
                {
                         // increment data
                        if (currentDirection == DIRECITON_RIGHT)
                        {
                                 currentNumber = (currentNumber + 1) % LED_COUNT;
                        }
                        else
                        {
                                 if (currentNumber == 0)
                                         currentNumber = LED_COUNT;
                                 currentNumber -= 1;
                        }
                        incrementHandleStatus = INCREMENT_HANDLED;
                }
                if (currentButtonState == BUTTON_PRESSED && SW1)
                {
                        currentButtonState = BUTTON_RELEASED;
                        currentDirection = currentDirection == DIRECITON_RIGHT
                                        ? DIRECTION LEFT
                                         : DIRECITON_RIGHT;
                }
                if (currentButtonState == BUTTON_RELEASED && !SW1)
                {
                        currentButtonState = BUTTON PRESSED;
                }
        }
}
```

Interrupts.c

```
TMR2CN0_TF2H = 0;
incrementHandleStatus = INCREMENT_UNHANDLED;
```

Az elkészült programot be kell mutatni!

A gyakorlatvezető ellenőrizte:

- <u>Igen</u>
- Nem

A program működött:

- <u>Igen</u>
- Nem

Megjegyzések

A második feladatnál az volt a kérés, hogy rakjak be szoftveres pergésmentesítést. Egy pergésmentesítést alkalmaztam 8 bites túlcsordulással (ez túl kicsi valós pergések megfogására?).

A szorgalmi feladatban 35 Hz helyett kevesebbet alkalmaztam, mivel túl gyors volt az érdembeli értékeléshez.

Légyszi ne húzzatok le a select_display függvény miatt. Büszke vagyok rá.