# Timer, interrupt

#### MICLAB-03

Név: Stefán Kornél

Dátum: 2024. 09. 30. 18:00

Mérőhely: 7 bal

#### Bevezetés

Az interrupt használatának megismerése.

#### Ajánlott irodalom

http://www.inf.u-szeged.hu/noise/Education/MicLab/

### Jegyzőkönyv készítése

A jegyzőkönyvek az órán végzett munka dokumentálására szolgálnak. A letölthető minta jegyzőkönyvet kell kiegészíteni a megfelelő információkkal: név, dátum, mérőhely (pl. 3. jobb), a feladatokhoz tartozó esetleges kifejtendő válaszokkal, valamint a kódok lényeges részével.

A jegyzőkönyveket a CooSpace-en kell feltölteni, külön pdf formátumban csatolni kell a jegyzőkönyvet (a fájl neve a következő mintát kövesse: NagyJ.KissB.o3.pdf), egy külön zip fájlban pedig a kódokat (\*.c, \*.cwg). Amennyiben probléma merül fel a beadás során, az anyagokat az oktató e-mail címére kell elküldeni, levél tárgya legyen pl. MicLab o3.

## 1. feladat – Reakcióidő mérése

Írjon egy programot, ami mérni tudja a felhasználó reakcióidejét. Az idő méréséhez a Timero-át használja interrupt módban, az időmérés felbontása 1 ms legyen.

A működés leírása:

- indulás után valamennyi késleltetéssel felkapcsol a LEDo
- a felhasználónak minél rövidebb időn belül meg kell nyomnia a BTNo-át. Ha a 200 ms-on belül sikerül megnyomnia, akkor a LEDo lekapcsol.
- (Ügyeljen a megfelelő változóvédelemre és arra, hogy a LEDo ne kapcsoljon fel újra, ha már megtörtént a mérés és az belül volt a 200 ms-on.)

A program részekre bontott forráskódja (Config, Main.c, Interrupts.c, ha van):

#### Config

```
<property object="INTERRUPT 0" propertyId="interrupt.interruptenable.enabletimer0interrupt"</pre>
value="Enabled"/>
    cproperty object="P1.4" propertyId="ports.settings.outputmode" value="Push-pull"/>
    cproperty object="PBCFG_0" propertyId="pbcfg.settings.enablecrossbar" value="Enabled"/>
   cproperty object="TIMER01_0" propertyId="ABPeripheral.included" value="true"/>
cproperty object="TIMER01_0" propertyId="timer01.timer0highbyte.timer0highbyte" value="1"/>
    cproperty object="TIMER01 0"
propertyId="timer01.timer0mode2:8bitcountertimerwithautoreload.targetoverflowfrequency" value="1000"/>
    cproperty object="TIMER01 0"
propertyId="timer01.timer0mode2:8bitcountertimerwithautoreload.timerreloadvalue" value="1"/>
    cproperty object="TIMER16_2" propertyId="ABPeripheral.included" value="true"/>
cproperty object="TIMER16_3" propertyId="ABPeripheral.included" value="true"/>
   Counter/Timer with Auto-Reload"/>
   <property object="TIMER_SETUP_0" propertyId="timer_setup.timer0.timerrunningstate" value="Timer is</pre>
Running"/>
   <property object="TIMER_SETUP_0" propertyId="timer_setup.timer0.timerswitch1:runcontrol"</pre>
value="Start"/>
    <property object="TIMER_SETUP_0" propertyId="timer_setup.timer01control.timer0runcontrol"</pre>
value="Start"/>
  </mode>
  <modeTransition>
   <property object="RESET &#x2192; DefaultMode" propertyId="modeTransition.target"</pre>
value="DefaultMode"/>
  </modeTransition>
</device:XMLDevice>
Main.c érdektelen.
Interrupts.c
// src/Interrupts.c: generated by Hardware Configurator
//
// This file will be regenerated when saving a document.
// leave the sections inside the "\{\ldots\}" comment tags alone
// or they will be overwritten!
// USER INCLUDES
#include <SI_EFM8BB1_Register_Enums.h>
#define ONBOARD LED P1 B4
#define ONBOARD_BTN P0_B2
#define LED ENABLE 0
#define LED DISABLE 1
#define MAGIC WAIT 3795
#define ALLOWED_DELAY 200
#define COUNTER RESET 0
enum {
       WAIT_FOR_LED, // Waiting for LED to turn on (counting to 3795ms)
       LED_ON, // LED is on, waiting for button press
       LED_OFF // LED turned off after button press
} State;
extern uint16_t globalCounter = 0;
extern uint16_t globalState = WAIT_FOR_LED;
// TIMERØ ISR
//-----
//
// TIMERO ISR Content goes here. Remember to clear flag bits:
// TCON::TF0 (Timer 0 Overflow Flag)
SI_INTERRUPT (TIMERO_ISR, TIMERO_IRQn)
       switch (globalState)
       {
              // This is the initial state
```

```
case WAIT_FOR_LED:
                        globalCounter++;
                        if (globalCounter == MAGIC_WAIT)
                        {
                                 globalState = LED_ON;
                                 globalCounter = COUNTER_RESET;
                                 ONBOARD_LED = LED_ENABLE;
                        else
                        {
                                 ONBOARD_LED = LED_DISABLE;
                        }
                        break;
                // This is the speed testing part
                case LED ON:
                        if (globalCounter > ALLOWED_DELAY) {
                                 break;
                        globalCounter++;
                        if (!ONBOARD_BTN)
                                 globalState = LED_OFF;
                                 ONBOARD_LED = LED_DISABLE;
                        }
                        break;
                // This is the win condition
                case LED_OFF:
                default:
                        break;
        }
}
```

Az elkészült programot be kell mutatni!

A gyakorlatvezető ellenőrizte:

- Igen
- Nem

A program működött:

- Igen
- Nem

# 2. feladat – LED időzített vezérlése - SOS

Írjon egy programot, mely a LEDo segítségével kiadja az SOS morse kódot. A kód végén várjon 2 másodpercet, majd ismételje meg előröl a folyamatot.

A program részekre bontott forráskódja (Config, Main.c, Interrupts.c, ha van):

#### Config

```
<property object="INTERRUPT 0" propertyId="interrupt.interruptenable.enabletimer2interrupt"</pre>
value="Enabled"/>
  cproperty object="P1.4" propertyId="ports.settings.iomode" value="Digital Push-Pull Output"/>
  cproperty object="P1.4" propertyId="ports.settings.outputmode" value="Push-pull"/>
  cproperty object="PBCFG_0" propertyId="pbcfg.settings.enablecrossbar" value="Enabled"/>
  Running"/>
  value="5"/>
  <property object="TIMER16_2" propertyId="timer16.initandreloadvalue.timerreloadvalue"</pre>
value="14494"/>
  cproperty object="TIMER_SETUP_0" propertyId="ABPeripheral.included" value="true"/>
 <modeTransition>
  value="DefaultMode"/>
 </modeTransition>
</device:XMLDevice>
Main.c-ben nincsen semmi érdekes.
Interrupts.c
```

```
// src/Interrupts.c: generated by Hardware Configurator
// This file will be regenerated when saving a document.
// leave the sections inside the "[...]" comment tags alone
// or they will be overwritten!
// USER INCLUDES
#include <SI EFM8BB1 Register Enums.h>
#define LED ON 0
#define LED_OFF 1
#define FIRST_LETTER 0
#define NO_WAIT 0
#define SHORT_WAIT 1
#define LONG_WAIT 3
#define WORD_WAIT 10
#define ONBOARD LED P1 B4
#define ONBOARD BTN P0 B2
enum {
       DOT_ON, DOT_OFF,
       DASH_ON, DASH_OFF,
        LETTER_PAUSE, WORD_PAUSE
};
// Current state
extern uint16_t morseState = DOT_ON;
// Timer for longer operations (DASH)
extern uint16_t morseCounter = 0;
// Where we are in SOS
extern uint16_t letterIndex = 0;
const unsigned char morsePattern[] = {
       DOT_ON, DOT_OFF, DOT_ON, DOT_OFF, DOT_ON, DOT_OFF, // S = ...
        LETTER_PAUSE, // Pause between S and O
       DASH_ON, DASH_OFF, DASH_ON, DASH_OFF, DASH_ON, DASH_OFF, // 0 = ---
        LETTER PAUSE, // Pause between O and S
        DOT_ON, DOT_OFF, DOT_ON, DOT_OFF, DOT_ON, DOT_OFF, // S = ...
       WORD_PAUSE // Word pause after SOS 2s
};
// TIMER2_ISR
```

```
//
// TIMER2 ISR Content goes here. Remember to clear flag bits:
// TMR2CN0::TF2H (Timer # High Byte Overflow Flag)
// TMR2CN0::TF2L (Timer # Low Byte Overflow Flag)
//--
SI_INTERRUPT (TIMER2_ISR, TIMER2_IRQn)
        TMR2CN0 TF2H = 0; // Clear the timer interrupt flag
        switch (morseState)
        {
                case DOT_ON:
                         ONBOARD_LED = LED_ON;
                         morseCounter = NO WAIT;
                         morseState = DOT_OFF;
                         break;
                case DOT_OFF:
                         ONBOARD LED = LED OFF;
                         morseCounter = NO_WAIT;
                         letterIndex++;
                         morseState = morsePattern[letterIndex];
                         break;
                case DASH ON:
                        ONBOARD_LED = LED_ON;
                         if (morseCounter >= LONG_WAIT)
                         {
                                 morseState = DASH_OFF;
                                 morseCounter = NO_WAIT;
                         }
                         else
                         {
                                 morseCounter += SHORT_WAIT;
                         }
                         break;
                case DASH OFF:
                        ONBOARD_LED = LED_OFF;
                         morseCounter = NO_WAIT;
                         letterIndex++;
                         morseState = morsePattern[letterIndex];
                        break;
                case LETTER_PAUSE:
                         ONBOARD_LED = LED_OFF;
                         if (morseCounter >= LONG_WAIT)
                         {
                                 morseCounter = NO_WAIT;
                                 letterIndex++;
                                 morseState = morsePattern[letterIndex];
                         }
                         else
                         {
                                 morseCounter += SHORT_WAIT;
                         }
                        break;
                case WORD_PAUSE:
                        ONBOARD LED = LED OFF;
                         if (morseCounter >= WORD_PAUSE)
                         {
                                 morseCounter = NO_WAIT;
                                 letterIndex = FIRST_LETTER;
                                 morseState = morsePattern[letterIndex];
                         }
                         else
```

Az elkészült programot be kell mutatni!

A gyakorlatvezető ellenőrizte:

- <u>Igen</u>
- Nem

A program működött:

- <u>Igen</u>
- Nem

# Megjegyzések

A laboron megbeszéltük, hogy a második feladat kódja hosszú (129), de ez itt speciális engedéllyel lehet hosszú.