



APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 22-025

Date: 7/Oct/22

Reissued

SUBJECT: RAMP SAFETY

APPLICABLE TO: ALL RAMP PERSONNEL

Section H of ULTRA GOM H.4.5; 4.3.2; 4.5 and Section J.3.4 details the proper ramp safety procedures when Loading an aircraft

Don't allow this happen to you. Always pay attention to the task at hand

An aircraft was allowed to depart our station MIA, with a pallet of cargo in the wrong position inside its belly.

xxxxx kgs that could have caused the aircraft to suffer a catastrophic accident when taking off

If you are assigned as a crew member in a crew that is loading an aircraft you must:

1- Follow the LIR to the letter

2- No changes to the LIR will be performed unless approve by the dispatcher and or Load control officer

3- If any changes to the LIR are made by the Load control agent, these changes are to be discussed with the ramp Lead, and agents responsible for executing the changes

4- Once the loading is completed the ramp ;lead will sign the LIR, stating that the aircraft is loaded according to the instruction set forth on the LIR

Then and ONLY then can an aircraft be allowed to depart the gate

Remember you SMS training report any unsafe acts, or hazard conditions to you supervisor or manager or anonymously to safety@ultravi.com

Be SAFE follow all ramp safety rules and company SOP

PREPARED BY:

Safety Department



ULTRA AVIATION SERVICES, INC.

Standard Operations Manual

APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Sección H de ULTRA GOM H.4.5; 4.3.2; 4.5 y la Sección J.3.4 detalla los procedimientos adecuados de seguridad en rampa al cargar una aeronave

No permitas que esto te suceda. Siempre preste atención a la tarea en cuestión

Se permitió que un avión partiera de nuestra estación MIA, con una paleta de carga en la posición incorrecta dentro de su vientre.

XXXX kgs que podrían haber causado que la aeronave sufriera un accidente catastrófico al despegar

Si está asignado como miembro de la tripulación en una tripulación que está cargando una aeronave, debe:

- 1- Sigue la LIR al pie de la letra
- 2- No se realizarán cambios en el LIR a menos que lo apruebe el despachador o el oficial de control de carga
- 3- Si el agente de control de carga realiza cambios en el LIR, estos cambios deben discutirse con el líder de la rampa y los agentes responsables de ejecutar los cambios.
- 4- Una vez que se complete la carga, el líder de la rampa firmará el LIR, indicando que la aeronave está cargada de acuerdo con las instrucciones establecidas en el LIR.

Entonces, y SÓLO entonces, se puede permitir que un avión salga de la puerta

Recuerde que su capacitación por SMS informa cualquier acto inseguro o condiciones peligrosas a su supervisor o gerente o de forma anónima a safety@ultravi.com

PREPARED BY:

Safety Department

