



ULTRA AVIATION SERVICES, INC.

General Operations Manual

APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 18-008

Date: 13/Apr/18

Reissued

SUBJECT: RAMP procedures reminder PUSH BACK PROCEDURES for normal departures and tows

APPLICABLE TO: ALL RAMP PERSONNEL

Section J of ULTRA GOM J states that for every departure push and or tow the following personnel and procedure will be followed

GSE required

- 1-Push back, capable of pushing the type of aircraft been push
- 1 Tow bar , appropriate for the type of aircraft
- 1 Set of head set for ground to flight deck communication
- 2 pairs of wands. Plastic orange for daylight, lighted wands for night or adverse weather operation
- 1 hand held two way communication radio when towing

Personnel required

- 1 Qualified tug driver, If towing MUST have Movement Area AOA drivers permit
- 2 wing walkers

Procedures for PUSH operation

- 1- insert By Pass pin
- 2- Connect two bar
- 3- Connect head set
- 4- Connect tractor and tow bar
- 5- Conduct a pre departure walk around
- 6- Conduct a pre push / tow briefing with crew
- 7- When give the push back clearance, signal to wing walker, by blowing horn on tractor, and make sure that all area is clear

NOTE: DO NOT PUSH THE AIRCRAFT BACK IN REVERSE ALWAYS PERFORM THIS TASK FACING THE AIRCRAFT. WHEN ASSIGNED TO PERFORM A TOW, AFTER THE PUSH PORTION IS FINISHED, TURN THE TRACTOR AROUND SO YOU CAN PULL THE AIRCRAFT FORWARD AND COMPLETE THE TOW

Be SAFE follow all ramp safety rules and company SOP

PREPARED BY:

Safety Department