



ULTRA AVIATION SERVICES, INC.

General Operations Manual

APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 19-015

Date: 17/Jul/19

SUBJECT: RAMP SAFETY

APPLICABLE TO: ALL ULTRA RAMP personnel

REMEMBER

When assigned to push back and or tow a B-737 aircraft.....REMEMBER

- 1- always have in your possession your FL Driver License, MDAD ID, and AOA drivers permit
- 2- You must insure that your GSE is in working condition by performing a pre trip safety walk around
- 3- **Make sure that you have the correct by pass pin for the aircraft type**
- 4- ON the 300 to 700 series make sure that the bulb stays in, if you hear a popping noise once you have inserted the pin, call maintenance immediately. This means that the system is not fully bypassed and the pumps might need to be turned off
- 5- USE HEAD SET communications with the flight deck at all times during push back and towing

737-300-700. Thin pin



Right side of gear



737-800/900 thicker pin



Lever is located on the Left side of gear



**DO NOT
FORGET TO
USE YOUR
WING
WALKERS**

BE safe your life and that of others might depend on it

PREPARED BY:

Your friendly Safety Department...use your SMS training report any hazards to safety@ultravi.com