



ULTRA AVIATION SERVICES, INC.

General Operations Manual

APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 16-003

Date: 19/Mar/16

SUBJECT: DRIVING ON THE AOA

APPLICABLE TO: ALL ULTRA AVIATION SERVICE AGENTS

When operating a vehicle on the Airport Operation Area (AOA) you will always follow the following rules and procedures:

- 1- Perform a safety walk around before operating the vehicle
- 2- Perform a brake check
- 3- Do not operate any Ground Support equipment that is not mechanically sound (working properly)
- 4- If operating in a congested area or when driving in reverse always use a guide person
- 5- DO NOT operate a piece of Ground support equipment if you have not been properly trained and certified to use it
- 6- Be aware of your surrounding 100% of the time
- 7- Observe all traffic markings and speed limits
- 8- Remember Airplanes, passenger and fuel trucks have the right of way
- 9- Report all mishaps no matter how minor
- 10- If in doubt STOP

PREPARED BY:

ERNESTO RIVERO