



APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 20-009

Date: 31-Oct-20

Reissued

SUBJECT: Tow bar connection and dis connection from aircraft

APPLICABLE TO: ALL ULTRA RAMP PERSONNEL

When assigned to connect the tow bar to the aircraft and push back tractor
Remember

- 1- Use the correct tow bar for the aircraft been push or tow
- 2- Insure that the by pass pin is in place
- 3- Connect to the aircraft first. Make sure that the bar locks in place and the safety pin is on
- 4- Connect to the push back tractor
- 5- Raise the tow bar wheel

6- Never move the aircraft without following point 5. Prevent damages to the bar



When in doubt check our company GOM section J it is in the company Portal


www.ultravi.com/ops

User name: employee

PW:ultravi

Cuando sea asignado a conectar una barra de empuje: Recuerde

- 1- Use la barra correcta para el tipo de aeronave
- 2- Asegurese que el pin de by pass de la aeronave este conectado
- 3- Conecte la barra a la aeronave primero. Asegúrese que el pin de seguridad de la barra este insertado.
- 4- Conecte el tractor
- 5- Suba las ruedas de la barra



6- Nunca mueva una aeronave sin completar el paso numero 5 . Prevenga daños a la barra de remolque



Si tiene alguna duda consulte nuestro GOM de la compañía. Lo encuentra en nuestro Portal

www.ultravi.com/ops

Nombre de usuario: employee

Contraseña: ultravi

Be SAFE follow all safety rules and company SOP

PREPARED BY:

Safety Department