

LINK

MICLINEHI-Z

INPUT

+48HPF

EQCOMPSEND

HF

FREQATKHPFTHRESH

FREQREL

FREQRATIO

FREQLFDE-ES

SOLOMUTESEL

PAN

INS

PRE

REC

MICLINEHI-Z

INPUT

+48HPF

HF

FREQHMFTHRESH

FREQREL

FREQRATIO

FREQLFDE-ES

SOLOMUTESEL

PAN

INS

PRE

REC

SEND

EQ

COMP

Aux 1 (press enable)

HF Gain (Hold for Q)

In Gain

Pan

Freq

Attack

Aux 2 (press enable)

HMF Gain (Hold for Q)

Thresh

Pan

Freq

Release

Aux 3 (press enable)

LMF Gain (Hold for Q)

Out Gain

Pan

Freq

Ratio

Aux 4 (press enable)

LF Gain (Hold for Q)

De-Ess Amt

Pan

Freq



