

## GP33 NMEA0183 CABLE WARNING! CUT OFF THE FUSES-THEY ARE NOT FOR DISPLAY POWER!

## **GP33 WIRING AND OP MANUAL CORRECTION:**

Installers, please note that when this optional 000-156-405 cable is used with the GP33, the red and black fused wires WILL NOT POWER THE DISPLAY!

(This cable is also used as the FCV620/585 Power/Data Cable)

When used with the GP33, cut the fuses off of the cable as the red/black wires are only used for the GP33 Speed Alarm Output.

GP33 Rev. A Ops. Manual Interconnection Diagram Correction:

ps. Mandai interconnection Diagram correction.

FINE DAN LOUS UP 保存 23 (A) THE PART OF T

Pin 7 = RED Wire, Pin 8 = Black of 000-156-405 cable. Other colors are correct. Please cut the fuses from the cable and use the red/black wires for the speed alarm output if desired.