ENR 3.3 AREA NAVIGATION (RNAV) ROUTES

of ing	Direction of cruising levels Odd Even		RNP Type	Remarks
			5	6
				Two-way radio contact
	•	↑		to be maintained with ATC in these airspaces Solwezi Approach avail able HJ as a relay sta- tion. Lusaka Control Frequency. 123.925Mhz 8888.0Khz 8873.0Khz 6586.0Khz
•	-			

THIS PAGE INTENTIONALLY LEFT BLANK