ENR 1.11 ADDRESSING OF FLIGHT PLAN MESSAGES

Flight movement messages relating to traffic into or via the Lusaka FIR shall be addressed as stated below in order to warrant correct relay and delivery.

All flights into or via Lusaka FIR shall be addressed to FLKKZPZX and FLFIZQZX

NOTE: Flight movement messages in this context comprise flight plan messages, amendment messages relating thereto and flight plan cancellation messages (ICAO PANS-ATM, Doc 4444, Part VIII, 2.1.1.3 refers).

Category of fight (IFR, VFR or both)	Route (into or via FIR and/or TMA)	Message address
1	2	3
IFR and VFR flights	into or via Lusaka FIR and, in addition, for flights:	FLFIZQZX
	- into or via Lusaka TMA	FLKKZAZX FLKKZTZX FLKKZPZX
	- within the Lusaka FIR	FLFIZQZX FLKKZPZX
	into or via Solwezi CTA	FLSWZTZX FLSWZPZX
	into or via Ndola TMA	FLSKZTZX FLSKZAZX FLSKZPZX
	into or via Mfuwe TMA	FLMFZTZX FLMFZPZX
	into or via Livingstone CTA	FLHNZTZX FLHNZAZX FLHNZPZX
	Into or Via FLKS aerodrome	FLKSZPZX
	Into or via FLMG aerodrome	FLHNZTZX FLHNZPZX FLMGZPZX
	Into or Via FLMA aerodrome	FLMAZPZX
	Into or Via FLCP aerodrome	FLMFZPZX FLMFZTZX FLCPZPZX
All flights	uncontrolled aerodrome	No AFTN address for uncontrolled aerodromes use ICAO location indicator for the nearest controlled aerodrome plus "FLFIZFZX" for VFR or "FLFIZQZX" for IFR

THIS PAGE INTENTIONALLY LEFT BLANK