GEN 2.2 ABBREVIATIONS USED IN AIS PUBLICATIONS

	GLN 2.2 ADDREVIATIONS		AIS FUBLICATIONS
<u>A</u>		<u>A</u>	
A	Amber	ALT	Altitude
AAA	(or AAB, AACetc in sequence) Amended Meteorological message (message type designator)	ALTN	Alternate or Alternating (light alternates in the colour)
A/A	Air-to-Air	AMA	Area Minimun Altitude
AAL	Above aerodrome level	AMD	Amend or amended (used to indicate amended Meteorological message; type designator)
ABM	Abeam	AMDT	Amendments (AIP Amendment)
ABT	About	AMS	Aeronautical mobile service
AC	Altocumulus	AMSL	Above mean sea level
ACAS+	Airbourne collision avoidance system	AMSS	Aeronautical mobile satellite service
ACC++	Area control centre or area control	ANS	Answer
Accid	Notification of aircraft accidents	AOC	Aerodrome Obstacle Chart
ACFT	Aircraft	AP	Airport
ACK<	Acknowledge	APCH	Approach
ACL	Altimeter check location	APP	Approach Control Office or Approach Control or Approach Control service
ACN	Aircraft Classification Number	APR	April
ACP	Acceptance (message type designator)	APRX	Approximate or approximately
ACPT	Active or Activated or Activity	APSG	After passing
AD	Aerodrome	APV	Approveor approved or approval
ADA	Advisory Area	ARFOR	Aerial forecast (in aeronautical Meteorological code)
ADDN	Addition or Additional	ARNG	Air Traffic service Reporting office
ADF++	Automatic Direction Finding Equipment	ARO	Air Traffic service Reporting office
ADIZ	(to be pronounced "AY-DIZ") Air	ARP	Aerodrome reference point
ADJ	Adjacent	ARP	Air-Report (Message type designator)
ADR	Advisory Route	ARQ	Automatic Area Correction
ADS	Automatic Dependence Surveillance	ARR	Arrive or Arrival
ADSU	Automatic Dependence Surveillance Unit	ARR	Arrival (message type designator)
ADVS	Advisory service	ARS	Special Air Report (message type designator)
ADZ	Advise	ASRT	Arresting (specify part of) aircraft aresting equipment
AES	Aircraft Earth Service	AS	Altostratus
AFIL	Flight Plan Filed in the air	ASC	Ascent or ascending to
AFIS	Aerodrome Flight Information Service	ASDA	Accelerate stop distance available
AFM	Yes or Affirm or Affirmative or that Is correct	ASPH	Asphalt
AFS	Aeronautical Fixed Service	AT	At (followed by time at which weather change is forecast to occur)
AFT	After(time or place)	ATA++	Actual time of arrival
AFTN++	Aeronautical Fixed Telecommunication Network	ATC++	Air Traffic Control (in general)
A/G	Air-to-Ground	ATD	Actual time of departure
AGA	Aerodromes,air routes and ground Aids	ATFM	Air traffic flow management
AGL	Above Ground Level	ATIS	Aeroautical telecommunications network
AGN	Again	ATM	Air Traffic Management
AIC	Aeronautical Information Circular	ATN	Aeronautical telecommunications network
AIP	Aeronautical Information Publication	ATP	AT(time or place)
AIRAC	Aeronautical Information regulation and Control	ATS	Air Traffic Services
AIREP	Air Report	ATTN	Attention
AIS	Aeronautical Information Service	ATZ	Aerodrome Traffic Zone
ALA	Alighting Area	AUG	Authorized as putherizeties
ALERFA	Alerting (massage type designator)	AUTH	Authorised or authorisation
ALR	Alerting (message type designator)	AUW	All up weight
ALRS	Alerting Service	AUX	Auxiliary

ALS	Approach lighting system	AVASIS	Abbreviated visual approach slope indicator system
		AVBL	Available or availability
<u>A</u>		<u>C</u>	
AVG	Average	CIT	Near or over large towns
AVGAS	Aviation gasoline	CIV	Civil
AWTA	Advise at what time able	CK	Check
AWY	Airways	CL	Centre line
AZM	Azimuth	CLA	Clear type of ice formation
		CLBR	Calibration
<u>B</u>		CLD	Cloud
<u>=</u> В	Blue	CLG	Calling
BA	Braking action	CLR	Clear (s) or clear toor clearance
BASE	Cloud base	CLSD	Close or closed or closing
BCFG	Fog patches	CM	Centimetres
BCM	Beacon (aeronautical ground light)	CMB	Climb to or climbing to
BCST	Broadcast	CMPL	Completion or completed or complete
BDRY	Boundary	CNL	Flight plan cancellation (message type designa-
BBITT	Boundary	ONE	tor)
BECMG	Becoming	CNS	Communication, navigation and surveillance
BFR	Before	COM	Communications
BKN	Broken	CONC	Concrete
BL	Blowing (followed by DU=Dust, SA=sand or SN=snow)	COND	Condition
BLDG	Building	CONS	Continuous
BLO	Below clouds	CONST	Construction or constructed
BLW	Below	CONT	Continue(s) or continued
BOMB	Bombing	COOR	Co-ordinate or co-ordination
BR	Mist	COP	Change of point
BRF	Short(used to indicate the type of approach de-	COR	Correct or correction or corrected(used to in-
	sired or required)		dicate corrected Meteorological message type designator)
BRG	Bearing	COT	At the cost
BRKG	Braking	COV	Cover or covered or covering
BS	Commercial broadcasting station	CPL	Current flight plan (message type designator)
BTL	Between layers	CRZ	Cruise
BTN	Between	CS	Cirrostratus
		CTA	Control Area
<u>C</u>		CTAM	Climb to and maintain
С	Centre (runway identification)	CTC	Contact
С	Degrees Celsius (Centigrade)	CTL	Control
CAT	Category	CTN	Caution
CAA	Civil Aviation Authority	CTR	Control Zone
CAT	Clear air turbulance	CU	Cumulus
CAVOK	(to be pronounced "KAH-OH-KAY") Visibility, cloud and present weather better than prescribed values or conditions.	CUF	Cumuliform
CB++	(to be pronounced ("CEE BEE") Cumulonimbus	CUST	Customs
CC	Cirrocumulus	CV FR	Controlled VFR Flight
CCA	(or CCB,CCCetc,in sequence) corrected Mete-		Continuous wave
	orological message (message type designator)		
CDA	Candela Caprillation (massage designator)	CWY	Clear way
CDA CF	Co-ordination (message designator)	<u>D</u> D	Danger area (followed by identification)
CF	Change frequency to circling guidance light (s)	D	Danger area (followed by identification)
			Downward (tendency in RVR during previous 10 minutes)
CH	Channel	DA	Decision altitude
CHG	Modification (message type designator)	DCD	Double channel duplex

\sim 1	Cirrus
UI .	Cirrus

CIDIN Common ICAO data interchanged network

<u>D</u>		<u>E</u>	
DCKG	Docking	ELEV	Elevation
DCS	Double channel simplex	ELR	Extra Long Range
DCT	Direct (in relation to flight plan clearances and	EM	Emmission
DEC	types of approach) December	EMBD	Embedded in a layer (to indicate cumulonimbus
DEG	Dograda	EMERG	embedded in layers of other clouds)
DENEB	Degrees Fog dispersal operations	END	Emergency Stop- end (relative to RVR)
DENEB		ENE	East north east
DES	Depart or departure	ENG	
DEST	Descend to or descending to Destination	ENR	Engine EN-route
DETRES-		EOBT	Estimate off – block time
FA	Distress phase	EODI	Estimate on – block time
DEV	Deviation or deviating	EQPT	Equipment
DFTI	Distance from touchdown indicator	ER	Hereor herewith
DH	Decision height	ESE	East south east
DIF	Diffuse	EST	Estimate or estimated or estimating (message type designator)
DIST	Distance	ETA++	Estimated time of arrival or estimating arrival
DIV	Divert or diverting	ETD++	Estimated time departure or estimating departure
DLA	Delay (message type designator)	ETO	Estimated time over significant point
DLA	Delay or delayed	EV	Every
DME++	Distance measuring equipment	EXC	Except
DNG	Danger or dangerous	EXER	Exercises or exercising or to exercise
DOM	Domestic	EXP	Expect or expected or expecting
DP	Dew point temperature	EXTD	Extend or extending
DPT	Depth		•
DR	Dead reckoning	<u>F</u>	
DR	Low drifting (followed by DU= Dust, SA= Sand or SN= Snow		Fixed
DRG	During	FAC	Facilities
DS	Duststorm	FAF	Final approach fix
DSB	Double sideband	FAL	Facilitation of international air transport
DTAM	Descend To And Maintain	FAP	Final approach point
DTG	Date- Time Group	FATO	Final Approach and take-off Area
DTRT	Deteriorate or Deteriorating	FAX	Facsimile transmission
DTW	Dual tandem wheels	FBL	FBL light (used to indicate the intensity of weather phenomena, interface or reports, eg. FBL RA = light rain)
DU	Dust	FC	Funnel cloud (Tornado or water spout)
DUC	Dense Upper Cloud	FCST	Forecast
DUR	Duration	FCT	Friction coefficient
DVOR	Doppler VOR	FEB	February
DW	Dual Wheels	FG	Fog
DZ	DrizzleE	FIC	Fighting Information Centre
		FIR++	Flight Information Region
<u>E</u>		FIS	Flight Information Service
E	East or Eastern Longitude	FISA	Automated flight information service
EAT	Expected Approach Time	FL	Flight level
EB	East Bound	FLD	Field
EET	Estimated Elapsed Time	FLG	Flashing
EFC	Expected Further Clearance	FLR	Flares

EHF ELBA	Extra High Frequency (30,000 to 300,00 MHz) Emergency Location Beacon Aircraft	FLT FLTCK	Flight Flight check
F			
<u>F</u> FLUC	Eluctuating or fluctuation or fluctuated	<u>H</u> H24	Continuous day and night convice
	Fluctuating or fluctuation or fluctuated	HAPI	Continuous day and night service
FLW FLY	Follow (s) or following	HBN	Helicopter approach path indicator Hazard beacon
FM	Fly of flying From	HDF	High frequency direction –finding station
FM	From (followed by time weather change is fore-	HDG	Heading
	cast to begin)		•
FMU	Floor management unit	HEL	Helicopter
FNA	Final approach	HF++	High frequency (3, 000 to 30,000 Khz)
FPL	Filed flight plan (message type designator)	HGT	Height or height above
FPM	Feet per minute	HJ	Sunrise to Sunset
FPR	Flight plan route	НО	Service available to meet operational Requirements
FR	Fuel remaining	HOL	Holiday
FREQ	Frequency	HOSP	Hospital aircraft
FRI	Friday	HPA	Hectopascal
FRNG	Firing	HR	Hour
FRONT	Front (relating to weather)	HRS(*)	Hours
FRQ	Frequent	HS	Service available during hour of scheduled operations
FSL	Full stop landing	HURCN	Hurricane
FSS	Flight Service Station	HBDF	High and very high frequency direction-finding stations (at the same location)
FST	First	HVY	Heavy
FT	Feet dimensional unit	HVY	Heavy (used in indicating intensity or weather phenomena, eg. HVYRA = heavy rain)
FU	Smoke	HX	No specific working hours
FZ	Freezing	HYR	Higher
FZDZ	Freezing drizzle	HZ	Hertz (cycle per second)
FZFG	Freezing fog		
FZRA	Freezing rain	<u>I</u>	
		IAC	Instrument approach chart
<u>G</u>		IAF	Initial approach fix
G	Green	IAO	In and out of clouds
GA(*)	Go ahead resume sending	IAR	Intersection of air routes
G/A	Ground-to –air	IAS	Indicated air speed
G/A/G	Ground-to-air-and air-to-ground	IBN	Identification Beacon
GCA++	Ground controlled approach system for ground controlled approach	IC	Diamond dust (very small ice crystals in suspension)
GEN	General	ICAO(*)	International Civil Aviation Organisation
GEO	Geographic or True	ICE	Icing
GES	Ground earth station	ID	Identifier or identify
GND	Glider	IDENT	Identification
GNDCK	Ground check	IF	Intermediate approach fix
GNSS	Global navigation satellite system	IFF	Identification friend/foe
GP	Glide path	IFR	Instrument flight rules
GPS(*)	Global positioning system	IGA	International General Aviation
GR	Hail	ILS++	Instrument landing system
GRASS	Grass landing area	IM	Inner marker
GRID	Processed Meteorological data in the form of grid point value (Aeronautical Meteorological code)		Instrument Meteorological Conditions
GRVL	Gravel	IMG	Immigration
GS	Ground speed	IMPR	improve or improving

GS

Small hail and /or snow pellets

I	G/S(*)	Glide slope	INA	Initial approach
INBD Inbound LGT Light or lighting INC IN cloud LGTD Light intensity high INFO Information LIL Light intensity high INFO Information LIL Light intensity medium INC If not possible LLZ Localiser INFR In progress LM Local medium INST Inertial navigation system LMT Local mean time INSTR Install or installed or installation LMT Local mean time INSTR Install or installed or installation LMT Local mean time INSTR Instrument LOC Local or locally or location or located INSTR International store LOC Local or locally or olocation or located INTTR Interrupting or interruption or interrupted LR LORAN LORAN (long range air navigation system) INTSF Interrupting or interruption or interrupted LR The last message sent by me was INTSF Interrupting or interruption or interrupted LR LR The last message sent by me w	0/0()	Clide Slope	III	пппагарргоаст
INBD Inbound LGT Light or lighting INC IN cloud LGTD Light intensity high INFO Information LIL Light intensity high INFO Information LIL Light intensity medium INC If not possible LLZ Localiser INFR In progress LM Local medium INST Inertial navigation system LMT Local mean time INSTR Install or installed or installation LMT Local mean time INSTR Install or installed or installation LMT Local mean time INSTR Instrument LOC Local or locally or location or located INSTR International store LOC Local or locally or olocation or located INTTR Interrupting or interruption or interrupted LR LORAN LORAN (long range air navigation system) INTSF Interrupting or interruption or interrupted LR The last message sent by me was INTSF Interrupting or interruption or interrupted LR LR The last message sent by me w				
INBD Inbound LGT Light or lighting INC IN cloud LGTD Light intensity high INFO Information LIL Light intensity high INFO Information LIL Light intensity medium INC If not possible LLZ Localiser INFR In progress LM Local medium INST Inertial navigation system LMT Local mean time INSTR Install or installed or installation LMT Local mean time INSTR Install or installed or installation LMT Local mean time INSTR Instrument LOC Local or locally or location or located INSTR International store LOC Local or locally or olocation or located INTTR Interrupting or interruption or interrupted LR LORAN LORAN (long range air navigation system) INTSF Interrupting or interruption or interrupted LR The last message sent by me was INTSF Interrupting or interruption or interrupted LR LR The last message sent by me w				
INBD Inbound LGT Light or lighting INC IN cloud LGTD Light intensity high INFO Information LIL Light intensity high INFO Inforperative LIM Light intensity medium INC If not possible LLZ Localiser INFR In progress LM Local man time INST Inertial navigation system LMT Local mean time INST Install or installed or installation LMT Local do include to indicate the type of approach desired or required) INSTR Instrument LOC Local or locally or location or located INTT International LOC Local or locally or location or located INTT International standard management LDC Local or locally or obtain or located INTSF Interrupting or interruption or interrupted LR The last message received by me was INTSF Interrupting or interruption or interrupted LR The last message sent by me was INTSF International standard atmosphere LTD Limited <				
INC IN cloud LGTD Lighted INCERFA uncertainty phase LIH Light intensity high INFO Information LIL Light intensity low INOP Inoperative LIM Light intensity medium INC In ot possible LLZ Localiser INFR In progress LM Locate, middle INST Install or installed or installation LNG Longused to indicate the type of approach desired or required) INSTR Instrument LO Locator, outer INT Intersection LOC Local or locally or location or located INT Interrepting or interruption or interrupted LR The last message received by me was. INTST Interrupting or interruption or interrupted LR The last message received by me was. INTST Intensity or intensity intensity intensity in the intensity or intensity intens				
INCERAL uncertainty phase LIH Light intensity low INFO Information LIL Light intensity low INC If not possible LLZ Localiser INS Inertial navigation system LMT Local or incidale INS Inertial navigation system LMT Local mean time INSTR Install or installed or installation LMT Local was dead to indicate the type of approach desired or required) INSTR instrument LOC Local or locally or location or located INT Intersection LOC Local or locally or location or located INT Interraction LOC Local or locally or location or located INTR Interractional LORA LORAN (long range air navigation system) INTSR Interrupting or interruption or interrupted LR The last message received by me was. INTSR Intensity or intensifying LR LR Lorg user air navigation system) INTST Intensity or intensifying LR LS The last message sent by me was. INTST Intensity				
INFO Information LIL Light intensity low INOP Inoperative LIM Light intensity medium INC If not possible LLZ Localiser INS In progress LM Local mean time INSTI Install or installed or installation LNG Long(used to indicate the type of approach desired or required) INSTR Instrument LO Locator, outer INT Intersection LOC Locator, outer INTR Interruption or interrupted LR Conglude INTSR Interrupting or interruption or interrupted LR The last message received by me was. INTSP Internusting or interruption or interrupted LR The last message received by me was. INTSF Internsity or intersifying LR The last message received by me was. INTSF Intensity or intensifying LR The last message received by me was. INTSF Intensity or intensifying LS The last message sent by me was. INTSF Intensity or intensifying LS The last message received by me				-
INOP Inoperative LIM Light intensity medium INC If not possible LLZ Localiser INS In progress LM Locator, middle INST Install or installed or installation LNG Long(used to indicate the type of approach desired or required) INSTR instrument LO Locator, outer INT Intersection LOC Local or locatily or location or located INTR Interrogator LORAN LORAN (long range air navigation system) INTSF Interrupting or interruption or interrupted LR The last message received by me was. INTSF Internsity or intensifying LR The last message sent by me was INTSF Internsity or intensifying LS The last message sent by me was INTSF Intersection LT Limited INTSF Intersection LT Limited INTSF Intersection LT Limited INTSF Intersection LT Limited INSO Lean or leaning LEAN <		· ·		
INC If not possible LLZ Locatiser INPR In progress LM Locator, middle INST Install or installed or installation LNT Local mean time INSTR Install or installed or installation LNC Lorgused to indicate the type of approach desired or required?) INSTR Instrument LO Locator, outer INT Interestion LONG Logal or location or located INTRP Interrogator LORAN LoRAN (long range air navigation system) INTSF Interrogator interruption or interrupted LR The last message received by me was. INTSF Internsity or intersitying LR Long range INTSF Intensity or intersitying LR Long range INTSF Intensity or intersitying LR The last message sent by me was INTSF Intensity or intersitying LR Long trange INTSF Intensity or intersitying LR Land transity at the security	INFO	Information	LIL	-
INPR In progress LM Locator, middle INS Inertial navigation system LMT Location, middle INSTL Install or installed or installation LNG Long(used to indicate the type of approach desired or required) INSTR instrument LO Locator, outer INT Intersection LOC Local or locatily or location or located INTR Interrational LONG Logalude INTRP Interrupting or interruption or interrupted LR The last message received by me was. INTST Intensity or intensitying LRG Long range INSA Intensity or intensitying LRG Long range INST Independent sideband LTT Landing teletypewriter ISO Line squal LTT	INOP	Inoperative	LIM	Light intensity medium
INS Inertial navigation system LMT Local mean time INSTR Instrument LO Long(used to indicate the type of approach designed or required) INSTR instrument LO Locator couter INT Intersection LOC Locator cotally or location or located INTGR International LONG Longitude INTST Interrupting or interruption or interrupted LR The last message received by me was. INTST Intensity or intensifying LR The last message received by me was. INTST Intensity or intensifying LR The last message sent by me was. INTST Intensity or intensifying LS The last message sent by me was. INTST Intensity or intensifying LS Line squall INTST Line squall LID Lintensity Line squall	INC	If not possible	LLZ	Localiser
INSTL Install or installed or installation LNG Long(used to indicate the type of approach desired or required) INSTR instrument LO Locator, outer INT Intersection LOC Local or locally or location or located INTR Interruption LORAN LORAN (long range air navigation system) INTSF Interrupting or interruption or interrupted LR The last message received by me was. INTSF Internsity or intensifying LRG Long range INTST Intensity LR Long range IR lo con runway LSQ Line squall ISA Intersected LTD Limited ISA Intersected LTD Limited ISA Intersected LTD Lase or lavariab	INPR	In progress	LM	Locator, middle
INSTR instrument LO Locator, outer INTT Intersection LOC Locator, outer INTG International LONG Longitude INTRP Interrogator LORAN LORAN (long range air navigation system) INTRP Internityting or interruption or interrupted LR The last message received by me was INTST Intensity or intensifying LRG Long range INTST Intensity or intensitying LSQ Line squall INTST Intensity or intensifying LSQ Line squall ISA Lablean squall LTT Landing teletypewriter	INS	Inertial navigation system	LMT	Local mean time
INSTR instrument LO Locator, outer INT Intersection LOC Local or location or located INTR International LONG Longitude INTRP Interropator LORAN LORAN (long range air navigation system) INTSF Intensify or intensifying LRG Long range INTST Intensational standard atmosphere LTD Line squall ISO Independent sideband LTD Limited ISO Isolated LV Light and variable (relating to wind) ISO Isolated LV Light and variable (relating to wind) JYS LYR Lave or layeredM JAN January	INSTL	Install or installed or installation	LNG	
INT Intersection LOC Local or locally or location or located INTG Intermational LONG Longitude INTSP Interropting or interruption or interrupted LR The last message received by me was. INTSF Intensify or intensifying LRG Long range INTST Intensify or intensifying LSQ Lines quall INTST Intensity or intensify or intensifying LSQ Lines quall INTST Intensity or intensify or intensifying LSQ Linesquall INTST Intensitional standard atmosphere LTD Limited ISS Intelegendent sideband LTT Laming teletypewriter ISOL Isolated LV Light and variable (relating to wind) ISS Independent sideband LTT Lawre or leaving JUV Ly Light and variable (relating to wind) ISOL Leave or leaving LV Leave or leaving JUN July Leave or leaving Leave or leaving JUN July MA Maximum authorised alt	INSTR	instrument	LO	
INTG Interrogator LONG Longalude INTGR Interrogator LORAN LORAN (long range air navigation system) INTSF Interrupting or interruption or interrupted LR The last message received by me was. INTSF Intensify or intensifying LR Long range INTST intensity LS The last message sent by me was IR loe on runway LSQ Line squall ISA International standard atmosphere LTD Limited ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) JUN Just and variable (relating to wind) LVE Leave or leaving JUN July M Metres (preceded by figures) JUN July M Metres (preceded by figures) MCS KIlogram MAN Maximum authorised altitude K MG Milograms MAP Meronautical maps and charts KHZ Kilogram MAPT Minimum	INT	Intersection	LOC	
INTGR Interrogator LORAN LORAN (long range air navigation system) INTRP Interrupting or interruption or interrupted LR The last message received by me was. INTST Intensity or intensitying LRG Long range INTST intensity LSC Line squall ISA International standard atmosphere LTD Limited ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) ISDL Isolated LVL Leave or leaving JUN January LVL Level JUN July M Metres (preceded by figures) JUN June MAA Maximum authorised altitude K MAG Magnetic KGS (*) Kilogram MAP Aeronautical maps and charts KHZ Kilohetz MAP Aeronautical maps and charts KMS (*) Kilometre MAR At sea KMS(*) Kilometre Per Hour MAS </td <td></td> <td>International</td> <td></td> <td></td>		International		
INTRP Intersity or intensitying LRG Long range INTSF Intensity or intensitying LRG Long range INTST Intensity LS The last message sent by me was IR Ice on runway LSQ Line squall ISA International standard atmosphere LTD Limited ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) LVL Level Leave or leaving JAN January LYR Leaver or layeredM JUL July LVL Leaver or layeredM JUN July ME V JUN July MM Metres (preceded by figures) JUN June MA Metres (preceded by figures) KG Kilogram MAA Maximum authorised altitude KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kiloberter MAP Aeronautical maps and charts				_
INTSF Intensity LRG Long range INTST intensity LS The last message sent by me was IR Ice on runway LSQ Line squall ISA International standard atmosphere LTD Limited ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) ISD Lyc Leave or leaving J January LVL Level JAN January LYR Layer or layeredM JUL July ME Layer or layeredM JUN July ME Met a sequer or layeredM JUN July ME Layer or layeredM JUN July Met a sequer or layeredM JUN July ME Layer or layeredM JUN July Met a sequer or layeredM JUN July Met Met sequer or layeredM JUN July Met Met sequer or layeredM JUN		•		
INTST intensity LSQ The last message sent by me was IR loe on runway LSQ Line squall ISA International standard atmosphere LTD Limited ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) ISOL Isolated LVE Leave or leaving JUL Level Leave or laveredM JAN January LYR Layer or layeredM JUL July Metres (preceded by figures) JUL July MM Metres (preceded by figures) MAD Maximum authorised altitude K MAA Maximum authorised altitude KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilohetrz MAP Airace approach point KM Kilometre MAR At sea KMS(*) Kilometre MAR At sea				· ·
IR Ice on runway LSQ Line squall ISA International standard atmosphere LTD Limited ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) JUR LVE Leave or leaving JAN January LV Lyer or layeredM JTST Jet Stream JUL Luyer or layeredM JUL July M Metres (preceded by figures) MAR Maximum authorised altitude MS Maximum authorised altitude MS Magnetic KGS(*) Kilogram MAR Marimum authorised altitude KGS(*) Kilogram MAR Marimum authorised altitude KHZ Kilohertz MAP Aeronautical maps and charts KHZ Kilohertz MAPT Missed approach point KM Kilometre MAR At sea KMS(*) Kilometre Per Hour MAS Manual AL simplex KPA Kilometre Per Hour MAS Manual AL simplex <			_	
ISA International standard atmosphere LTD Limited ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) LVE Leave or leaving JUL LyR Layer or layeredM JTST Jet Stream JUL Lyl JUN Jule M Metres (preceded by figures) MA Maximum authorised altitude K MAG Maginere KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilohertz MAPT Missed approach point KM Kilometre MAR At sea KMS(*) Kilometre MAR March KMM Kilopascal MAR Maximum KT Knot MAX Maximum KTS(*) Knot MC Minimum crossing altitude KTS(*) Knot MC Minimu		-		
ISB Independent sideband LTT Landing teletypewriter ISOL Isolated LV Light and variable (relating to wind) JEVE Leave or leaving LVL Level JAN January LYR Layer or layeredM JTST Jet Stream M Metres (preceded by figures) JUN June M Metres (preceded by figures) K MAA Maximum authorised altitude K MAG Magnetic KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilohertz MAP Aeronautical maps and charts KMS(*) Kilometre MAR At sea KMS(*) Kilometre Per Hour MAS Manual AL simplex KMH Kilometre Per Hour MAS Manual AL simplex KT Knot MAX Maximum KT Knot MAX Maximum KT Knot MAX <td></td> <td>-</td> <td></td> <td>•</td>		-		•
ISOL Isolated LV Light and variable (relating to wind) J LVE Leave or leaving JAN January LVL Level JTST Jet Stream Value M JUL July M Metres (preceded by figures) JUN June MA Maximum authorised altitude K MAG Magnetic KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilohertz MAPT Missed approach point KM Kilometre MAR At sea KMS(*) Kilometre Per Hour MAS Mavial AL simplex KMH Kilopascal MAX Maximum KT Knot MAX Maximum KTS(*) Knots MCA Minimum crossing altitude KW Kilowatts MCA Minimum descent altitude KW Kilowatts MCW Modulated continuous wave MDA Medium frequency direction-finding station L Left (runway identification) MDH Minimum descent height L Left (runway identification) MDH Minimum en-route altitude				
J LVE Leave or leaving JAN January LYR Layer or layeredM JTST Jet Stream JUL JUN JUN JUN June MA Metres (preceded by figures) K MAA Maximum authorised altitude K MAG Magnetic KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilometre MAP Aeronautical maps and charts KHZ Kilometre MAR At sea KMS(*) Kilometres MAR March KMM Kilometre MAR March KMM Kilometre Per Hour MAS Manual AL simplex KPA Kilopascal MAX Maximum KT Knot MAY May KTS(*) Knots MCA Minimum crossing altitude KW Kilowatts MCA Minimum descent altitude M MDA Medium frequency direction-finding station L Left (runway identi		•		
J LVL Level JAN January LYR Layer or layeredM JTST Jet Stream M JUL July M JUN June M Metres (preceded by figures) K MAA Maximum authorised altitude K MAR Maximum authorised altitude K KIlogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilohertz MAPT Missed approach point KM Kilometres MAR At sea KMS(*) Kilometres MAR March KMM Kilometre Per Hour MAS Manual AL simplex KPA Kilopascal MAX Maximum KT Knot MAY May KTS(*) Knots MCA Minimum crossing altitude KW Kilowatts MCW Modulated continuous wave MDA Minimum descent altitude ME MDA Minimum descent altitude MDA Minimum descent height </td <td>ISOL</td> <td>Isolated</td> <td></td> <td></td>	ISOL	Isolated		
JAN January LYR Layer or layeredM JTST Jet Stream JUL July M JUN June MAG Maximum authorised altitude K MAG Magnetic KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilohertz MAPT Missed approach point KM Kilometre MAR At sea KMS(*) Kilometre MAR Maximum KMH Kilometre Per Hour MAS Manual AL simplex KFA Kilopascal MAY May KTS(*) Knots MCA Minimum crossing altitude L Left (runway identification) MDH Minimum descent altitude L Locator (see LM>LO) MEA Minimum eye height over threshold(for visual approach slope indicator systems) LAN Inland MET Meteorology LDA Landing distance available, helicopter MHDF Medium and high frequency direction-finding stat- METAR Aviation routine weather report (aeronautical meteorological code) MEDA Medium frequency (300 to 3000KHz) Lending distance available, helicopter MHDF Medium and high frequency direction-finding stat-				•
JTST Jet Stream JUL July M JUN June M Metres (preceded by figures) K MAA Maximum authorised altitude K MAG Magnetic KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeronautical maps and charts KHZ Kilometre MAP Missed approach point KMS(*) Kilometre Per Hour MAR At sea KMS(*) Kilometre Per Hour MAS Manual AL simplex KPA Kilopascal MAX Maximum KT Knot MAY May KTS(*) Knots MCA Minimum crossing altitude KW Kilowatts MCA Minimum descent altitude L Left (runway identification) MDA Medium frequency direction-finding station L Left (runway identification) MDA Minimum eye height over threshold(for visual approach slope indicator systems) LAM Inland MET Meteorological or Meteorology LAT Latitude MET <t< td=""><td></td><td></td><td></td><td></td></t<>				
JUL July M Metres (preceded by figures) JUN June MA Maximum authorised altitude K MAG Magnetic KG Kilogram MAINT Maintenance KGS(*) Kilograms MAP Aeroautical maps and charts KHZ Kilohertz MAP Missed approach point KM Kilometre MAR At sea KMS(*) Kilometre Per Hour MAS March KPA Kilopascal MAX Maximum KT Knot MAY May KTS(*) Knots MCA Minimum crossing altitude KW Kilowatts MCA Minimum descent altitude KW Kilowatts MCA Minimum descent altitude L Left (runway identification) MDH Minimum descent height L Locator (see LM>LO) MEA Minimum en-route altitude LAM Logical acknowledgement (message type designator) MEHT Minimum eye height over threshold(for visual approach slope indicator systems) LAN Inland MET Metocological		•	LYR	Layer or layeredM
JUNJuneMMetres (preceded by figures)KMAAMaximum authorised altitudeKKIogramMAINTMaintenanceKGS(*)KilogramsMAPAeronautical maps and chartsKHZKilohertzMAPTMissed approach pointKMKilometreMARAt seaKMS(*)Kilometre Per HourMARMarchKMHKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum descent heightLLocator (see LM>LO)MEAMinimum descent heightLAMLogical acknowledgement (message type designator)MEHTMinimum descent height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDAHLanding distance available, helicopterMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-				
KMAAMaximum authorised altitudeKGKilogramMAINTMagneticKGS(*)KilogramsMAPAeronautical maps and chartsKHZKilohertzMAPTMissed approach pointKMKilometreMARAt seaKMS(*)KilometresMARMarchKMHKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding stand	JUL	July	<u>M</u>	
KKilogramMAGMagneticKGS(*)KilogramsMAPAeronautical maps and chartsKHZKilohertzMAPTMissed approach pointKMKilometreMARAt seaKMS(*)KilometresMARMarchKMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotsMCAMinimum crossing altitudeKWKilowattsMCAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLeft (runway identification)MEAMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMetorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding stance	JUN	June	M	Metres (preceded by figures)
KGKilogramMAINTMaintenanceKGS(*)KilogramsMAPAeronautical maps and chartsKHZKilohertzMAPTMissed approach pointKMKilometreMARAt seaKMS(*)KilometresMARMarchKMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMedium frequency direction-finding stationLLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach proach slope indicator systems)LANInlandMETMetorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-			MAA	Maximum authorised altitude
KGS(*)KilogramsMAPAeronautical maps and chartsKHZKilohertzMAPTMissed approach pointKMKilometreMARAt seaKMS(*)KilometresMARMarchKMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMetorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-	<u>K</u>		MAG	Magnetic
KHZKilohertzMAPTMissed approach pointKMKilometreMARAt seaKMS(*)KilometresMARMarchKMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMetorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-	KG	Kilogram	MAINT	Maintenance
KMKilometreMARAt seaKMS(*)KilometresMARMarchKMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding stance	KGS(*)	Kilograms	MAP	Aeronautical maps and charts
KMS(*)KilometresMARMarchKMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding stance	KHZ	Kilohertz	MAPT	Missed approach point
KMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-	KM	Kilometre	MAR	At sea
KMHKilometre Per HourMASManual AL simplexKPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-	KMS(*)	Kilometres	MAR	March
KPAKilopascalMAXMaximumKTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-		Kilometre Per Hour		Manual AL simplex
KTKnotMAYMayKTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum descent heightLAMLogical acknowledgement (message type designator)MEHTMinimum en-route altitudeLAMInlandMEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-		Kilopascal		•
KTS(*)KnotsMCAMinimum crossing altitudeKWKilowattsMCWModulated continuous waveMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum descent heightLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-				
KWKilowattsMCWModulated continuous waveLMDAMinimum descent altitudeLLeft (runway identification)MDAMedium frequency direction-finding stationLLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-				•
LMDAMinimum descent altitudeLLeft (runway identification)MDHMedium frequency direction-finding stationLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-				_
LMDAMedium frequency direction-finding stationLLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-	IXVV	Miowatts		
LLeft (runway identification)MDHMinimum descent heightLLocator (see LM>LO)MEAMinimum en-route altitudeLAMLogical acknowledgement (message type designator)MEHTMinimum eye height over threshold(for visual approach slope indicator systems)LANInlandMETMeteorological or MeteorologyLATLatitudeMETARAviation routine weather report (aeronautical meteorological code)LDALanding distance availableMFMedium frequency (300 to 3000KHz)LDAHLanding distance available, helicopterMHDFMedium and high frequency direction-finding sta-				
Locator (see LM>LO) LAM Logical acknowledgement (message type designator) LAN Inland MET Meteorological or Meteorology LAT Latitude METAR Aviation routine weather report (aeronautical meteorological code) LDA Landing distance available LDAH Landing distance available, helicopter MEA Minimum en-route altitude MEHT Meteorological or Meteorology Aviation routine weather report (aeronautical meteorological code) MF Medium frequency (300 to 3000KHz) Medium and high frequency direction-finding sta-		Loft (rupus, identification)		
LAM Logical acknowledgement (message type designator) LAN Inland MET Meteorological or Meteorology LAT Latitude METAR Aviation routine weather report (aeronautical meteorological code) LDA Landing distance available MF Medium frequency (300 to 3000KHz) LDAH Landing distance available, helicopter MHDF Medium and high frequency direction-finding sta-		· · · · · · · · · · · · · · · · · · ·		•
nator) proach slope indicator systems) LAN Inland MET Meteorological or Meteorology LAT Latitude METAR Aviation routine weather report (aeronautical meteorological code) LDA Landing distance available MF Medium frequency (300 to 3000KHz) LDAH Landing distance available, helicopter MHDF Medium and high frequency direction-finding sta-				
LAT Latitude METAR Aviation routine weather report (aeronautical meteorological code) LDA Landing distance available MF Medium frequency (300 to 3000KHz) LDAH Landing distance available,helicopter MHDF Medium and high frequency direction-finding sta-		nator)		proach slope indicator systems)
teorological code) LDA Landing distance available MF Medium frequency (300 to 3000KHz) LDAH Landing distance available,helicopter MHDF Medium and high frequency direction-finding sta-				
LDAH Landing distance available,helicopter MHDF Medium and high frequency direction-finding sta-	LAT	Latitude	METAR	
	LDA	Landing distance available	MF	Medium frequency (300 to 3000KHz)
	LDAH	Landing distance available,helicopter	MHDF	

IMT

Immediate or immediately

LDG	Landing	MH VDF	Medium, high and very high frequency direction-finding station (at the same location)
LDI	Landing direction indication	MHZ	Megahertz
LEN	Length	MID	Mid-point (related to RVR)
LF	Low frequency (30 to 300KHz)	MIFG	Shallow fog
<u>M</u>		<u>N</u>	
MIL	Military	NEB	North- eastbound
MIN++	Minutes	NEG	No or negative or permission not granted or that is not correct
MKR	Maker radio beacon	NGT	Night
MLS++	Microwave landing system	NIL	None or I have nothing to send to you
MM	Middle maker	NM	Nautical miles
MNM	Minimum	NML	Normal
MNPS	Minimum navigation performance specifications	NNE	North north east
MNT	Monitor or monitoring or monitored	NNW	North north west
MNTN	maintain	NOF	International NOTAM office
MOA	Military operating area	NOSIG	No significant change (used in trend-type landing forecasts)
MOC	Minimum obstacle clearance (required)	NOTAM	A notice containing information concerning the establishment, condition or change in any aeronautical facility, service, procedure, or hazard, the timely knowledge of which is essential to personal concerned with flight operations
MOD	Moderate (used to indicate the intensity of weather phenomena, interference or static reports eg. MODRA = moderate rain)	NOV	November
MON	Above mountain	NR	Number
MON	Monday	NRH	No reply heard
MONTE	Meteorological operational Telecommunications Network Europe	NS	Nil significant Cloud
MOV	Move or moving or movement	NSW	Nil significant weather
MPS	Metres per second	NW	North- west
MRA	Minimum reception altitude	NWB	North-westbound
MRG	Medium range	NXT	Next
MRP	ATS /MET reporting points		
MS	Minus	<u>O</u>	
MSA	Minimum sector altitude	OAC	Oceanic area control centre
MSL	Mean sea level	OAS	Obstacle assessment surface
MT	Mountain	OBS	Observe or observed or observation
MTU	Metric units	OBSC	Obscure or Obscured or obscuring
MTW	Mountain waves	OCA	Obstacle Clearance Altitude
MVDF	Medium and very high frequency directing-finding stations (at the same location)	OCA	Obstacle Control Area
MWO	Meteorological watch office	OCC	Occasional or Occasionally
MX	Mixed type of ice formation (wide and clear)	OCT	October
		OHD	Overhead
<u>N</u>		OM	Outer marker
N	North or northern latitude	OPA	Opaque, white type of ice formation
N	No distinct tendency (in RVR during previous 10 minute	OPC	Open or opening or opened
NACL(*)	National Airports Corporation Limited	OPMET	Operational Meteorological (information)
NAV	Navigation	OPN	Open or opening or opened
NB	Northbound	ORR	Operated or operative operating or operations
NBFR	Not before	OPSNORM	Operations normal
NC	No change	O/R	On request
NDB++	Non directional radio beacon	ORD	Indication of an order
NE	North-east	OSV	Ocean station vessel

		OTLK	Out look (used in sigmet messages for volcanic ash and tropical cyclones)
<u>o</u>		Q	
OTP	on top	QFE++	Atmosphere pressure at aerodrome elevation (or at runway threshold)
OTS	Organised track system	QFU	Magnetic orientation or runway
OUBD	Out bound	QNH++	Altimeter sub-scale setting to obtain elevation when on the ground
OVC	Overcast	QTE	True bearing
		QUAD	Quadrant
<u>P</u>			
P	Prohibited area (followed identification)	<u>R</u>	
PALS	Precision approach lighting system(specify category)	R	Red
PANS	Procedures for air navigation services	R	Restricted area (followed by identification)
PAPI	Precision approach path indicator	R	Right (runway identification)
PAR++	Precision approach radar	RA	Rain
PARL	Parallel	RAC	Rules of the air and air traffic service
PAX	Passenger(s)	RAG	Ragged
PCD	Proceed or proceeding or proceeded	RAG	Runway arresting gear
PCN	Pavement classification number	RAI	Runway alignment indicator
PE	Ice pellets	RAIL	Runway alignment indicator lights
PER	Performance	RB	Rescue boat
PERM	Permanent	RCA	Reach cruising altitude
PJE	Parachute jumping exercise	RCC	Rescue co-ordination centre
PLA	Practice low approach	RCF	Radio communication failure (message type designator)
PLN	Flight plan	RCH	Reach or reaching
PLVL	Present level	RCL	Runway centre line
PN	Prior notice required	RCLL	Runway centre line light(s)
PNR	Point of no return	RCLR	Recleared
PO	Dust devils	RDH	Reference datum height (for ILS)
POB	Persons on board	RDL	Radial
POSS	Possible	RDO	Radio
PPI	Planning position indicator	RE	Recent (used to describe weather phenomena, e.g RERA= recent rain)
PPR	Prior permission required	REC	Received or receiver
PPSN	Present position	REDL	Runway edge light(s)
PRI	Primary	REF	Reference to or refer to
PRKG	Parking	REG	Registration
PROB	probability	REIL(*)	Runway end identifier light
PROC	Procedure	RENL	Runway end light(s)
PROV	Provisional	REP	Report or reporting or reporting point
PS	Plus	REQ	Request or requested
PSG	Passing	RERTE	Reroute
PSN	Position	RG	Range (lights)
PSP	Pierced steel plank	RIF	Reclearance in flight
PTN	Procedure turn	RITE	Right (direction or turn)
PWR	Power	RL	Report leaving
		RLA	Replay to
		RLCE	Request level change en-route
		RLLS	Runway lead-in lighting system
Q		RLNA	Request level not available
QBI	Compulsory IFR flight	RMK	Remark
QDM++	Magnetic heading (zero wind)	RNAV	(to be pronounced "AR-NAV") Area navigation
QDR	Magnetic bearing	RNG	Radio range

<u>R</u>		<u>s</u>	
RNP	Required navigation performance ROBEX Regional OPMET bulletin exchange (scheme)	SC	Stratocumulus
ROC	Rate of climb	SCT	Scattered
ROFOR	Route forecast (in aeronautical meteorological code)	SDBY	Stand by
RON	Receiving only	SE	South -east
RPL	Repetitive flight plan	SEB	South – eastbound
RPLC	Replace or replaced	SEC	Seconds
RPS	Radar position symbol	SECT	Sector
RQMNTS	Requirements	SELCAL	Selective calling system
RQP	Request flight plan (message type designator)	SEP	September
RQS	Request supplementary flight plan (message type designator)	SER	Service or servicing or served
RR	Report reaching	SEV	Severe (used e.g. to qualify icing and turbulence reports)
RRA	(or RRB, RRC etc, in sequence) Delayed meteorological message (message type designator)	SFC	Surface
RSC	Rescue sub-centre	SG	Snow grains
RSCD	Runway surface condition	SGL	Signal
RSP	Responder beacon	SH	Showers (followed by RA=rain, SN=snow, PE=ice pallets, GR=hail, GS=small hail and/or snow pallets or snow combinations thereof e.g.
RTD	Delayed (used to indicate delayed meteorological message; message type designator)	SHRASN	showers of rain and snow
RTE	Route	SHF	Super light frequency (3,000 to 30,000 MHz)
RTF	Radiotelephone	SID	Standard instrument departure
RTG	Radiotelegraph	SIF	Selective identification feature
RTHL	Runway threshold light(s)	SIGMET	Information concerning en-route weather phe- nomena which may affect the safety of aircraft operations.
RTN	Return or returned or returning	SIGWX	Significant weather
RTODAH	Rejected take-off distance available, helicopter	SIMUL	Simultaneous or simultaneously
RTS	Return to service	SIWL	Single isolated wheel load
RTT	Radio teletypewriter	SKC	Sky clear
RTZL	Runway touchdown zone light(s)	SKED	Schedule or scheduled
RUT	Standard regional route transmitting frequencies	SLP	Speed limiting point
RV	rescue vessel	SLW	Slow
RVR++	Runway visual range	SMC	Surface movement control
RWY	Runway	SMR	Surface movement radar
_		SN	Snow
<u>S</u>		SNOW- TAM	A special NOTAM notifying the presence or removal of hazardous conditions due to snow, ice, slush or standing water associated with snow slush and ice of the movement area, by means of a specific format.
S	South of southern latitude	SPECI	Aviation selected special weather report (in aeronautical Meteorological code)
SA	Sand	SPECIAL	Special meteorological report (in abbreviated plain language)
SALS	Simple approach lighting system	SPL	Supplementary flight plan (message type designator)
SAN	Sanitary	SPOT	Spot wind
SAP	As soon as possible	SQ	Squall
SAR	Search and rescue	SR	Sunrise
SARPS	Standards and Recommended Practices ICAO	SRA	Surveillance radar approach
SAT	Saturday	SRE	Surveillance radar element or precision approach radar system
SATCOM	Satellite communication	SRG	Short range

Search and rescue region

SRR

South bound

SB

<u>s</u>		Ţ	
SRY	Secondary	TEND	Trend forecast
SS	Sand storm	TFC	Traffic
SS	Sun set	TGL	Touch-and-go landing
SSB	Single side band	TGS	Taxiing guidance system
SSE	South south east	THR	Threshold
SSR++	Secondary Surveillance Radar	THU	Thursday
SST	Supersonic transport	TIL	Until
SSW	South south west	TIP	Until past (place)
STAR	Standard instrument arrival	TKOF	Take-off
STD	Standard	TL	Till (followed by time which weather change is forecast to end)
STF	Stratiform	TLOF	Touch-down and lift-off area
STN	station	TLX	Telex
STNR	Stationery	TMA++	Terminal control area
STOL	Short take-off and landing	TNA	Turn altitude
STS	Status	TOH	Turn height
STWL	Stopway light(s)	TO	TO (place)
Subject:	Subject to	TOC	Top of climb
SUN	Sunday	TODA	Take off distance available
SUP	Supplementary (AIP Supplement)	TODAH	Take off distance available, helicopter
SUPPS	Regional Supplementary procedures	TOP	Cloud top
SVC	Service message	TORA	Take-off run available
SVCBL	Serviceable	TP	Turning point
SVFR(*)	Special visual flight rules	TR	Track
SW	South – west	TRA	Temporal reserved air space
SWB	South-west bound	TRANS	Transmits or transmitter
SWY	Stop-way	TRL	Transition level
		TROP	Tropopause
I		TS	Thunderstorm(in aerodrome reports and fore- cast, TS used alone means thunder heard but no precipitation at the aerodrome)
Т	Temperature	TS	Thunderstorm (followed by RA = rain, SN=s- now, PE=ice pallets, GR=hail, GS=small hails and/or snow pallets or combinations there- of e.g.TRSASN= thunderstorms with rain and snow)
TA	Transition altitude	TT	Teletypewriter
TACAN	UHF Tactical air navigation aid	TUE	Tuesday
TAF	Aerodrome forecast	TURB	Turbulence
TAIL	Tail wind	TVOR	Terminal VOR
TAR	Terminal area surveillance radar	TWR	Aerodrome control tower or aerodrome control
TAS	True air speed	TWY	Taxiway
TAX	Taxiing or taxi	TWYZ	Taxiway-zone
TC	Tropical cyclone	TYP	Type of aircraft
TCU	Towering cumulus	TYPH	Typhoon
TDO	Tornado		
TDZ	Touch down zone	<u>U</u>	
TECR	Technical reason	U	Upward (tendency in RVR during previous 10 minutes)

UAB

UAC

Until advised by ...

Upper area control centre

<u>U</u>		W	
UAR	Upper air route	W	West or western longitude
UDF	Ultra high frequency direction-finding station	W	White
UFN	Until further notice	WAC	World aeronautical chart – ICAO 1:1,000,000
UHDT	Unable higher due traffic	WAFC	World area forecast centre
UHF++	ultra high frequency (300 to 3,000 MHz)	WB	West bound
UIC	upper information centre	WBAR	Wing bar lights
UIR++	Upper flight information region	WDI	Wind direction indicator
ULR	Ultra long range	WDSPR	Widespread
UNA	Unable	WED	Wednesday
UNAP	Unable to approve	WEF	With effect from or effective from
UNL	Unlimited	WI	Within
UNREL	Unreliable	WID	Width
U/S	Unserviceable	WIE	With immediate effect or effective immediately
UTA	Upper control area	WILCO	Will comply
UTC++	Co-ordinated universal time	WINTEM	Forecast upper wind and temperature for aviation
		WIP	Work in progress
<u>V</u>		WKN	Weaken or weakening
VA	Volcanic ash	WNW	West north west
VAC	Visual approach chart	WO	Without
VAL	In valleys	WPT	Way-point
VAN	Runway control van	WRNG	Warning
VAR	Magnetic variation	WS	Wind shear
VAR	Visual-aural radio range	WSW	West south west
VASIS	Visual approach slope indicator system	WT	Weight
VC	Vicinity of the aerodrome (followed by FG = fog, FC=funnel cloud, SH=showers, PO=dust and sand whirls, BLDU=blowing dust, BLSA=blowing sand or BLSN=blowing snow, e.g. VCFG=vicinity fog)	WTSPT	Water Spout
VCY	Vicinity	WX	Weather
VDF	Very high frequency direction- finding station		
VER	Vertical	<u>X</u>	
VFR	Visual flight rules	Χ	Cross
VHF++	Very high frequency (30 to 300 MHz)	XBAR	Crossbar (of approach lighting system)
VIP++	Very important person	XNG	Crossing
VIS	Visibility	XS	Atmospherics
VLF	Very low frequency (3 to 30 KHz)		
VLR	Very long range	<u>Y</u>	
VMC++	Visual meteorological condition	Υ	Yellow
VORMET	Meteorological information for aircraft in flight	YCZ	Yellow caution zone (runway)
VOR++	VHF omnidirectional radio range	YR	Your
VORTAC	VOR and TACAN combination		
VOT	VOR airborne equipment test facility	<u>Z</u>	
VRB	Variable	Z	Co-ordinated universal time
VSA	By visual reference to the ground		
VSP	Vertical speed		
VTOL	Vertical take-off and landing		

Telephone

Temporary or temporal

TEL TEMPO

THIS PAGE INTENTIONALLY LEFT BLANK