
Ticker Plus FAQ

Tracker Plus · your desk clock with news and weather

In one line: a big clock with the weather, today's exchange rates and news headlines, all in one screen.



Ticker Plus



The MENU

What am I looking at?

The time and date, the weather for your town, a strip of exchange rates across the top, and news headlines scrolling along the bottom. There is also **On this day**, the moon phase, sunrise and sunset, weather warnings and air quality.

How do I change Celsius and Fahrenheit?

Tap **MENU** in the top right corner, then **Units**. It switches between C and F.

Why is the weather for the wrong place?

Settings > Location, and type your town.

How do I see the weather radar?

Tap the weather card on the main screen. Radar pictures are from Environment Canada.

What is the night clock?

After a minute with no touching, at night, the screen shows a dim clock so it does not light up the room. Tap to wake it. In the MENU, **Night: ON/OFF** turns this feature on or off.



The night clock

Do I get weather warnings?

Yes for Canada (Environment Canada) and the United States (the National Weather Service). A warning shows on the main screen. Air quality is shown for Canada.

Which exchange rates are these?

The strip across the top uses the Bank of Canada's daily rates.

How do I refresh everything?

MENU > **Refresh everything now**.

Where does the data come from?

Free public services: MET Norway (weather), Environment Canada, the US National Weather Service, the Bank of Canada and Wikipedia (news). Nothing to pay.

Need more help?

Open the full Tracker Plus guide from Settings > Help & info (scan the QR code), or contact the seller and tell them the version in Settings > Help & info.