World Events FAQ

Tracker Plus · big events as they happen

In one line: big earthquakes, tsunami messages, disasters and world news, with a pop-up alert when something major happens.



Quakes



Disasters

What pages are there?

Four tabs along the bottom: **Quakes** (magnitude 7 and up), **Tsunami** messages, **Disasters** (storms, floods, eruptions, droughts) and **World news**.

How do I read more?


Tap any item. You see the details, and a QR code. Scan the QR code with your phone to read the whole story.

What are the alerts?

A card with a sound pops up for a new big quake, a tsunami warning, or a new red disaster alert. Tap it to close it. Each alert only shows once.



Tap an item for more



An alert card

Does it move by itself?

If you do not touch it for a minute, it steps through the pages by itself (about 10 seconds each).

How often does it check?

Quakes and tsunami messages every few minutes, the rest less often. MENU > **Update now** checks straight away.

It says Loading.


If a download fails it tries again later. MENU > Update now tries straight away.

Where does it come from?

Free public sources: USGS (quakes), tsunami.gov, GDACS (disasters) and Wikipedia (in the news). Nothing to pay.



World news



Tsunami messages

Need more help?

Open the full Tracker Plus guide from Settings > Help & info (scan the QR code), or contact the seller and tell them the version in Settings > Help & info.