

SOCCER TRACKER

Frequently asked questions · up to 12 of your teams, live, from leagues and cups worldwide

What it is

Soccer Tracker is a small desk screen that follows up to 12 of your soccer teams, live, from leagues and cups around the world. It only needs Wi-Fi - no app, no account, no phone.

First start

Plug it into any USB power and follow the screen. It takes about 2 minutes.

1. Touch calibration - press each of the 3 dots, then lift your finger.

2. Wi-Fi - tap SCAN, pick your network, type the password, tap OK.

3. Pick your teams - tap a league, then tap up to 12 teams (tap again to remove). Tap BACK when done. That's it. It remembers everything, even after unplugging.

What you'll see

The screens rotate on their own. When one of your teams is playing, the live match stays on screen until it ends.

Screen	Shows
Live	Match minute, score, scorers, cards, shots and possession. Flashes GOAL! and RED CARD
Next match	Countdown to kick-off, recent form, stadium, last result
Full-time	Final score, who scored, and your team's new league position
Table	League table around your team, in team colours
Around the world	Today's scores from other leagues

The strip along the bottom scrolls goals, cards and upcoming matches.

Using it

Tap the screen to jump to the next screen.

Tap SET (top right) for settings: **My teams** - add or remove teams; **Wi-Fi** - change network; **Time zone** - tap to cycle through them; **Touch cal** - redo the touch calibration; **Demo** - shows every screen with sample matches; **Done** - back to the scores.

If something's off

Why does it take a while to show data? Please be patient.

Every time it starts, or when you leave the SET menu, it downloads fresh matches, tables and team logos from the internet. It can take a few seconds, and up to a couple of minutes the first time, before every screen is filled in. That's normal - it isn't stuck.

Problem	Fix
Taps land on the wrong key	SET > Touch cal, or hold the Wi-Fi screen for 3 seconds
Wrong clock time	SET > Time zone
Red dot next to the clock	Wi-Fi dropped - it reconnects by itself
Grey circles instead of logos	Logos download over the first few minutes
"Loading matches" for a long time	Check Wi-Fi, then unplug and plug back in

Scores come from ESPN. Soccer Tracker is not affiliated with any league or club.