

实验五、路由器广域网 HDLC 封装配置

一、实验目的

- 1. 掌握广域网 HDLC 封装配置
- 2. 理解 DCE、DTE
- 3. 理解封装匹配

二、应用环境

- 1. 企业环境中异地的互连通常要经过第三方的网络,比如网通、电信等等,所以与局域网 的配置不同
- 2. 广域网通常需要付费、带宽比较有限、可靠性相比局域网要低

三、实验设备

1. DCR-1751 两台

2. CR-V35MT 一条

3. CR-V35FC 一条

四、实验拓扑



五、实验要求

 Router-A
 Router-B

 接口
 IP 地址

 S1/1 DCE
 192.168.1.1

 S1/0 DTE
 192.168.1.2

六、实验步骤

第一步 Router-A 的配置

Router>**enable**Router #**config**

Router _config#hostname Router-A

!进入特权模式

! 进入全局配置模式

!修改机器名



Router-A_config#interface s1/1

Router-A config s1/0#ip address 192.168.1.1 255.255.255.0

Router-A_config_s1/1#encapsulation hdlc

Router-A_config_s1/0#physical-layer speed 64000

Router-A_config_s1/0#no shutdown

Router-A_config_s1/0#^Z

! 进入接口模式

! 配置 IP 地址

! 封装 HDLC 协议

! 配置 DCE 时钟频率

! 按 ctrl + z 进入特权模式

第二步: 查看配置

Router-A#show interface s1/1

Serial 1/0 is up, line protocol is down

! 查看接口状态

! 对端没有配置,所以协议是 DOWN ! 查看 DCE

Mode=Sync **DCE** Speed=64000

DTR=UP,DSR=UP,RTS=UP,CTS=DOWN,DCD=UP

Interface address is 192.168.1.1/24

! 杳看 IP 地址

MTU 1500 bytes, BW 64 kbit, DLY 2000 usec

Encapsulation prototol **HDLC**, link check interval is 10 sec

! 查看封装协议

! 封装 HDLC 协议

Octets Received0, Octets Sent 0

Frames Received 0, Frames Sent 0, Link-check Frames Received0

Link-check Frames Sent 89, LoopBack times 0

Frames Discarded 0, Unknown Protocols Frames Received 0, Sent failuile 0

Link-check Timeout 0, Queue Error 0, Link Error 0,

60 second input rate 0 bits/sec, 0 packets/sec!

60 second output rate 0 bits/sec, 0 packets/sec!

0 packets input, 0 bytes, 8 unused rx, 0 no buffer

0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort

8 packets output, 192 bytes, 0 unused_tx, 0 underruns

error:

0 clock, 0 grace

PowerQUICC SCC specific errors:

0 recy allocb mblk fail 0 recv no buffer

0 transmitter queue full 0 transmitter hwqueue full

第三步: Router-B 的配置

Router>enable ! 进入特权模式

! 进入全局配置模式 Router #config

! 修改机器名 Router config#hostname Router-B

Router-B_config#interface s1/0 ! 进入接口模式

Router-B_config_s1/0#ip address 192.168.1.2 255.255.255.0 ! 配置 IP 地址

Router-B_config_s1/1#encapsulation hdlc

Router-B_config_s1/0#no shutdown

! 按 ctrl + z 进入特权模式 Router-B_config_s1/0#^Z

第四步: 查看配置

! 查看接口状态 Router-A#show interface s1/0

! 接口和协议都是 up Serial 1/0 is up, line protocol is up



Mode=Sync DTE ! 查看 DTE

DTR=UP,DSR=UP,RTS=UP,CTS=DOWN,DCD=UP

Interface address is 192.168.1.2/24 ! 查看 IP 地址

MTU 1500 bytes, BW 64 kbit, DLY 2000 usec

Encapsulation prototol **HDLC**, link check interval is 10 sec ! 查看封装协议

Octets Received0, Octets Sent 0

Frames Received 0, Frames Sent 0, Link-check Frames Received0

Link-check Frames Sent 89, LoopBack times 0

Frames Discarded 0, Unknown Protocols Frames Received 0, Sent failuile 0

Link-check Timeout 0, Queue Error 0, Link Error 0,

60 second input rate 0 bits/sec, 0 packets/sec!

60 second output rate 0 bits/sec, 0 packets/sec!

0 packets input, 0 bytes, 8 unused_rx, 0 no buffer

0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort

8 packets output, 192 bytes, 0 unused_tx, 0 underruns

error:

0 clock, 0 grace

PowerQUICC SCC specific errors:

0 recv allocb mblk fail 0 recv no buffer

0 transmitter queue full 0 transmitter hwqueue_full

第五步:测试连通性

Router-A#ping 192.168.1.2

PING 192.168.1.2 (192.168.1.2): 56 data bytes

!!!!!

--- 192.168.1.2 ping statistics ---

5 packets transmitted, 5 packets received, 0% packet loss round-trip min/avg/max = 20/22/30 ms

七、注意事项和排错

- 1. 注意查看接口状态,接口和协议都必须是 UP
- 2. CR-V35FC 所连的接口为 DCE, CR-V35MT 所连的接口为 DTE
- 3. 协议是 DOWN,通常是封装不匹配、DCE 时钟没有配置
- 4. 接口是 DOWN,通常是线缆故障
- 5. 在实际工作中, DCE 设备通常由服务提供商配置, 本实验是模拟环境

八、配置序列

路由器A的序列

Router-A#show running-config

Building configuration...





```
Current configuration:
!version 1.3.2E
service timestamps log date
service timestamps debug date
no service password-encryption
hostname Router-A
                                                             ! 查看机器名
interface FastEthernet0/0
 ip address 192.168.2.1 255.255.255.0
                                                             ! 查看 IP 地址
 no ip directed-broadcast
< 省略....>
interface Serial1/1
                                                             ! 查看 IP 地址
 ip address 192.168.1.1 255.255.255.0
 no ip directed-broadcast
 physical-layer speed 64000
interface Async0/0
 no ip address
 no ip directed-broadcast
```

九、共同思考

- 1. 如果没有指明封装协议,默认的是什么协议?
- 2. 为什么要配置 DCE 的时钟频率?

十、课后练习

请将A的封装改为PPP,观察PING的结果

十一、相关命令详解

encapsulation

使用 encapsulation 接口配置命令设置接口使用的封装协议。使用这个命令的 **no** 形式恢复缺省封装

encapsulation encapsulation-type



参数

参数	参数说明
encapsulation-type	封装类型,为下面的关键字之一:
	frame-relay—帧中继(用于串行接口);
	hdlc一串行接口的HDLC协议,它提供HDLC的同步帧和检错功能而无窗口或
	重传机制;
	ppp-PPP (用于串行接口);
	slip-SLIP(用于串行接口);
	x25-X.25 (用于串行接口);
	sdlc一串行接口的SDLC协议;

缺省

缺省值与接口的类型有关。例如,同步串行接口缺省为 HDLC, 异步接口和拨号接口缺省为 PPP。

命令模式

接口配置态

使用说明

若想同时支持多个封装,可以使用 autoselect 命令。此命令设置接口的主要封装协议。可以 使用 show interface 命令显示接口的主要封装。目前此命令只在串行接口有效。

示例

下面的例子设置串行接口 1/1 上的帧中继封装:

interface serial 1/1

encapsulation framerelay

下面的例子恢复串行接口 1/0 上的缺省封装:

interface serial 1/0

no encapsulation