

Printer Cleaning Guide

GEN2™, GEN2 Universal™, and GEN3 Evolution® Printers



GEN2: PSA-66-ST2R (RS232); PSA-66-ST2N (Netplex)

GEN2 Universal: PSA-66-ST2RU (RS232/USB); PSA-66-ST2NU (Netplex/USB)

GEN3 Evolution: PSA-66-ST3

Printer Cleaning Guide

GEN2™, GEN2 Universal™, and GEN3 Evolution® Printers

ã 2010 - 2012 FutureLogic, Incorporated. All Rights Reserved.

GEN2, GEN2 Universal, GEN3, Evolution, and FutureLogic are either trademarks or registered trademarks of FutureLogic, Incorporated in the United States and/or other countries. Additional trademarks and intellectual property rights are listed on www.futurelogic-inc.com. All other trademarks and products or brand names mentioned herein are the property of their respective owners.

This document contains Proprietary and Confidential information and its contents are covered by Non-Disclosure Agreement.

This manual, as well as any software described in it, is furnished under license and may be used or copied only in accordance with the terms of such license. The content of this manual including technical information is disclosed and furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by FutureLogic, Incorporated. FutureLogic, Incorporated assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual and/or software. No grant of license or use rights of any such information is made by publication or distribution of this manual.

Except as permitted by such license, no part of this manual may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, recording, or otherwise, without the prior written permission of FutureLogic, Incorporated.

The information in this manual and/or software described is distributed on an "As Is" basis, without warranty. While every precaution has been taken in the preparation of this book and/or software, FutureLogic, Incorporated shall not have any liability to any person or entity with respect to any loss or damage caused or alleged to be caused directly or indirectly by the instructions and/or information contained in this manual or by the computer software and/or hardware products described in it.

FUTURELOGIC, INCORPORATED ("FUTURELOGIC") MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THE FUTURELOGIC SOFTWARE. FUTURELOGIC DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE FUTURELOGIC SOFTWARE IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY, CURRENTNESS, OR OTHERWISE. THE ENTIRE RISK AS TO THE RESULTS AND PERFORMANCE OF THE FUTURELOGIC SOFTWARE IS ASSUMED BY YOU. THE EXCLUSION OF IMPLIED WARRANTIES IS NOT PERMITTED BY SOME STATES. THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

IN NO EVENT WILL FUTURELOGIC, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES (INCLUDING DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, AND THE LIKE) ARISING OUT OF THE USE OR INABILITY TO USE THE FUTURELOGIC SOFTWARE EVEN IF FUTURELOGIC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

These specifications are subject to change without notice and may not completely and correctly document the operation of this product.

11/14/2012 MNL-000054 REV.D ((

The products described in this manual is in compliance with all applied CE standards.

The GEN2 Netplex printer (PSA-66-ST2N) and the GEN2 Universal Netplex printer (PSA-66-ST2NU) are in compliance with the Netplex protocol of IGT.

FutureLogic, Inc. 425 East Colorado St., Suite 100 Glendale, CA 91205 USA

Phone 818.244.4700 Fax 818.244.4764 FutureLogic Europe, Ltd Unit 6, Cordwallis Industrial Estate, Clivemont Road Maidenhead SL6 7BU United Kingdom Tel. +44 (0) 1628 760 080

Tel. +44 (0) 1628 760 080 Fax. +44 (0) 1628 760 089

www.futurelogic-inc.com • info@futurelogic-inc.com



Table of Contents

1	Guide Overview	
_	Introduction	
	Intended Audience	
	Applicability	
	Conventions Used in this Document	
2	Printer Cleaning	2
_	Introduction	
	Cleaning and Maintenance Do's and Don'ts	
	Required Cleaning Supplies	
	GEN2 Universal / GEN2 Printer – Reference Points for Procedures	3
	GEN3 Evolution Printer – Reference Points for Procedures	3
	Cleaning Card Method	4
	Manual Cleaning Method	6
	Sensor Cleaning (Ticket Taken, Paper Low, Lid Open)	



1 Guide Overview

Introduction

This Guide provides the procedures and instructions for cleaning FutureLogic printers as identified in the Applicability section.

Intended Audience

The intended audience for this Guide: Operators and Technicians.

Applicability

This Guide covers the GEN2™, GEN2 Universal™, and GEN3 Evolution® Printers.

Conventions Used in this Document

This document uses the following conventions:

Example	Description
	This is a note. A note includes information that emphasizes or supplements important points of the topic.
111111111111111111111111111111111111111	This is a tip. A tip provides techniques and procedures to aid with a task.
1	This is a caution/warning. A caution/warning emphasizes information that may cause damage to equipment and/or injury to a person.
Bold text	This document uses bold text to clearly identify a field, a tab, a command selection, and an option selection. For example, click the Site name.
Button	This document uses button style to clearly identify a button to click. For example, click OK .



2 Printer Cleaning

Introduction

This chapter covers cleaning the printer. Most illustrations show a GEN2 Universal printer. Wherever there is a difference for the GEN3 Evolution printer, additional illustrations are shown.

Cleaning and Maintenance Do's and Don'ts

Media Storage	Do Not store spare media (tickets) stacks inside the game. Ambient heat within the game may cause stored tickets to experience print quality and/or paper jam issues over time.
Cleaning Tools	Do Not use sharp or abrasive objects when cleaning the Print Head, Platen Roller, Pinch and Presenter Rollers.
Cleaning Materials	Do Not use non-approved cleaners or detergents.
Cleaning Card	Do Not use the Cleaning Card more than once.
Cleaning Swab	Do Not use the Cleaning Swab more than once.
Cleaning Wipe	Do Not use the Cleaning Wipe more than once.
Cleaning Frequency	Do use the Cleaning Card method every 3 months. (See page 4.)
	Do perform the manual cleaning method generally two (2) times per year or as required depending upon game and media conditions. (See <i>page 6</i> .)
Cleaning Material	Do use FutureLogic approved Cleaning Cards, Cleaning Wipes, and Cleaning Swabs.

Required Cleaning Supplies

The Printer Cleaning Kit (P/N 350-00292-100) contains 10 each of Cleaning Swab, Cleaning Wipe, and Cleaning Card.








Use the Cleaning Swabs and Cleaning Wipes with the Manual Cleaning Method. (See *page 6*.) Additionally, have on hand if needed:


- · Isopropyl Alcohol (I.P.A.) 99% or greater
- · Compressed Air to blow out dust from the print mechanism and sensors



GEN2 Universal / GEN2 Printer – Reference Points for Procedures



GEN3 Evolution Printer – Reference Points for Procedures






Printer Cleaning Guide (GEN2™, GEN2 Universal™, and GEN3 Evolution® Printers)

Cleaning Card Method

Use these procedures to quickly clean the Paper Path and Sensors. Perform these steps every three (3) months or as necessary.





Note: Steps 1 and 2 apply only if the printer is in a game.


- 1. Slide the printer out.
- 2. Remove any loaded tickets from the printer.



Power Source (if not in game)

3. Confirm that the printer has power.







Note: This custom Cleaning Card is made for the printer sensors and for feeding through the Paper Path.



5. Insert the Cleaning Card into the Paper Loading Slot.



Printer Cleaning Guide (GEN2™, GEN2 Universal™, and GEN3 Evolution® Printers)



The printer will feed the Cleaning Card to the loading point.



6. Press the **FEED** button on the Keypad to feed the Cleaning Card through the Paper Path.



The Cleaning Card advances to this position.

7. Remove the Cleaning Card.




Tip: Flip over the Cleaning Card and feed through the printer for a second cleaning cycle.





Manual Cleaning Method


Use these procedures for manually cleaning the Paper Path. Perform these steps every six (6) months or as necessary.





Note: Steps 1 and 2 apply only if the printer is in a game.

- 1. Slide the printer out.
- 2. Remove any loaded tickets from the printer.



3. Use compressed air to blow out any excessive dust and dirt in the presenter compartment, including the Presenter Rollers and Ticket Taken Sensor, etc.



4. Position the compressed air nozzle within the Paper Loading Slot to blow out any excessive dust and dirt from the Paper Out (Black Index Mark) Sensor (not visible).



The position of the compressed air nozzle is approximately 1 inch from the right side of printer.



Cleaning Swab Main Release Lever Print Head Print-line





Push back into close position

Presenter Rollers



Printer Cleaning Guide (GEN2™, GEN2 Universal™, and GEN3 Evolution® Printers)

5. Pull open the Main Release Lever before cleaning the Print Head and Platen Rollers.




WARNING!! Use care when cleaning the Print Head print-line.

- 6. Use the Cleaning Swab to clean across the Print Head print-line). Use this same Cleaning Swab to clean the sensors (see *page 8*). If a Cleaning Swab is not available, use a clean Cleaning Wipe to avoid placing dirt and contaminants on the Print Head.
- 7. Use the Cleaning Wipe to wipe and clean the Platen Roller.
- 8. Rotate the Platen Roller.
- 9. Repeat steps 7 and 8 until the entire roller is clean.
- 10. Push the Main Release Lever back to the Close position.
- 11. Use the Cleaning Wipe to wipe and clean the Presenter Rollers.
- 12. Rotate the Presenter Rollers.
- 13. Repeat steps 11 and 12 until both rollers are clean.
- 14. Use the Cleaning Wipe to wipe and clean the Upper Pinch Roller.
- 15. Clean the sensors. See page 8.




Sensor Cleaning (Ticket Taken, Paper Low, Lid Open)

Use these procedures to clean the sensors. Perform these steps every six (6) months or as necessary.




GEN2 Universal / GEN2Ticket Taken Sensor



GEN3 Evolution Ticket Taken Sensor

1. Use the Cleaning Swab to wipe across the surface of the Ticket Taken Sensor.



GEN2 Universal New Style Paper Low Sensor





GEN3 EvolutionPaper Low Sensor

2. (New style Paper Low Sensor) Use the Cleaning Swab to clean the upper and lower portions.



Printer Cleaning Guide (GEN2™, GEN2 Universal™, and GEN3 Evolution® Printers)








GEN2 Universal / GEN2

3. Clean the Printer Open Sensor.




GEN3 Evolution



Tip: If the Cleaning Swab is not available, use the Cleaning Wipe. Fold the Cleaning Wipe to fit; then clean all the required sensor surfaces: Ticket Taken Sensor, Printer Open Sensor, Paper Low Sensor (not shown), etc.







425 East Colorado St., Suite 100

Glendale, CA 91205

USA

Phone 818.244.4700

Fax 818.244.4764

FutureLogic Europe, Ltd

Unit 6, Cordwallis Industrial Estate, Clivemont Road

Maidenhead SL6 7BU

United Kingdom

Tel. +44 (0) 1628 760 080

Fax. +44 (0) 1628 760 089

www.futurelogic-inc.com • info@futurelogic-inc.com