

Part Number: PT990 -34220

**Kit Contents**

Item #	Quantity Reqd.	Description
1	1	Accessory Weight Rating Label
2		
3		

**Vehicle Service Parts** (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

**Hardware Bag Contents**

Item #	Quantity Reqd.	Description
1		
2		
3		

**Additional Items Required For Installation**

Item #	Quantity Reqd.	Description
1		
2		
3		

**Conflicts**

None
------

**Recommended Tools**

Personal & Vehicle Protection	Notes
Special Tools	Notes
Installation Tools	Notes
Special Chemicals	Notes
VDC Approved Glass Cleaner	

**General Applicability**

All Toyota models sold in the US.
-----------------------------------

**Recommended Sequence of Application**

Item #	Accessory
1	
2	
3	

\*Mandatory

**Legend**

 <b>STOP:</b> Damage to the vehicle may occur. Do not proceed until process has been complied with.
 <b>OPERATOR SAFETY:</b> Use caution to avoid risk of injury.
 <b>CAUTION:</b> A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.
 <b>TOOLS &amp; EQUIPMENT:</b> Used in Figures calls out the specific tools and equipment recommended for this process.
 <b>REVISION MARK:</b> This mark highlights a change in installation with respect to previous issue.
 <b>SAFETY TORQUE:</b> This mark indicates that torque is related to safety.
 <b>REGULATORY MARK:</b> This mark indicates the component is related to regulatory compliance

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.



Fig. 1-1

## 1. Locate the Tire Placard

- (a) The Tire Placard is located on the B-Pillar, inside the driver's front door. (Fig. 1-1)
- (b) Using a VDC approved cleaner, clean the areas around the tire placard where the Load Capacity Reduction Label (Accessory Weight Rating AWR Label) will be applied.



Fig. 2-1

## 2. Apply Load Capacity Reduction Label (Accessory Weight Rating AWR Label)

- (a) Affix the yellow Load Capacity Reduction Label to the driver-side B-pillar, within 25mm (1 inch) of the original tire placard. (Fig 2-1)

Note: Label should be placed on a flat surface if possible. Some panel shape is acceptable. (Fig 2-2, 2-3)




Fig. 2-3

**TOYOTA            All Vehicle Models            2020 -            Accessory Weight Rating Label**Checklist - these points **MUST** be checked to ensure a quality installation.

Check:	Look For:
<u>Accessory Function Checks</u>  <input type="checkbox"/> Verify yellow Load Capacity Reduction Label is securely affixed onto vehicle.  <input type="checkbox"/> Verify legibility and orientation  <input type="checkbox"/> Verify contents of label	No bubbling, warping, cosmetic damages to the yellow Load Capacity Reduction Label  Ensure the text is legible (free of streaks, smears or fading) and upright  Ensure there is a VIN and weight value printed
<u>Vehicle Function Checks</u>  <input type="checkbox"/>	
<u>Vehicle Appearance Check</u>  <input type="checkbox"/> After accessory installation and removal of protective cover(s), perform a visual inspection.	Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMNA Accessory Quality Shipping Standard.)
 <input type="checkbox"/> Yellow Load Capacity Reduction Label Placement	Ensure that the yellow Load Capacity Reduction Label is within 25mm (1 inch) of the Tire Placard.