===== 4/4/26 Osiris 0.3.7 wali_tour test ====

```
ubuntu@TB5WaLI:~/TB5-WaLI/wali_ws$ pip3 install --upgrade osiris-agent --break-system-packages
Defaulting to user installation because normal site-packages is not writeable
Requirement already satisfied: osiris-agent in /home/ubuntu/.local/lib/python3.12/site-packages (0.3.6)
Collecting osiris-agent
  Downloading osiris_agent-0.3.7-py3-none-any.whl.metadata (3.2 kB)
Requirement already satisfied: websockets in /home/ubuntu/.local/lib/python3.12/site-packages (from osiris-agent) (16.0)
Requirement already satisfied: psutil in /usr/lib/python3/dist-packages (from osiris-agent) (5.9.8)
Requirement already satisfied: pyzmq in /home/ubuntu/.local/lib/python3.12/site-packages (from osiris-agent) (27.1.0)
Downloading osiris_agent-0.3.7-py3-none-any.whl (30 kB)
Installing collected packages: osiris-agent
  Attempting uninstall: osiris-agent
    Found existing installation: osiris_agent 0.3.6
    Uninstalling osiris_agent-0.3.6:
      Successfully uninstalled osiris_agent-0.3.6
Successfully installed osiris-agent-0.3.7
```

Undock, drive ready at 0.73 battery 5% steady state (7.5% square top "peaks") with loc and osiris running (was 10% before),
With Nav2 running CPU 37.5%

Summary:
- End of tour Battery at 0.60)
- skipped waypoints 2, 7, 8 of 1-10
- wp 1 3.45, 3.95
- wp 2 skipped
- wp 3 2.54, -1.35 36s 6 recoveries
- wp 4 0.83, -0.6 25s
- wp 5 -2.65, -0.675 25s
- wp 6 3.97, 1.21 33s
- wp 7 skipped
- wp 8 skipped
- wp 9 1.9, 4.13 28s
- wp 10 -0.059, -0.423 32s

wali_tour console:

```
ubuntu@TB5WaLI:~/TB5-WaLI/wali_ws$ cmds/nav_wali_tour.sh
'** nav wali tour.sh executing **' added to life.log
ros2 run wali wali tour
 11:16:52 up 22:23,  5 users,  load average: 6.87, 4.24, 2.01
[INFO] [1775315814.602031813] [basic_navigator]: Begin Tour: front_door, couch_view, laundry, table, dining, kitchen, patio_view, office, hall_view, ready
[INFO] [1775315815.610154076] [basic_navigator]: 'FollowWaypoints' action server not available, waiting...
[INFO] [1775315816.367009002] [basic_navigator]: Following 10 goals....
[INFO] [1775316120.808470699] [basic_navigator]: Done Wali Tour
 11:22:01 up 22:28,  5 users,  load average: 9.88, 6.58, 3.60
ubuntu@TB5WaLI:~/TB5-WaLI/wali_ws$
```

Osiris console:

```
ubuntu@TB5WaLI:~/TB5-WaLI/wali_ws$ osiris_node

[INFO] [1775315080.341278477] [osiris_node]: Connecting to gateway...
[INFO] [1775315080.351828342] [osiris_node]: 🚀 Osiris agent v0.3.7 — graph_interval=2.0s, topic_batch=10
[INFO] [1775315082.328889862] [osiris_node]: controller_manager_msgs not found — ros2_control panels disabled
[INFO] [1775315082.712844536] [osiris_node]: Connected and authenticated to gateway
[INFO] [1775315082.723984069] [osiris_node]: Sent initial_state: 26 nodes, 121 topics, 18 actions, 228 services
[INFO] [1775315118.269666241] [osiris_node]: Subscribed to /battery_state
[INFO] [1775315125.540277454] [osiris_node]: Subscribed to /dock_status
[INFO] [1775315210.734495647] [osiris_node]: Subscribed to /amcl_pose
```

Localization Console:

```
ubuntu@TB5WaLI:~/TB5-WaLI/wali_ws$ cmds/launch localization.sh
'** launch localization.sh executing **' added to life.log
Launch TB4 Navigation Localization (On map from TB4 Async SLAM with default params)
ros2 launch turtlebot4_navigation localization.launch.py map:=/home/ubuntu/TB5-WaLI/wali_ws/maps/tb4_nav_async_w_chrony.map.yaml
[INFO] [launch]: All log files can be found below /home/ubuntu/.ros/log/2026-04-04-11-06-05-607378-TB5WaLI-85947
[INFO] [launch]: Default logging verbosity is set to INFO
[INFO] [map_server-1]: process started with pid [85950]
[INFO] [amcl-2]: process started with pid [85951]
[INFO] [lifecycle_manager-3]: process started with pid [85952]
[amcl-2] [INFO] [1775315165.880083709] [amcl]:
[amcl-2]    amcl lifecycle node launched.
[amcl-2]    Waiting on external lifecycle transitions to activate
[amcl-2]    See https://design.ros2.org/articles/node_lifecycle.html for more information.
[amcl-2] [INFO] [1775315165.884204499] [amcl]: Creating
[lifecycle_manager-3] [INFO] [1775315165.889630515] [lifecycle_manager_localization]: Creating
[lifecycle_manager-3] [INFO] [1775315165.898190911] [lifecycle_manager_localization]: Creating and initializing lifecycle service clients
[map_server-1] [INFO] [1775315165.923491653] [map_server]:
[map_server-1]  map_server lifecycle node launched.
[map_server-1]  Waiting on external lifecycle transitions to activate
[map_server-1]  See https://design.ros2.org/articles/node_lifecycle.html for more information.
[map_server-1] [INFO] [1775315165.923657598] [map_server]: Creating
[lifecycle_manager-3] [INFO] [1775315166.956389952] [lifecycle_manager_localization]: Starting managed nodes bringup...
[lifecycle_manager-3] [INFO] [1775315166.956473952] [lifecycle_manager_localization]: Configuring map_server
[map_server-1] [INFO] [1775315166.960413760] [map_server]: Configuring
[map_server-1] [INFO] [1775315166.960521982] [map_io]: Loading yaml file: /home/ubuntu/TB5-WaLI/wali_ws/maps/tb5wali_current.map.yaml
[map_server-1] [INFO] [1775315166.960968502] [map_io]: resolution: 0.05
[map_server-1] [INFO] [1775315166.960993002] [map_io]: origin[0]: -7.46
[map_server-1] [INFO] [1775315166.960999947] [map_io]: origin[1]: -2.83
[map_server-1] [INFO] [1775315166.961005058] [map_io]: origin[2]: 0
[map_server-1] [INFO] [1775315166.961146836] [map_io]: free_thresh: 0.25
[map_server-1] [INFO] [1775315166.961154632] [map_io]: occupied_thresh: 0.65
[map_server-1] [INFO] [1775315166.961165095] [map_io]: mode: trinary
[map_server-1] [INFO] [1775315166.961172392] [map_io]: negate: 0
[map_server-1] [INFO] [1775315166.961549541] [map_io]: Loading image file: /home/ubuntu/TB5-WaLI/wali_ws/maps/tb5wali_current.map.pgm
[map_server-1] [INFO] [1775315166.969551935] [map_io]: Read map /home/ubuntu/TB5-WaLI/wali_ws/maps/tb5wali_current.map.pgm: 343 X 232 map @ 0.05 m/cell
[lifecycle_manager-3] [INFO] [1775315166.984410924] [lifecycle_manager_localization]: Configuring amcl
[amcl-2] [INFO] [1775315166.985134889] [amcl]: Configuring
[amcl-2] [INFO] [1775315166.985255056] [amcl]: initTransforms
[amcl-2] [INFO] [1775315167.014698884] [amcl]: initPubSub
[amcl-2] [INFO] [1775315167.031459655] [amcl]: Subscribed to map topic.
[lifecycle_manager-3] [INFO] [1775315167.042541262] [lifecycle_manager_localization]: Activating map_server
[map_server-1] [INFO] [1775315167.042916449] [map_server]: Activating
[map_server-1] [INFO] [1775315167.043396376] [map_server]: Creating bond (map_server) to lifecycle manager.
[amcl-2] [INFO] [1775315167.044424175] [amcl]: Received a 343 X 232 map @ 0.050 m/pix
[lifecycle_manager-3] [INFO] [1775315167.159483127] [lifecycle_manager_localization]: Server map_server connected with bond.
[lifecycle_manager-3] [INFO] [1775315167.159552572] [lifecycle_manager_localization]: Activating amcl
[amcl-2] [INFO] [1775315167.160181296] [amcl]: Activating
[amcl-2] [INFO] [1775315167.160242740] [amcl]: Creating bond (amcl) to lifecycle manager.
[amcl-2] [INFO] [1775315167.167839967] [amcl]: createLaserObject
[lifecycle_manager-3] [INFO] [1775315167.270904290] [lifecycle_manager_localization]: Server amcl connected with bond.
```

```
[lifecycle_manager-3] [INFO] [1775315167.270969272] [lifecycle_manager_localization]: Managed nodes are active
[lifecycle_manager-3] [INFO] [1775315167.270994198] [lifecycle_manager_localization]: Creating bond timer...
[amcl-2] [WARN] [1775315169.068647169] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315171.164728708] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315173.261849158] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315175.359032590] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315177.448156905] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315179.451399874] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315181.547547228] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315183.644621493] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315185.741799221] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315187.744905541] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315189.834166579] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315191.931288177] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315194.027432920] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315196.124569518] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315198.127689838] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315200.224820992] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315202.313943048] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315204.316112272] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315206.405241884] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315208.502315649] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315210.599522525] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315212.696667734] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315214.793810999] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315216.890188410] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315218.987099933] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315221.084310717] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [WARN] [1775315223.174329720] [amcl]: AMCL cannot publish a pose or update the transform. Please set the initial pose...
[amcl-2] [INFO] [1775315224.064338004] [amcl]: initialPoseReceived
[amcl-2] [WARN] [1775315224.064515245] [amcl]: Failed to transform initial pose in time (Lookup would require extrapolation into the future.  Requested time
1775315224.064402 but the latest data is at time 1775315224.020202, when looking up transform from frame [base_link] to frame [odom])
[amcl-2] [INFO] [1775315224.064550245] [amcl]: Setting pose (1775315224.064549): 0.022 -0.372 0.000
[amcl-2] [WARN] [1775315280.410182336] [amcl]: New subscription discovered on topic '/particle_cloud', requesting incompatible QoS. No messages will be sent to it. Last
incompatible policy: RELIABILITY_QOS_POLICY
```

Nav2 Console:

```
ubuntu@TB5WaLI:~/TB5-WaLI/wali_ws$ cmds/launch_test_nav2.sh
'** launch_test_nav2.sh executing **' added to life.log
Launch TB4 Navigation Nav2 with test.nav2.yaml
ros2 launch turtlebot4 navigation nav2.launch.py params file:=/home/ubuntu/TB5-WaLI/wali ws/params/test.nav2.yaml
[INFO] [launch]: All log files can be found below /home/ubuntu/.ros/log/2026-04-04-11-11-51-914290-TB5WaLI-86495
[INFO] [launch]: Default logging verbosity is set to INFO
[INFO] [controller_server-1]: process started with pid [86498]
[INFO] [smoother_server-2]: process started with pid [86499]
[INFO] [planner_server-3]: process started with pid [86500]
[INFO] [route_server-4]: process started with pid [86501]
[INFO] [behavior_server-5]: process started with pid [86502]
[INFO] [bt_navigator-6]: process started with pid [86503]
[INFO] [waypoint_follower-7]: process started with pid [86504]
[INFO] [velocity_smoother-8]: process started with pid [86505]
[INFO] [collision_monitor-9]: process started with pid [86506]
[INFO] [opennav_docking-10]: process started with pid [86507]
[INFO] [lifecycle_manager-11]: process started with pid [86508]
[planner_server-3] [INFO] [1775315512.434771201] [planner_server]:
[planner_server-3]  planner_server lifecycle node launched.
[planner_server-3] Waiting on external lifecycle transitions to activate
[planner_server-3] See https://design.ros2.org/articles/node_lifecycle.html for more information.
[smoother_server-2] [INFO] [1775315512.437241264] [smoother_server]:
[smoother_server-2]     smoother_server lifecycle node launched.
[smoother_server-2]     Waiting on external lifecycle transitions to activate
[smoother_server-2]     See https://design.ros2.org/articles/node_lifecycle.html for more information.
[smoother_server-2] [INFO] [1775315512.440783756] [smoother_server]: Creating smoother server
[planner_server-3] [INFO] [1775315512.465129680] [planner_server]: Creating
[waypoint_follower-7] [INFO] [1775315512.489765401] [waypoint_follower]:
[waypoint_follower-7]  waypoint_follower lifecycle node launched.
[waypoint_follower-7]  Waiting on external lifecycle transitions to activate
[waypoint_follower-7]  See https://design.ros2.org/articles/node_lifecycle.html for more information.
[waypoint_follower-7] [INFO] [1775315512.491993000] [waypoint_follower]: Creating
[velocity_smoother-8] [INFO] [1775315512.519928842] [velocity_smoother]:
[velocity_smoother-8]  velocity_smoother lifecycle node launched.
[velocity_smoother-8]  Waiting on external lifecycle transitions to activate
[velocity_smoother-8]  See https://design.ros2.org/articles/node_lifecycle.html for more information.
[planner_server-3] [INFO] [1775315512.562523987] [global_costmap.global_costmap]:
[planner_server-3]  global_costmap lifecycle node launched.
[planner_server-3] Waiting on external lifecycle transitions to activate
[planner_server-3] See https://design.ros2.org/articles/node_lifecycle.html for more information.
[planner_server-3] [INFO] [1775315512.567659595] [global_costmap.global_costmap]: Creating Costmap
[bt_navigator-6] [INFO] [1775315512.580206298] [bt_navigator]:
[bt_navigator-6]    bt_navigator lifecycle node launched.
[bt_navigator-6]    Waiting on external lifecycle transitions to activate
[bt_navigator-6]    See https://design.ros2.org/articles/node_lifecycle.html for more information.
[opennav_docking-10] [INFO] [1775315512.580806930] [docking_server]:
[opennav_docking-10]    docking_server lifecycle node launched.
[opennav_docking-10]    Waiting on external lifecycle transitions to activate
[opennav_docking-10]    See https://design.ros2.org/articles/node_lifecycle.html for more information.
[opennav_docking-10] [INFO] [1775315512.582577454] [docking_server]: Creating docking_server
[bt_navigator-6] [INFO] [1775315512.586497836] [bt_navigator]: Creating
[controller_server-1] [INFO] [1775315512.603976184] [controller_server]:
[controller_server-1]  controller_server lifecycle node launched.
[controller_server-1]  Waiting on external lifecycle transitions to activate
[controller_server-1]  See https://design.ros2.org/articles/node_lifecycle.html for more information.
[lifecycle_manager-11] [INFO] [1775315512.614235492] [lifecycle_manager_navigation]: Creating
[controller_server-1] [INFO] [1775315512.615844959] [controller_server]: Creating controller_server
[lifecycle_manager-11] [INFO] [1775315512.622697683] [lifecycle_manager_navigation]: Creating and initializing lifecycle service clients
[controller_server-1] [INFO] [1775315512.632305767] [local_costmap.local_costmap]:
[controller_server-1]  local_costmap lifecycle node launched.
[controller_server-1]  Waiting on external lifecycle transitions to activate
[controller_server-1]  See https://design.ros2.org/articles/node_lifecycle.html for more information.
[controller_server-1] [INFO] [1775315512.633295807] [local_costmap.local_costmap]: Creating Costmap
[route_server-4] [INFO] [1775315512.669070524] [route_server]:
[route_server-4]    route_server lifecycle node launched.
[route_server-4]    Waiting on external lifecycle transitions to activate
[route_server-4]    See https://design.ros2.org/articles/node_lifecycle.html for more information.
[collision_monitor-9] [INFO] [1775315512.679639315] [collision_monitor]:
[collision_monitor-9]  collision_monitor lifecycle node launched.
[collision_monitor-9]  Waiting on external lifecycle transitions to activate
[collision_monitor-9]  See https://design.ros2.org/articles/node_lifecycle.html for more information.
[behavior_server-5] [INFO] [1775315512.680469540] [behavior_server]:
[behavior_server-5]     behavior_server lifecycle node launched.
[behavior_server-5]     Waiting on external lifecycle transitions to activate
[behavior_server-5]     See https://design.ros2.org/articles/node_lifecycle.html for more information.
[lifecycle_manager-11] [INFO] [1775315514.627056858] [lifecycle_manager_navigation]: Waiting for service controller_server/get_state...
[lifecycle_manager-11] [INFO] [1775315516.628974414] [lifecycle_manager_navigation]: Waiting for service controller_server/get_state...
[lifecycle_manager-11] [INFO] [1775315518.480628174] [lifecycle_manager_navigation]: Starting managed nodes bringup...
[lifecycle_manager-11] [INFO] [1775315518.480723267] [lifecycle_manager_navigation]: Configuring controller_server
[controller_server-1] [INFO] [1775315518.484894316] [controller_server]: Configuring controller interface
[controller_server-1] [INFO] [1775315518.484952113] [controller_server]: getting progress checker plugins..
[controller_server-1] [INFO] [1775315518.485454762] [controller_server]: getting goal checker plugins..
[controller_server-1] [INFO] [1775315518.485775985] [controller_server]: Controller frequency set to 20.0000Hz
[controller_server-1] [INFO] [1775315518.485860282] [local_costmap.local_costmap]: Configuring
```

```
[controller_server-1] [INFO] [1775315518.620939793] [local_costmap.local_costmap]: Using plugin "static_layer"
[controller_server-1] [INFO] [1775315518.637138211] [local_costmap.local_costmap]: Subscribing to the map topic (/map) with transient local durability
[controller_server-1] [INFO] [1775315518.673033392] [local_costmap.local_costmap]: Initialized plugin "static_layer"
[controller_server-1] [INFO] [1775315518.673101651] [local_costmap.local_costmap]: Using plugin "voxel_layer"
[controller_server-1] [INFO] [1775315518.707649290] [local_costmap.local_costmap]: Subscribed to Topics: scan
[bt_navigator-6] [WARN] [1775315518.710663892] [bt_navigator.rclcpp]: failed to send response to /bt_navigator/get_parameters (timeout): client will not receive
response, at ./src/rmw_response.cpp:153, at ./src/rcl/service.c:400
[controller_server-1] [INFO] [1775315518.749511192] [voxel_grid]: Error, this implementation can only support up to 16 z values (20)
[controller_server-1] [INFO] [1775315518.749583044] [local_costmap.local_costmap]: Initialized plugin "voxel_layer"
[controller_server-1] [INFO] [1775315518.749626970] [local_costmap.local_costmap]: Using plugin "inflation_layer"
[controller_server-1] [INFO] [1775315518.755678729] [local_costmap.local_costmap]: Initialized plugin "inflation_layer"
[controller_server-1] [INFO] [1775315518.894900252] [local_costmap.local_costmap]: StaticLayer: Resizing static layer to 343 X 232 at 0.050000 m/pix
[controller_server-1] [INFO] [1775315518.896428275] [controller_server]: Created progress_checker : progress_checker of type nav2_controller::SimpleProgressChecker
[controller_server-1] [INFO] [1775315518.907823198] [controller_server]: Controller Server has progress_checker  progress checkers available.
[controller_server-1] [INFO] [1775315518.916192093] [controller_server]: Created goal checker : general_goal_checker of type nav2_controller::SimpleGoalChecker
[controller_server-1] [INFO] [1775315518.937430026] [controller_server]: Controller Server has general_goal_checker  goal checkers available.
[controller_server-1] [INFO] [1775315518.942162281] [controller_server]: Created controller : FollowPath of type nav2_mppi_controller::MPPIController
[controller_server-1] [INFO] [1775315518.966611927] [controller_server]: Controller period is equal to model dt. Control sequence shifting is ON
[controller_server-1] [INFO] [1775315518.975129304] [controller_server]: ConstraintCritic instantiated with 1 power and 4.000000 weight.
[controller_server-1] [INFO] [1775315518.975220638] [controller_server]: Critic loaded : mppi::critics::ConstraintCritic
[controller_server-1] [INFO] [1775315518.983222995] [controller_server]: InflationCostCritic instantiated with 1 power and 300.000000 / 0.015000 weights. Critic will
collision check based on footprint cost.
[controller_server-1] [INFO] [1775315518.983305625] [controller_server]: Critic loaded : mppi::critics::CostCritic
[controller_server-1] [INFO] [1775315518.987240655] [controller_server]: GoalCritic instantiated with 1 power and 5.000000 weight.
[controller_server-1] [INFO] [1775315518.987343211] [controller_server]: Critic loaded : mppi::critics::GoalCritic
[controller_server-1] [INFO] [1775315518.992454745] [controller_server]: GoalAngleCritic instantiated with 1 power, 3.000000 weight, and 0.500000 angular threshold.
[controller_server-1] [INFO] [1775315518.992540023] [controller_server]: Critic loaded : mppi::critics::GoalAngleCritic
[controller_server-1] [INFO] [1775315519.006520397] [controller_server]: ReferenceTrajectoryCritic instantiated with 1 power and 14.000000 weight
[controller_server-1] [INFO] [1775315519.008090365] [controller_server]: Critic loaded : mppi::critics::PathAlignCritic
[controller_server-1] [INFO] [1775315519.016841243] [controller_server]: Critic loaded : mppi::critics::PathFollowCritic
[controller_server-1] [INFO] [1775315519.023496244] [controller_server]: PathAngleCritic instantiated with 1 power and 2.000000 weight. Mode set to: Forward Preference
[controller_server-1] [INFO] [1775315519.023589374] [controller_server]: Critic loaded : mppi::critics::PathAngleCritic
[controller_server-1] [INFO] [1775315519.032105584] [controller_server]: PreferForwardCritic instantiated with 1 power and 5.000000 weight.
[controller_server-1] [INFO] [1775315519.034508295] [controller_server]: Critic loaded : mppi::critics::PreferForwardCritic
[controller_server-1] [INFO] [1775315519.043778045] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315519.064193957] [MPPIController]: Configured MPPI Controller: FollowPath
[controller_server-1] [INFO] [1775315519.064242531] [controller_server]: Controller Server has FollowPath  controllers available.
[lifecycle_manager-11] [INFO] [1775315519.128113554] [lifecycle_manager_navigation]: Configuring smoother_server
[smoother_server-2] [INFO] [1775315519.129491298] [smoother_server]: Configuring smoother server
[smoother_server-2] [INFO] [1775315519.206111673] [smoother_server]: Created smoother : simple_smoother of type nav2_smoother::SimpleSmoother
[smoother_server-2] [INFO] [1775315519.215607535] [smoother_server]: Smoother Server has simple_smoother  smoothers available.
[lifecycle_manager-11] [INFO] [1775315519.267713245] [lifecycle_manager_navigation]: Configuring planner_server
[planner_server-3] [INFO] [1775315519.271349941] [planner_server]: Configuring
[planner_server-3] [INFO] [1775315519.271430608] [global_costmap.global_costmap]: Configuring
[planner_server-3] [INFO] [1775315519.332806086] [global_costmap.global_costmap]: Using plugin "static_layer"
[planner_server-3] [INFO] [1775315519.344411453] [global_costmap.global_costmap]: Subscribing to the map topic (/map) with transient local durability
[planner_server-3] [INFO] [1775315519.354513409] [global_costmap.global_costmap]: Initialized plugin "static_layer"
[planner_server-3] [INFO] [1775315519.354579928] [global_costmap.global_costmap]: Using plugin "obstacle_layer"
[planner_server-3] [INFO] [1775315519.364714773] [global_costmap.global_costmap]: Subscribed to Topics: scan
[planner_server-3] [INFO] [1775315519.392348984] [global_costmap.global_costmap]: Initialized plugin "obstacle_layer"
[planner_server-3] [INFO] [1775315519.392434577] [global_costmap.global_costmap]: Using plugin "inflation_layer"
[planner_server-3] [INFO] [1775315519.397468184] [global_costmap.global_costmap]: Initialized plugin "inflation_layer"
[planner_server-3] [INFO] [1775315519.520102881] [global_costmap.global_costmap]: StaticLayer: Resizing costmap to 343 X 232 at 0.050000 m/pix
[planner_server-3] [INFO] [1775315519.522687537] [planner_server]: Created global planner plugin GridBased of type nav2_navfn_planner::NavfnPlanner
[planner_server-3] [INFO] [1775315519.522931260] [planner_server]: Configuring plugin GridBased of type NavfnPlanner
[planner_server-3] [INFO] [1775315519.541040313] [planner_server]: Planner Server has GridBased  planners available.
[lifecycle_manager-11] [INFO] [1775315519.617172520] [lifecycle_manager_navigation]: Configuring route_server
[route_server-4] [INFO] [1775315519.618012708] [route_server]: Configuring
[route_server-4] [INFO] [1775315519.770259121] [route_server]: Created GraphFileLoader GeoJsonGraphFileLoader of type nav2_route::GeoJsonGraphFileLoader
[route_server-4] [INFO] [1775315519.770350436] [route_server]: Configuring geojson graph file loader
[route_server-4] [INFO] [1775315519.770374362] [route_server]: No graph file provided to load yet.
[route_server-4] [INFO] [1775315519.791160276] [route_server]: Created edge cost function plugin DistanceScorer of type nav2_route::DistanceScorer
[route_server-4] [INFO] [1775315519.791226424] [route_server]: Configuring distance scorer.
[route_server-4] [INFO] [1775315519.791900389] [route_server]: Created edge cost function plugin DynamicEdgesScorer of type nav2_route::DynamicEdgesScorer
[route_server-4] [INFO] [1775315519.791951574] [route_server]: Configuring adjust edges scorer.
[route_server-4] [INFO] [1775315519.813183508] [route_server]: Created route operation AdjustSpeedLimit of type nav2_route::AdjustSpeedLimit
[route_server-4] [INFO] [1775315519.813249601] [route_server]: Configuring Adjust speed limit operation.
[route_server-4] [INFO] [1775315519.818582783] [route_server]: Created route operation ReroutingService of type nav2_route::ReroutingService
[route_server-4] [INFO] [1775315519.819489656] [route_server]: Configuring Rerouting service operation.
[lifecycle_manager-11] [INFO] [1775315519.837798840] [lifecycle_manager_navigation]: Configuring behavior_server
[behavior_server-5] [INFO] [1775315519.839041177] [behavior_server]: Configuring
[behavior_server-5] [INFO] [1775315519.879148370] [behavior_server]: Creating behavior plugin spin of type nav2_behaviors::Spin
[behavior_server-5] [INFO] [1775315519.883722142] [behavior_server]: Creating behavior plugin backup of type nav2_behaviors::BackUp
[behavior_server-5] [INFO] [1775315519.888141044] [behavior_server]: Creating behavior plugin drive_on_heading of type nav2_behaviors::DriveOnHeading
[behavior_server-5] [INFO] [1775315519.892488594] [behavior_server]: Creating behavior plugin assisted_teleop of type nav2_behaviors::AssistedTeleop
[behavior_server-5] [INFO] [1775315519.897335886] [behavior_server]: Creating behavior plugin wait of type nav2_behaviors::Wait
[behavior_server-5] [INFO] [1775315519.918424430] [behavior_server]: Configuring spin
[behavior_server-5] [INFO] [1775315519.967641891] [behavior_server]: Configuring backup
[behavior_server-5] [INFO] [1775315520.000339562] [behavior_server]: Configuring drive_on_heading
[behavior_server-5] [INFO] [1775315520.023094611] [behavior_server]: Configuring assisted_teleop
[behavior_server-5] [INFO] [1775315520.051263361] [behavior_server]: Configuring wait
[lifecycle_manager-11] [INFO] [1775315520.080438280] [lifecycle_manager_navigation]: Configuring velocity_smoother
[velocity_smoother-8] [INFO] [1775315520.082113934] [velocity_smoother]: Configuring velocity smoother
[lifecycle_manager-11] [INFO] [1775315520.137212782] [lifecycle_manager_navigation]: Configuring collision_monitor
[collision_monitor-9] [INFO] [1775315520.138102507] [collision_monitor]: Configuring
[collision_monitor-9] [INFO] [1775315520.188478285] [collision_monitor]: [scan]: Creating Scan
[collision_monitor-9] [INFO] [1775315520.208567641] [collision_monitor]: [FootprintApproach]: Creating Polygon
[collision_monitor-9] [INFO] [1775315520.210168201] [collision_monitor]: [FootprintApproach]: Polygon points are not defined. Using dynamic subscription instead.
[collision_monitor-9] [INFO] [1775315520.226569157] [collision_monitor]: [FootprintApproach]: Making footprint subscriber on local_costmap/published_footprint topic
[lifecycle_manager-11] [INFO] [1775315520.306167652] [lifecycle_manager_navigation]: Configuring bt_navigator
[bt_navigator-6] [INFO] [1775315520.307982232] [bt_navigator]: Configuring
[bt_navigator-6] [INFO] [1775315520.344177432] [bt_navigator]: Creating navigator id navigate_to_pose of type nav2_bt_navigator::NavigateToPoseNavigator
[bt_navigator-6] [INFO] [1775315520.594314450] [bt_navigator]: Creating navigator id navigate_through_poses of type nav2_bt_navigator::NavigateThroughPosesNavigator
[lifecycle_manager-11] [INFO] [1775315520.740693161] [lifecycle_manager_navigation]: Configuring waypoint_follower
[waypoint_follower-7] [INFO] [1775315520.742032276] [waypoint_follower]: Configuring
[waypoint_follower-7] [INFO] [1775315520.858172768] [waypoint_follower]: Created waypoint_task_executor : wait_at_waypoint of type nav2_waypoint_follower::WaitAtWaypoint
[lifecycle_manager-11] [INFO] [1775315520.869662821] [lifecycle_manager_navigation]: Configuring docking_server
[opennav_docking-10] [INFO] [1775315520.870542731] [docking_server]: Configuring docking server
[opennav_docking-10] [INFO] [1775315520.870608194] [docking_server]: Controller frequency set to 50.0000Hz
[opennav_docking-10] [INFO] [1775315521.038137745] [docking_server]: Created charging dock plugin simple_charging_dock of type opennav_docking::SimpleChargingDock
[opennav_docking-10] [WARN] [1775315521.089547064] [docking_server]: Dock database filepath nor dock parameters set. Docking actions can only be executed specifying the
dock pose via the action request. Or update the dock database via the reload_database service.
[opennav_docking-10] [INFO] [1775315521.089631490] [docking_server]: Docking Server has 1 dock types and 0 dock instances available.
[lifecycle_manager-11] [INFO] [1775315521.098317868] [lifecycle_manager_navigation]: Activating controller_server
[controller_server-1] [INFO] [1775315521.099073796] [controller_server]: Activating
[controller_server-1] [INFO] [1775315521.099128667] [local_costmap.local_costmap]: Activating
[controller_server-1] [INFO] [1775315521.099143204] [local_costmap.local_costmap]: Checking transform
[controller_server-1] [INFO] [1775315521.099329871] [local_costmap.local_costmap]: start
[controller_server-1] [WARN] [1775315521.308666676] [controller_server]: Parameter controller_server.verbose not found
[controller_server-1] [INFO] [1775315521.313369671] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315521.314508656] [MPPIController]: Activated MPPI Controller: FollowPath
[controller_server-1] [INFO] [1775315521.314574804] [controller_server]: Creating bond (controller_server) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315521.435945867] [lifecycle_manager_navigation]: Server controller_server connected with bond.
[lifecycle_manager-11] [INFO] [1775315521.436024553] [lifecycle_manager_navigation]: Activating smoother_server
[smoother_server-2] [INFO] [1775315521.437246982] [smoother_server]: Activating
[smoother_server-2] [INFO] [1775315521.437320983] [smoother_server]: Creating bond (smoother_server) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315521.552543713] [lifecycle_manager_navigation]: Server smoother_server connected with bond.
[lifecycle_manager-11] [INFO] [1775315521.552632046] [lifecycle_manager_navigation]: Activating planner_server
[planner_server-3] [INFO] [1775315521.553738883] [planner_server]: Activating
[planner_server-3] [INFO] [1775315521.553813939] [global_costmap.global_costmap]: Activating
[planner_server-3] [INFO] [1775315521.553833253] [global_costmap.global_costmap]: Checking transform
[planner_server-3] [INFO] [1775315521.554091958] [global_costmap.global_costmap]: start
```

```
[planner_server-3] [INFO] [1775315522.558411783] [planner_server]: Activating plugin GridBased of type NavfnPlanner
[planner_server-3] [INFO] [1775315522.571017394] [planner_server]: Creating bond (planner_server) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315522.695077614] [lifecycle_manager_navigation]: Server planner_server connected with bond.
[lifecycle_manager-11] [INFO] [1775315522.695153373] [lifecycle_manager_navigation]: Activating route_server
[route_server-4] [INFO] [1775315522.695943561] [route_server]: Activating
[route_server-4] [INFO] [1775315522.696187246] [route_server]: Creating bond (route_server) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315522.813358038] [lifecycle_manager_navigation]: Server route_server connected with bond.
[lifecycle_manager-11] [INFO] [1775315522.813439408] [lifecycle_manager_navigation]: Activating behavior_server
[behavior_server-5] [INFO] [1775315522.814282226] [behavior_server]: Activating
[behavior_server-5] [INFO] [1775315522.814324967] [behavior_server]: Activating spin
[behavior_server-5] [INFO] [1775315522.814346337] [behavior_server]: Activating backup
[behavior_server-5] [INFO] [1775315522.814363837] [behavior_server]: Activating drive_on_heading
[behavior_server-5] [INFO] [1775315522.814383504] [behavior_server]: Activating assisted_teleop
[behavior_server-5] [INFO] [1775315522.814404745] [behavior_server]: Activating wait
[behavior_server-5] [INFO] [1775315522.814432319] [behavior_server]: Creating bond (behavior_server) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315522.946061375] [lifecycle_manager_navigation]: Server behavior_server connected with bond.
[lifecycle_manager-11] [INFO] [1775315522.946133468] [lifecycle_manager_navigation]: Activating velocity_smoother
[velocity_smoother-8] [INFO] [1775315522.947061045] [velocity_smoother]: Activating
[velocity_smoother-8] [INFO] [1775315522.947174156] [velocity_smoother]: Creating bond (velocity_smoother) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315523.081570610] [lifecycle_manager_navigation]: Server velocity_smoother connected with bond.
[lifecycle_manager-11] [INFO] [1775315523.081658721] [lifecycle_manager_navigation]: Activating collision_monitor
[collision_monitor-9] [INFO] [1775315523.082391223] [collision_monitor]: Activating
[collision_monitor-9] [INFO] [1775315523.082450742] [collision_monitor]: Creating bond (collision_monitor) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315523.210788937] [lifecycle_manager_navigation]: Server collision_monitor connected with bond.
[lifecycle_manager-11] [INFO] [1775315523.210870011] [lifecycle_manager_navigation]: Activating bt_navigator
[bt_navigator-6] [INFO] [1775315523.211815162] [bt_navigator]: Activating
[bt_navigator-6] [INFO] [1775315523.741282211] [bt_navigator]: Creating bond (bt_navigator) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315523.858621077] [lifecycle_manager_navigation]: Server bt_navigator connected with bond.
[lifecycle_manager-11] [INFO] [1775315523.858695688] [lifecycle_manager_navigation]: Activating waypoint_follower
[waypoint_follower-7] [INFO] [1775315523.859709024] [waypoint_follower]: Activating
[waypoint_follower-7] [INFO] [1775315523.859791951] [waypoint_follower]: Creating bond (waypoint_follower) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315523.982851333] [lifecycle_manager_navigation]: Server waypoint_follower connected with bond.
[lifecycle_manager-11] [INFO] [1775315523.982975630] [lifecycle_manager_navigation]: Activating docking_server
[opennav_docking-10] [INFO] [1775315523.984893210] [docking_server]: Activating docking_server
[opennav_docking-10] [INFO] [1775315524.088307405] [docking_server]: Creating bond (docking_server) to lifecycle manager.
[lifecycle_manager-11] [INFO] [1775315524.236168602] [lifecycle_manager_navigation]: Server docking_server connected with bond.
[lifecycle_manager-11] [INFO] [1775315524.236258047] [lifecycle_manager_navigation]: Managed nodes are active
[lifecycle_manager-11] [INFO] [1775315524.236285084] [lifecycle_manager_navigation]: Creating bond timer...
[waypoint_follower-7] [INFO] [1775315816.369935492] [waypoint_follower]: Received follow waypoint request with 10 waypoints.
[bt_navigator-6] [INFO] [1775315816.375159544] [bt_navigator]: Begin navigating from current location (-0.23, -0.34) to (3.39, 3.99)
[controller_server-1] [INFO] [1775315816.397174054] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [WARN] [1775315816.397271036] [controller_server]: No goal checker was specified in parameter 'current_goal_checker'. Server will use only plugin
loaded general_goal_checker . This warning will appear once.
[controller_server-1] [WARN] [1775315816.397295165] [controller_server]: No progress checker was specified in parameter 'current_progress_checker'. Server will use only
plugin loaded progress_checker . This warning will appear once.
[controller_server-1] [INFO] [1775315817.448282962] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315818.399048925] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 20.0234 Hz.
[controller_server-1] [INFO] [1775315818.498270904] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315819.498324975] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315820.548636326] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315821.548630434] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315822.598312505] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315823.598336095] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315824.648287925] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315825.649244537] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315826.298243162] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 20.6173 Hz.
[controller_server-1] [INFO] [1775315826.698295606] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315827.598343770] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 19.9764 Hz.
[controller_server-1] [INFO] [1775315827.698294807] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315828.748423916] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315829.749174415] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315830.748328707] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315831.798285574] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315832.798429146] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315833.848281384] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315834.849056995] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315835.849906569] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315836.898291617] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315837.948380411] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315838.948364260] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315839.948936982] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315840.998279144] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315841.998291234] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315842.622431174] [controller_server]: Reached the goal!
[controller_server-1] [INFO] [1775315842.630128216] [controller_server]: Optimizer reset
[bt_navigator-6] [INFO] [1775315842.659019986] [bt_navigator]: Goal succeeded
[waypoint_follower-7] [INFO] [1775315843.320261833] [waypoint_follower]: Succeeded processing waypoint 0, processing waypoint task execution
[waypoint_follower-7] [INFO] [1775315843.320335481] [waypoint_follower]: Arrived at 0'th waypoint, sleeping for 10000 milliseconds
[waypoint_follower-7] [INFO] [1775315853.320450512] [waypoint_follower]: Task execution at waypoint 0 succeeded
[waypoint_follower-7] [INFO] [1775315853.320524142] [waypoint_follower]: Handled task execution on waypoint 0, moving to next.
[bt_navigator-6] [INFO] [1775315853.322369666] [bt_navigator]: Begin navigating from current location (3.52, 3.97) to (0.50, 2.70)
[controller_server-1] [INFO] [1775315853.333736237] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315854.383997735] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315855.383991769] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315856.434555176] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315857.434376321] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315858.483991132] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315859.483994259] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315860.351376642] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 14.8765 Hz.
[controller_server-1] [WARN] [1775315860.398751097] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 21.1446 Hz.
[controller_server-1] [WARN] [1775315860.439573070] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 24.5484 Hz.
[bt_navigator-6] [WARN] [1775315860.544914845] [bt_navigator_navigate_to_pose_rclcpp_node]: Timed out while waiting for action server to acknowledge goal request for
compute_path_to_pose
[controller_server-1] [WARN] [1775315860.563246677] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 8.1139 Hz.
[bt_navigator-6] [ERROR] [1775315860.572012795] [bt_navigator_navigate_to_pose_rclcpp_node]: Failed to cancel action server for follow_path
[bt_navigator-6] [ERROR] [1775315860.592239781] [bt_navigator_navigate_to_pose_rclcpp_node]: Failed to get result for follow_path in node halt!
[bt_navigator-6] [WARN] [1775315860.595856736] [bt_navigator]: [navigate_to_pose] [ActionServer] Aborting handle.
[bt_navigator-6] [ERROR] [1775315860.596983036] [bt_navigator]: Goal failed
[controller_server-1] [INFO] [1775315860.663334195] [controller_server]: Cancellation was successful. Stopping the robot.
[controller_server-1] [INFO] [1775315860.663410825] [controller_server]: [follow_path] [ActionServer] Client requested to cancel the goal. Cancelling.
[controller_server-1] [INFO] [1775315860.664632106] [controller_server]: Optimizer reset
[waypoint_follower-7] [INFO] [1775315861.270877012] [waypoint_follower]: Failed to process waypoint 1, moving to next.
[bt_navigator-6] [INFO] [1775315861.323051704] [bt_navigator]: Begin navigating from current location (2.94, 3.84) to (2.70, -1.47)
[controller_server-1] [INFO] [1775315861.344235841] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315862.394456672] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315863.444458947] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315864.444454704] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315865.494461720] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315866.494447217] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315867.544459141] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315868.594451453] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315869.594453117] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315870.644474744] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315871.644457649] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315872.644459498] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315873.694456496] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315874.744455400] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315875.744461972] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315876.794451414] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315877.794460189] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315878.844456853] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315879.844450573] [controller_server]: Passing new path to controller.
```

```
[controller_server-1] [INFO] [1775315880.894455107] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315881.894453549] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315882.944453047] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315883.944455785] [controller_server]: Passing new path to controller.
[planner_server-3] [INFO] [1775315884.307054543] [global_costmap.global_costmap]: Message Filter dropping message: frame 'rplidar_link' at time 1775315883.906 for reason
'the timestamp on the message is earlier than all the data in the transform cache'
[controller_server-1] [INFO] [1775315884.944451727] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315885.994474539] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315886.994681778] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315888.044453312] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315888.267603917] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.287577550] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.287824680] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315888.312522790] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.333528945] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.333757576] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315888.567243063] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.583138295] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.584112243] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315888.609858634] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.622809783] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.622946117] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315888.662676271] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.681661365] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.681821606] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315888.714355147] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.735186727] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.735307579] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315888.759508891] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.774566936] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.774699918] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315888.810439987] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.822732338] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.822924857] [controller_server]: Optimizer fail to compute path
[controller_server-1] [ERROR] [1775315888.823006413] [controller_server]: Controller patience exceeded
[controller_server-1] [INFO] [1775315888.830030174] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.830108304] [controller_server]: [follow_path] [ActionServer] Aborting handle.
[controller_server-1] [INFO] [1775315888.843802993] [local_costmap.local_costmap]: Received request to clear entirely the local_costmap
[controller_server-1] [INFO] [1775315888.844912570] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315888.919270124] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.940606131] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.941028799] [controller_server]: Optimizer fail to compute path
[controller_server-1] [WARN] [1775315888.941295874] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 10.3860 Hz.
[controller_server-1] [INFO] [1775315888.965896577] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315888.981978606] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315888.982802960] [controller_server]: Optimizer fail to compute path
[controller_server-1] [WARN] [1775315888.983119961] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 23.9348 Hz.
[controller_server-1] [INFO] [1775315889.000329660] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.019166308] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.019339346] [controller_server]: Optimizer fail to compute path
[controller_server-1] [WARN] [1775315889.020559035] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 26.7425 Hz.
[controller_server-1] [INFO] [1775315889.045208626] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.074820251] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.075031696] [controller_server]: Optimizer fail to compute path
[controller_server-1] [WARN] [1775315889.078330465] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 17.3308 Hz.
[controller_server-1] [INFO] [1775315889.078404576] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315889.103673799] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.128075409] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.128256668] [controller_server]: Optimizer fail to compute path
[controller_server-1] [WARN] [1775315889.129440172] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 19.5931 Hz.
[controller_server-1] [INFO] [1775315889.154537135] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.172664300] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.175492642] [controller_server]: Optimizer fail to compute path
[controller_server-1] [ERROR] [1775315889.175617679] [controller_server]: Controller patience exceeded
[controller_server-1] [INFO] [1775315889.182511107] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.182630459] [controller_server]: [follow_path] [ActionServer] Aborting handle.
[controller_server-1] [INFO] [1775315889.193769751] [local_costmap.local_costmap]: Received request to clear entirely the local_costmap
[planner_server-3] [INFO] [1775315889.194543883] [global_costmap.global_costmap]: Received request to clear entirely the global_costmap
[controller_server-1] [INFO] [1775315889.583942610] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315889.598770950] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.615742352] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.616946671] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315889.650512066] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.672316557] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.672497594] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315889.696418406] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.720216884] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.720413755] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315889.750056842] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.763073714] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.763260456] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315889.797914929] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.811428228] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.811607932] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315889.846962259] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.863615790] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.863834327] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315889.896614017] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315889.920718014] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.920849256] [controller_server]: Optimizer fail to compute path
[controller_server-1] [ERROR] [1775315889.920936182] [controller_server]: Controller patience exceeded
[controller_server-1] [INFO] [1775315889.924592841] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315889.924690045] [controller_server]: [follow_path] [ActionServer] Aborting handle.
[controller_server-1] [INFO] [1775315889.943725694] [local_costmap.local_costmap]: Received request to clear entirely the local_costmap
[controller_server-1] [INFO] [1775315889.944530511] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315890.117384800] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315890.136486209] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315890.136653043] [controller_server]: Optimizer fail to compute path
[controller_server-1] [WARN] [1775315890.136973136] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 5.1988 Hz.
[controller_server-1] [INFO] [1775315890.154650670] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315890.176561290] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315890.176702328] [controller_server]: Optimizer fail to compute path
[controller_server-1] [INFO] [1775315890.242086670] [controller_server]: Optimizer reset
[controller_server-1] [INFO] [1775315890.267597875] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315890.267781412] [controller_server]: Optimizer fail to compute path
[controller_server-1] [ERROR] [1775315890.267848449] [controller_server]: Controller patience exceeded
[controller_server-1] [INFO] [1775315890.274605562] [controller_server]: Optimizer reset
[controller_server-1] [WARN] [1775315890.274712007] [controller_server]: [follow_path] [ActionServer] Aborting handle.
[behavior_server-5] [INFO] [1775315890.295455328] [behavior_server]: Running spin
[behavior_server-5] [INFO] [1775315890.295711347] [behavior_server]: Turning 1.57 for spin behavior.
[behavior_server-5] [WARN] [1775315890.596532737] [behavior_server]: Collision Ahead - Exiting Spin
[behavior_server-5] [WARN] [1775315890.596591886] [behavior_server]: spin failed
[behavior_server-5] [WARN] [1775315890.596613497] [behavior_server]: [spin] [ActionServer] Aborting handle.
[behavior_server-5] [INFO] [1775315890.614004141] [behavior_server]: Running wait
[behavior_server-5] [INFO] [1775315895.614294944] [behavior_server]: wait completed successfully
[controller_server-1] [INFO] [1775315895.638228182] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315896.688411457] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315897.114141403] [controller_server]: Reached the goal!
[controller_server-1] [INFO] [1775315897.115448018] [controller_server]: Optimizer reset
[bt_navigator-6] [INFO] [1775315897.143537990] [bt_navigator]: Goal succeeded
[waypoint_follower-7] [INFO] [1775315897.820858791] [waypoint_follower]: Succeeded processing waypoint 2, processing waypoint task execution
[waypoint_follower-7] [INFO] [1775315897.820932792] [waypoint_follower]: Arrived at 2'th waypoint, sleeping for 10000 milliseconds
```

```
[waypoint_follower-7] [INFO] [1775315907.821032286] [waypoint_follower]: Task execution at waypoint 2 succeeded
[waypoint_follower-7] [INFO] [1775315907.821098304] [waypoint_follower]: Handled task execution on waypoint 2, moving to next.
[bt_navigator-6] [INFO] [1775315907.822479994] [bt_navigator]: Begin navigating from current location (2.59, -1.36) to (0.97, -0.70)
[controller_server-1] [INFO] [1775315907.843924168] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315908.894110611] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315909.944112738] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315910.944112624] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315911.944115381] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315912.994106952] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315913.994112950] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315915.044115743] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315916.044111445] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315917.094112831] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315918.095950593] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315919.144779957] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 19.7368 Hz.
[controller_server-1] [INFO] [1775315919.145146329] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315920.144108990] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315920.195091344] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 19.6130 Hz.
[controller_server-1] [WARN] [1775315920.478821222] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 5.4233 Hz.
[controller_server-1] [INFO] [1775315921.178988165] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315922.178922736] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315923.228917104] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315924.228912879] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315925.279037118] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315926.053612614] [controller_server]: Reached the goal!
[controller_server-1] [INFO] [1775315926.055716787] [controller_server]: Optimizer reset
[bt_navigator-6] [INFO] [1775315926.078085965] [bt_navigator]: Goal succeeded
[waypoint_follower-7] [INFO] [1775315926.721562073] [waypoint_follower]: Succeeded processing waypoint 3, processing waypoint task execution
[waypoint_follower-7] [INFO] [1775315926.721630240] [waypoint_follower]: Arrived at 3'th waypoint, sleeping for 10000 milliseconds
[waypoint_follower-7] [INFO] [1775315936.721739067] [waypoint_follower]: Task execution at waypoint 3 succeeded
[waypoint_follower-7] [INFO] [1775315936.721811845] [waypoint_follower]: Handled task execution on waypoint 3, moving to next.
[bt_navigator-6] [INFO] [1775315936.723705314] [bt_navigator]: Begin navigating from current location (0.84, -0.61) to (-2.60, -0.50)
[controller_server-1] [INFO] [1775315936.744836784] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315937.795068782] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315938.845076150] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315939.845067110] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315940.895065756] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315941.895074920] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315942.895068214] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315943.945068970] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315944.945079857] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315945.995068132] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315946.995068185] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315948.045070997] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315949.045065272] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315950.095071085] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315951.095064101] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315952.145066117] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315953.145175596] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315954.195064167] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315955.195071368] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315956.245066014] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315957.245068696] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315958.245059768] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315959.298380146] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 19.0871 Hz.
[controller_server-1] [INFO] [1775315959.298455738] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315960.295265541] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315961.345064890] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315961.923485621] [controller_server]: Reached the goal!
[controller_server-1] [INFO] [1775315961.926055573] [controller_server]: Optimizer reset
[bt_navigator-6] [INFO] [1775315961.945599186] [bt_navigator]: Goal succeeded
[waypoint_follower-7] [INFO] [1775315962.622164726] [waypoint_follower]: Succeeded processing waypoint 4, processing waypoint task execution
[waypoint_follower-7] [INFO] [1775315962.622237004] [waypoint_follower]: Arrived at 4'th waypoint, sleeping for 10000 milliseconds
[waypoint_follower-7] [INFO] [1775315972.622710370] [waypoint_follower]: Task execution at waypoint 4 succeeded
[waypoint_follower-7] [INFO] [1775315972.622804296] [waypoint_follower]: Handled task execution on waypoint 4, moving to next.
[bt_navigator-6] [INFO] [1775315972.624234189] [bt_navigator]: Begin navigating from current location (-2.65, -0.67) to (3.71, 1.04)
[controller_server-1] [INFO] [1775315972.655580430] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775315973.705824521] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315974.705834463] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315975.755832182] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315976.755842291] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315977.806340567] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315978.805836138] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315979.855849561] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775315980.402731773] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 6.8076 Hz.
[controller_server-1] [INFO] [1775315980.853401199] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315981.902767750] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315982.902864489] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315983.952849746] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315984.953022132] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315986.002883092] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315987.002823367] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315988.002820383] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315989.052831270] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315990.053270769] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315991.102816487] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315992.102814447] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315993.152939464] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315994.152835053] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315995.202826495] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315996.202836270] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315997.253120287] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775315998.253041007] [controller_server]: Passing new path to controller.
[planner_server-3] [INFO] [1775315998.813019035] [global_costmap.global_costmap]: Message Filter dropping message: frame 'rplidar_link' at time 1775315998.408 for reason
'the timestamp on the message is earlier than all the data in the transform cache'
[controller_server-1] [INFO] [1775315999.252841559] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316000.302816205] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316001.303299296] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316002.352830459] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316003.352835549] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316004.402818602] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316005.283160653] [controller_server]: Reached the goal!
[controller_server-1] [INFO] [1775316005.284310823] [controller_server]: Optimizer reset
[bt_navigator-6] [INFO] [1775316005.310528993] [bt_navigator]: Goal succeeded
[waypoint_follower-7] [INFO] [1775316005.973290362] [waypoint_follower]: Succeeded processing waypoint 5, processing waypoint task execution
[waypoint_follower-7] [INFO] [1775316005.973366418] [waypoint_follower]: Arrived at 5'th waypoint, sleeping for 10000 milliseconds
[waypoint_follower-7] [INFO] [1775316015.973507801] [waypoint_follower]: Task execution at waypoint 5 succeeded
[waypoint_follower-7] [INFO] [1775316015.973578320] [waypoint_follower]: Handled task execution on waypoint 5, moving to next.
[bt_navigator-6] [INFO] [1775316015.975609437] [bt_navigator]: Begin navigating from current location (3.97, 1.21) to (-3.40, 2.10)
[controller_server-1] [INFO] [1775316015.998009466] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775316017.048742929] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316018.098280721] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316019.098274089] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316020.098274308] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316021.148746492] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316022.148319081] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316023.198425042] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316024.198276669] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316025.198272148] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316026.248285701] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775316026.300105965] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 19.2946 Hz.
[controller_server-1] [INFO] [1775316027.249626369] [controller_server]: Passing new path to controller.
```

```
[controller_server-1] [WARN] [1775316028.309734229] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 16.2708 Hz.
[controller_server-1] [INFO] [1775316028.309826489] [controller_server]: Passing new path to controller.
[bt_navigator-6] [WARN] [1775316029.278621820] [bt_navigator_navigate_to_pose_rclcpp_node]: Timed out while waiting for action server to acknowledge goal request for
compute path to pose
[controller_server-1] [INFO] [1775316029.298271489] [controller_server]: Cancellation was successful. Stopping the robot.
[controller_server-1] [INFO] [1775316029.298336415] [controller_server]: [follow_path] [ActionServer] Client requested to cancel the goal. Cancelling.
[controller_server-1] [INFO] [1775316029.299560660] [controller_server]: Optimizer reset
[bt_navigator-6] [WARN] [1775316029.302303834] [bt_navigator]: [navigate_to_pose] [ActionServer] Aborting handle.
[bt_navigator-6] [ERROR] [1775316029.308169407] [bt_navigator]: Goal failed
[waypoint_follower-7] [INFO] [1775316029.975088197] [waypoint_follower]: Failed to process waypoint 6, moving to next.
[bt_navigator-6] [INFO] [1775316030.029829877] [bt_navigator]: Begin navigating from current location (0.93, 0.68) to (-4.56, -0.01)
[controller_server-1] [INFO] [1775316030.052889223] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775316031.103101110] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316032.103932758] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316033.153127698] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316034.153188492] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316035.203103137] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316036.203118375] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316037.253099798] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316038.253348741] [controller_server]: Passing new path to controller.
[bt_navigator-6] [WARN] [1775316039.286431114] [bt_navigator_navigate_to_pose_rclcpp_node]: Timed out while waiting for action server to acknowledge goal request for
follow_path
[bt_navigator-6] [WARN] [1775316039.298428946] [bt_navigator]: [navigate_to_pose] [ActionServer] Aborting handle.
[bt_navigator-6] [ERROR] [1775316039.299856302] [bt_navigator]: Goal failed
[controller_server-1] [INFO] [1775316039.303157201] [controller_server]: Passing new path to controller.
[waypoint_follower-7] [INFO] [1775316039.974495022] [waypoint_follower]: Failed to process waypoint 7, moving to next.
[bt_navigator-6] [INFO] [1775316040.030515002] [bt_navigator]: Begin navigating from current location (-1.38, 0.34) to (2.10, 4.00)
[controller_server-1] [INFO] [1775316040.053678701] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775316040.309825200] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 18.2189 Hz.
[controller_server-1] [WARN] [1775316040.455307890] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 9.9365 Hz.
[controller_server-1] [INFO] [1775316041.105543537] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316042.105392867] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316043.155401013] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316044.155410325] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316045.155806490] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316046.205402431] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316047.205411447] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316048.256235540] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316049.305488868] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316050.305495236] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316051.355400715] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316052.355398675] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316053.405400506] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316054.405392059] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316055.455398408] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316056.455392961] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316057.505399014] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316058.505538938] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316059.555812899] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316060.556546436] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316061.605395133] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316062.655395001] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316063.654456666] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316064.705404533] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316065.755399345] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316066.755400861] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316067.805392562] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316068.481425805] [controller_server]: Reached the goal!
[controller_server-1] [INFO] [1775316068.483106254] [controller_server]: Optimizer reset
[bt_navigator-6] [INFO] [1775316068.506064359] [bt_navigator]: Goal succeeded
[waypoint_follower-7] [INFO] [1775316069.174758487] [waypoint_follower]: Succeeded processing waypoint 8, processing waypoint task execution
[waypoint_follower-7] [INFO] [1775316069.174841765] [waypoint_follower]: Arrived at 8'th waypoint, sleeping for 10000 milliseconds
[waypoint_follower-7] [INFO] [1775316079.174940092] [waypoint_follower]: Task execution at waypoint 8 succeeded
[waypoint_follower-7] [INFO] [1775316079.175014759] [waypoint_follower]: Handled task execution on waypoint 8, moving to next.
[bt_navigator-6] [INFO] [1775316079.177039302] [bt_navigator]: Begin navigating from current location (1.91, 4.13) to (-0.21, -0.32)
[controller_server-1] [INFO] [1775316079.198563514] [controller_server]: Received a goal, begin computing control effort.
[controller_server-1] [INFO] [1775316080.248776845] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316081.298831009] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316082.348789247] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316083.398776245] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316084.398849002] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316085.449031370] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316086.448791756] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316087.498822327] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316088.498783732] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316089.548792915] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316090.598776542] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316091.599530986] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316092.648771796] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316093.698791978] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316094.698782624] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316095.748795195] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316096.748777193] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316097.748784672] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316098.798898392] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316099.798782352] [controller_server]: Passing new path to controller.
[controller_server-1] [WARN] [1775316100.440292510] [controller_server]: Control loop missed its desired rate of 20.0000 Hz. Current loop rate is 7.0667 Hz.
[controller_server-1] [INFO] [1775316100.841199642] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316101.890446563] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316102.891494563] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316103.890457576] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316104.940497037] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316105.940384960] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316106.990388328] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316107.990388381] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316108.990384674] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316110.040577154] [controller_server]: Passing new path to controller.
[controller_server-1] [INFO] [1775316110.083590800] [controller_server]: Reached the goal!
[controller_server-1] [INFO] [1775316110.084792933] [controller_server]: Optimizer reset
[bt_navigator-6] [INFO] [1775316110.111031474] [bt_navigator]: Goal succeeded
[waypoint_follower-7] [INFO] [1775316110.775370051] [waypoint_follower]: Succeeded processing waypoint 9, processing waypoint task execution
[waypoint_follower-7] [INFO] [1775316110.775438718] [waypoint_follower]: Arrived at 9'th waypoint, sleeping for 10000 milliseconds
[waypoint_follower-7] [INFO] [1775316120.775540768] [waypoint_follower]: Task execution at waypoint 9 succeeded
[waypoint_follower-7] [INFO] [1775316120.775618453] [waypoint_follower]: Handled task execution on waypoint 9, moving to next.
[waypoint_follower-7] [INFO] [1775316120.775635268] [waypoint_follower]: Completed all 10 waypoints requested.
```