



TUBE CLEANING

CHECKLIST (Manual)



All team members must understand and practice hand signals for “Turn on Water”, “Pressure Up/OK to begin blasting”, and “Cut Pressure”

Safety Devices

Select the proper size AWD collet based on the size of the lance – ensure that it will not allow the metallic hose end to pass through the device

Ensure AWD is securely in place to prevent accidental withdrawal of lance

Use snorkel tube, if necessary, to maintain maximum 1” between tube sheet and hand guard

Test the safety device before pressuring up – pull on the lance to ensure that the hose crimp catches on the collet

Pressurizing the System

Demonstrate proper placement and operation of the dump valve

Insert the lance and nozzle at least 6” into the tube before activating the dump

Use **clear hand signals** and maintain line of sight with the pump operator

Signal to the pump operator to pressurize the system, activate the dump until the required pressure is achieved

Test the dump valve before starting to clean



TUBE CLEANING

CHECKLIST (Manual) – CONT.



Flex Lancing – Oscillating Technique (Loop and Feed)

- Use proper hand position – hands 24” apart, knuckles facing up, the hand closest to the tube has a loose grip, allowing the lance to rotate
- The hand further from the tube turns 180 degrees towards the front hand, into a “palm up” position – achieve oscillation of the lance
- Feed the lance in 12-18” sections, making sure to back flush frequently to avoid blockage or hydraulicing

System Pressure Down

- Release foot pedal to dump pressure
- Signal pump operator to shut down pump, maintaining line of sight with pump operator
- Maintain control of the lance – do not leave unattended until the pump is completely shut down