ROS Resources: Documentation | Support | Discussion Forum | Service Status | Q&A answers.ros.org



tags users badges

Hi there! Please sign in help

ALL UNANSWERED

Search or ask your question

ASK YOUR QUESTION

Move a certain distance, turn, then move (Odometry topic)



Currently, I am able to have my robot move forward for a certain distance, turn right by a certain degree, then move forward again. However, it is extremely inaccurate as highlighted in ahendrix's answer here



"http://answers.ros.org/question/204973/robot-pose-slightly-off-when-publishing-to-cmd vel/".

move.angular.z = 0; movement_pub.publish(move);

I want to re-make this program by using the odometry topic. This is the current code that I have, I am currently working on the TurtleBot 2.

```
#include <ros/ros.h>
#include <geometry_msgs/Twist.h>
#include <math.h>
int main(int argc, char **argv)
const double PI = 3.14159265358979323846;
ros::init(argc, argv, "move_pub");
ros::NodeHandle n;
ros::Publisher movement_pub = n.advertise<geometry_msgs::Twist>("mobile_base/commands/velocit
y",1); //for sensors the value after , should be higher to get a more accurate result (queued)
ros::Rate rate(10); //the larger the value, the "smoother" , try value of 1 to see "jerk" move
ment
//move forward
ros::Time start = ros::Time::now();
while(ros::Time::now() - start < ros::Duration(5.0))</pre>
    geometry_msgs::Twist move;
    //velocity controls
   move.linear.x = 0.1; //speed value m/s
    move.angular.z = 0;
    movement_pub.publish(move);
    ros::spinOnce();
    rate.sleep();
//turn riaht
ros::Time start_turn = ros::Time::now();
while(ros::Time::now() - start_turn < ros::Duration(4.0))</pre>
    geometry_msgs::Twist move;
    //velocity controls
    move.linear.x = 0; //speed value m/s
    move.angular.z = -2.25;
    movement_pub.publish(move);
    ros::spinOnce();
    rate.sleep();
//move forward again
ros::Time start2 = ros::Time::now();
while(ros::Time::now() - start2 < ros::Duration(5.0))</pre>
    geometry_msgs::Twist move;
    //velocity controls
    move.linear.x = 0.1; //speed value m/s
```

Question Tools

Follow

1 follower

subscribe to rss feed

Stats

Asked:	Mar 17 '15
Seen:	3,158 times
Last updated:	Aug 28 '17

Related questions

How to get Position of turtlebot?

Turning 90degrees using the odometry orientation message

robot_pose_ekf

navigation using kinect without laser

twist message: angular velocity unit

an error waiting for move base server to come up

TF_OLD_DATA ignoring data from the past for frame odom

What does Velocity in nav_msgs/Odometry actually mean?

Obstacle avoidance in move_base package

navigation for non-holonomic robots

```
ros::spinOnce();
rate.sleep();
}
return 0;
}
```

How should I go about replicating this program using the odometry topic?

I am a beginner at ROS, all of your help will be greatly appreciated. I am currently on my school holidays and I am feeling great joy learning something new:)

Comments

http://answers.ros.org/question/20513...

I was able to find a python script in a library book that achieves this. However, I dont know how to replicate as a ROS C++ node, I posted it as a separate question.

dylankc (Mar 17 '15)

add a comment

1 Answer

Sort by »

newest

oldest

most voted

0

Hello,

I started from your code and did some changes in order to use an Odometry message to measure how much the robot moved.



I couldn't format the code properly using this editor, so I created a post: http://www.theconstructsim.com/move-c... But you can see the code below:

```
#include <ros/ros.h>
#include <tf/tf.h>
#include <geometry_msgs/Twist.h>
#include <geometry_msgs/Pose2D.h>
#include <nav msqs/Odometry.h>
#include <math.h>
geometry_msgs::Pose2D current_pose;
ros::Publisher pub_pose2d;
void odomCallback(const nav_msgs::OdometryConstPtr& msg)
    // linear position
    current_pose.x = msg->pose.pose.position.x;
    current_pose.y = msg->pose.pose.position.y;
    // quaternion to RPY conversion
    tf::Quaternion q(
        msg->pose.pose.orientation.x,
        msg->pose.pose.orientation.y,
        msg->pose.pose.orientation.z,
        msg->pose.pose.orientation.w);
    tf::Matrix3x3 m(q);
    double roll, pitch, yaw;
    m.getRPY(roll, pitch, yaw);
    // angular position
    current_pose.theta = yaw;
    pub_pose2d.publish(current_pose);
int main(int argc, char **argv)
    const double PI = 3.14159265358979323846;
    ROS_INFO("start");
    ros::init(argc, argv, "move_pub");
    ros::NodeHandle n;
    ros::Subscriber sub_odometry = n.subscribe("odom", 1, odomCallback);
```

```
ros::Publisher movement_pub = n.advertise("cmd_vel",1); //for sensors the value after , sh
ould be higher to get a more accurate result (queued)
   pub_pose2d = n.advertise("turtlebot_pose2d", 1);
   ros::Rate rate(10); //the larger the value, the "smoother" , try value of 1 to see "jerk"
movement
   //move forward
   ROS_INFO("move forward");
   ros::Time start = ros::Time::now();
   while(ros::ok() && current_pose.x < 1.5)</pre>
       geometry msgs::Twist move;
       //velocity controls
       move.linear.x = 0.2; //speed value m/s
       move.angular.z = 0;
       movement_pub.publish(move);
       ros::spinOnce();
       rate.sleep();
    //turn right
   ROS_INFO("turn right");
   ros::Time start_turn = ros::Time::now();
   while(ros::ok() && current_pose.theta > -PI/2)
       geometry_msgs::Twist move;
       //velocity controls
       move.linear.x = 0; //speed value m/s
       move.angular.z = -0.3;
       movement_pub.publish(move);
       ros::spinOnce();
       rate.sleep();
   //move forward again
   ROS_INFO("move forward");
   ros::Time start2 = ros::Time::now();
   while(ros::ok() && current_pose.y > -1.5)
       geometry_msgs::Twist move;
        //velocity controls
       move.linear.x = 0.2; //speed value m/s
       move.angular.z = 0;
       movement_pub.publish(move);
       ros::spinOnce();
       rate.sleep();
   // just stop
   while(ros::ok()) {
       geometry msgs::Twist move;
       move.linear.x = 0;
       move.angular.z = 0;
       movement_pub.publish(move);
       ros::spinOnce();
       rate.sleep();
   }
   return 0;
```


If you want to reproduce my experiment, you can use the Turtlebot 2 public simulation available in RDS (https://rds.theconstructsim.com/). But you can do it in your own computer too, using this robot.

Basically, you have to consider the current position of the robot to have closed loop. The way it's right now, it relays on time and a very good calibration of the robot, what is not recommended if you want to have a node as generic that could be used in different robots and environments.

Don't forget that you have to add in your CMakeLists.txt and package.xml the dependency **nav_msgs** before trying to compile.

Comments

This answer, as it is, limited without the source. Please include the source and information from the post in this answer as links can and do go down/die.



Your Answer

Please start posting anonymously - your entry will be published after you log in or create a new account.

Add Answer	

about \mid faq \mid help \mid privacy policy \mid terms of service \mid give feedback Powered by Askbot version 0.7.58

ROS Answers is licensed under Creative Commons Attribution 3.0 Content on this site is licensed under a Creative Commons Attribution Share Alike 3.0 license.

