ļ

Please ask about problems and questions regarding this tutorial on ● answers.ros.org (http://answers.ros.org). Don't forget to include in your question the link to this page, the versions of your OS & ROS, and also add appropriate tags.

Go to Goal

Description: This tutorial is based on Turtlesim Video Tutorials (/turtlesim/Tutorials)

Tutorial Level: INTERMEDIATE

Contents

- 1. Preparing for work
- 2. Understanding the code
 - 1. The TurtleBot Class
 - 2. The Subscriber
 - 3. The euclidean distance method
 - 4. The PID Controller
 - 5. Tolerance
- 3. The Code
- 4. Testing the code

You can find the complete package at: • https://github.com/clebercoutof/turtlesim_cleaner (https://github.com/clebercoutof/turtlesim_cleaner)

Now we are going to move the turtle to a specified location.

1. Preparing for work

Let's create our file gotogoal.py (or any name you want) and paste it in the source directory of our package: if you followed the past tutorial, it will be: ~/catkin_ws/src/turtlesim_cleaner/src. Then, don't forget to make the node executable:

\$ chmod u+x ~/catkin_ws/src/turtlesim_cleaner/src/gotogoal.py

2. Understanding the code

2.1 The TurtleBot Class

The class TurtleBot will contain all the aspects of our robot, such as pose, the publisher and subscriber, the subscriber callback function and the "move to goal" function.

2.2 The Subscriber

Our subscriber will subscribe to the topic '/turtle1/pose', which is the topic to which the actual turtlesim position is published. The function update_pose is called when a message is received and saves the actual position in a class attribute called pose.

2.3 The euclidean_distance method

This method will use the previously saved turtle position (i.e. self.pose) and the argument (i.e. data) to calculate the point-to-point (Euclidean) distance between the turtle and the goal.

2.4 The PID Controller

In order for our robot to move, we will use a •PID controller (https://en.wikipedia.org/wiki/PID_controller) for linear speed and angular velocity. The linear speed will consist of a constant multiplied by the distance between the turtle and the goal and the angular speed will depend on the arctangent of the distance in the y-axis by the distance in the x-axis multiplied by a constant. You can check the Go to Goal Turtlesim Video Tutorials (/turtlesim/Tutorials) for better explanation.

2.5 Tolerance

We have to create a tolerance zone around our goal point, since a really high precision to get exactly to the goal would be needed. In this code, if we use a really small precision the turtle would go crazy (you can have a try!). In other words, the code and the simulator are simplified, so it won't work with full precision.

3. The Code

Toggle line numbers

	350
	i I

```
1 #!/usr/bin/env python
   2 #!/usr/bin/env python
   3 import rospy
   4 from geometry_msgs.msg import Twist
   5 from turtlesim.msg import Pose
   6 from math import pow, atan2, sqrt
   7
   8
   9 class TurtleBot:
  10
         def __init__(self):
  11
             # Creates a node with name 'turtlebot_controller' and make sure i
  12
t is a
  13
             # unique node (using anonymous=True).
             rospy.init_node('turtlebot_controller', anonymous=True)
  14
  15
             # Publisher which will publish to the topic '/turtle1/cmd_vel'.
  16
  17
             self.velocity_publisher = rospy.Publisher('/turtle1/cmd_vel',
  18
                                                       Twist, queue_size=10)
  19
  20
             # A subscriber to the topic '/turtle1/pose'. self.update_pose is
 called
  21
             # when a message of type Pose is received.
  22
             self.pose_subscriber = rospy.Subscriber('/turtle1/pose',
  23
                                                     Pose, self.update_pose)
  24
  25
             self.pose = Pose()
  26
             self.rate = rospy.Rate(10)
  27
  28
         def update_pose(self, data):
  29
             """Callback function which is called when a new message of type P
ose is
  30
             received by the subscriber."""
  31
             self.pose = data
  32
             self.pose.x = round(self.pose.x, 4)
  33
             self.pose.y = round(self.pose.y, 4)
  34
  35
         def euclidean_distance(self, goal_pose):
  36
             """Euclidean distance between current pose and the goal."""
  37
             return sqrt(pow((goal_pose.x - self.pose.x), 2) +
  38
                         pow((goal_pose.y - self.pose.y), 2))
  39
         def linear_vel(self, goal_pose, constant=1.5):
  40
             """See video: https://www.youtube.com/watch?v=Qh15Nol5htM."""
  41
             return constant * self.euclidean_distance(goal_pose)
  42
  43
  44
         def steering_angle(self, goal_pose):
  45
             """See video: https://www.youtube.com/watch?v=Qh15Nol5htM."""
  46
             return atan2(goal_pose.y - self.pose.y, goal_pose.x -
self.pose.x)
```

```
47
  48
         def angular_vel(self, goal_pose, constant=6):
  49
             """See video: https://www.youtube.com/watch?v=Qh15Nol5htM."""
             return constant * (self.steering_angle(goal_pose) - self.pose.the
  50
ta)
  51
  52
         def move2goal(self):
             """Moves the turtle to the goal."""
  53
  54
             goal_pose = Pose()
  55
             # Get the input from the user.
  56
  57
             goal_pose.x = input("Set your x goal: ")
             goal_pose.y = input("Set your y goal: ")
  58
  59
             # Please, insert a number slightly greater than 0 (e.g. 0.01).
  60
             distance_tolerance = input("Set your tolerance: ")
  61
  62
             vel_msg = Twist()
  63
  64
  65
             while self.euclidean_distance(goal_pose) >= distance_tolerance:
  66
                 # Porportional controller.
  67
                 # https://en.wikipedia.org/wiki/Proportional_control
  68
  69
  70
                 # Linear velocity in the x-axis.
  71
                 vel_msg.linear.x = self.linear_vel(goal_pose)
  72
                 vel_msg.linear.y = 0
  73
                 vel_msg.linear.z = 0
  74
  75
                 # Angular velocity in the z-axis.
  76
                 vel_msg.angular.x = 0
  77
                 vel_msg.angular.y = 0
  78
                 vel_msg.angular.z = self.angular_vel(goal_pose)
  79
  80
                 # Publishing our vel_msg
  81
                 self.velocity_publisher.publish(vel_msg)
  82
  83
                 # Publish at the desired rate.
  84
                 self.rate.sleep()
  85
             # Stopping our robot after the movement is over.
  86
             vel_msg.linear.x = 0
  87
  88
             vel_msg.angular.z = 0
  89
             self.velocity_publisher.publish(vel_msg)
  90
  91
             # If we press control + C, the node will stop.
  92
             rospy.spin()
  93
  94 if __name__ == '__main__':
  95
         try:
  96
             x = TurtleBot()
```

```
97 x.move2goal()
98 except rospy.ROSInterruptException
99 pass
```

First, we import the libraries that will be needed. The rospy and geometry_msgs were discussed in the previous tutorials. The math library contains the function that will be used, such as atan, sqrt and round. The turtlesim.msg contains the Pose message type, which is the one published to the topic '/turtle1/pose'. You can check with the following command:

```
$ rostopic info /turtle1/pose
```

You should see the following screen:

```
~$ rostopic info /turtle1/pose
Type: turtlesim/Pose
Publishers:
* /turtlesim (http://birnuc1:45049/)
Subscribers: None
```

The pose message is composed by the x and y coordinates, the theta angle, linear velocity and angular velocity. You can see this info with the following command:

```
$ rosmsg show turtlesim/Pose
```

You should see the following screen:

```
~$ rosmsg show turtlesim/Pose
float32 x
float32 y
float32 theta
float32 linear_velocity
float32 angular_velocity
```

Then we create our class. In the __init__ method, we initiate the node, publisher, subscriber and the pose object. It's necessary to set a "publishing rate" in this case too:

```
Toggle line numbers
```

```
10
         def __init__(self):
             # Creates a node with name 'turtlebot_controller' and make sure i
 11
t is a
 12
             # unique node (using anonymous=True).
             rospy.init_node('turtlebot_controller', anonymous=True)
 13
 14
 15
             # Publisher which will publish to the topic '/turtle1/cmd vel'.
 16
             self.velocity_publisher = rospy.Publisher('/turtle1/cmd_vel',
 17
                                                       Twist, queue_size=10)
 18
             # A subscriber to the topic '/turtle1/pose'. self.update_pose is
 19
called
 20
             # when a message of type Pose is received.
             self.pose_subscriber = rospy.Subscriber('/turtle1/pose',
 21
 22
                                                     Pose, self.update pose)
 23
             self.pose = Pose()
 24
 25
             self.rate = rospy.Rate(10)
```

The update_pose method is a callback function which will be used by the subscriber: it will get the turtle current pose and save it in the self.pose attribute:

```
Toggle line numbers

27     def update_pose(self, data):
28         """Callback function which is called when a new message of type P
ose is
29          received by the subscriber."""
30          self.pose = data
31          self.pose.x = round(self.pose.x, 4)
32          self.pose.y = round(self.pose.y, 4)
```

The euclidean_distance method will be used to calculate the distance between the previously saved turtle position and the goal position:

The move2goal method will be the one which moves the turtle. First, we create the goal_pose object, which will receive the user's input, and it has the same type as the self.pose object. Then, we declare the vel_msg object, which will be published in '/turtle1/cmd_vel':

```
Toggle line numbers
```

```
51
       def move2goal(self):
           """Moves the turtle to the goal."""
52
53
           goal_pose = Pose()
54
55
           # Get the input from the user.
           goal_pose.x = input("Set your x goal: ")
56
57
           goal_pose.y = input("Set your y goal: ")
58
           # Please, insert a number slightly greater than 0 (e.g. 0.01).
59
           distance_tolerance = input("Set your tolerance: ")
60
61
62
           vel_msg = Twist()
```

In the while loop, we will keep publishing until the distance of the turtle to the goal is less than the distance_tolerance:

```
Toggle line numbers

64 while self.euclidean_distance(goal_pose) >= distance_tolerance:
```

At the end of the loop, we order the turtle to stop:

```
Toggle line numbers

85  # Stopping our robot after the movement is over.

86  vel_msg.linear.x = 0

87  vel_msg.angular.z = 0

88  self.velocity_publisher.publish(vel_msg)
```

The following statement causes the node to publish at the desired rate:

```
Toggle line numbers

82  # Publish at the desired rate.
83  self.rate.sleep()
```

The following statement guarantees that if we press CTRL + C our code will stop:

```
Toggle line numbers

90  # If we press control + C, the node will stop.
91  rospy.spin()
```

Finally, we call our function move2goal after having created an object x of type TurtleBot:

```
Toggle line numbers
```

```
93 if __name__ == '__main__':
94    try:
95         x = TurtleBot()
96         x.move2goal()
97    except rospy.ROSInterruptException
98    pass
```

4. Testing the code

In a **new terminal**, run:

```
$ roscore
```

In a **new terminal**, run:

```
$ rosrun turtlesim_node
```

The turtlesim window will open:




Now, in a new terminal, run our code:

```
$ rosrun turtlesim_cleaner gotogoal.py
```

Just type your inputs and the turtle will move! Here we have an example:

```
rosrun turtlesim_cleaner gotogoal.py
Set your x goal: 1
Set your y goal: 1
Set your tolerance: 0.5
```

The turtle will move like this:



Congratulations! You have finished the tutorials!

Except where otherwise noted, the ROS
wiki is licensed under the

Wiki: turtlesim/T utorials/Go to Goal (last edited 2018-04-06 20:15:54 by nbro (/nbro))

Creative Commons Attribution 3.0
(http://creativecommons.org/licenses/by/3.0/) | Find us on Google+
(https://plus.google.com/113789706402978299308)

Brought to you by: Open Source Robotics Foundation

(http://www.osrfoundation.org)