ROBOTS

SERVICES

CUSTOMERS


COMPANY

CONTACT US

ACCESSORIES STORE

ROS 101: CREATING A PUBLISHER NODE

by Martin Cote | Sep 23, 2014 | Teaching and Learning | 4 comments



In our <u>previous post</u>, we graduated from driving a Husky, to taking on a Grizzly! Now it's time to get down and dirty with what ROS is really made of, nodes! We will first be creating a workspace to work from, then we will write a simple publisher that will make our virtual Husky drive around randomly. If this is your first time visiting a Clearpath Robotics ROS 101 blog, get started <u>here.</u>

Creating a Workspace & Package

Before we begin writing a node, we need to create a workspace and a package. Workspaces are simply directories to store all of your packages. First we will need to create a new directory.

mkdir ~/ros101

This created a directory in your home folder which we will use as a workspace directory. We now need to create a subdirectory in your workspace directory to store all your source code for your packages

mkdir ~/ros101/src

The last step to creating the workspace will be to initialize the workspace with catkin_init_workspace.

cd ~/ros101/src
catkin_init_workspace

Now that our workspace has been created, we will create a package in the src directory we just created. This can be done by navigating to the ~/ros101/src directory, which you should have already done in the last step, and using the catkin_create_pkg command followed by what we want the package to be named, and then followed by what other packages our package will be dependent on; this command creates another directory for your new package, and two new configuration files inside that directory with some default settings.

```
catkin_create_pkg random_husky_driver roscpp std_msgs
```

You can see that this created CMakeLists.txt and package.xml inside the random_husky_driver directory; this is also where you will store all your source code for your packages. The roscpp and std_msgs_dependencies were added into the CMakeList.txt and package.xml.

Writing the publisher

As mentioned in our previous post, a publisher publishes messages to a particular topic. For this tutorial, we will be publishing random commands to the /husky/cmd_vel topic to make your Husky visualization drive itself. Start by creating a file in your ~/ros101/src/random_husky_driver/src directory called random_driver.cpp, and copy the following code.

```
#include <ros/ros.h>
#include <geometry msgs/Twist.h>
#include <stdlib.h>
int main(int argc, char **argv) {
     //Initializes ROS, and sets up a node
     ros::init(argc, argv, "random_husky_commands");
     ros::NodeHandle nh;
     //Ceates the publisher, and tells it to publish
     //to the husky/cmd_vel topic, with a queue size of 100
     ros::Publisher pub=nh.advertise<geometry_msgs::Twist>("husky/cmd_vel", 100);
     //Sets up the random number generator
     srand(time(0));
     //Sets the loop to publish at a rate of 10Hz
     ros::Rate rate(10);
       while(ros::ok()) {
            //Declares the message to be sent
            geometry_msgs::Twist msg;
           //Random x value between -2 and 2
           msg.linear.x=4*double(rand())/double(RAND_MAX)-2;
           //Random y value between -3 and 3
           msg.angular.z=6*double(rand())/double(RAND_MAX)-3;
           //Publish the message
           pub.publish(msg);
          //Delays untill it is time to send another message
          rate.sleep();
```

```
}
```

Let's break down this code line by line,

```
#include <ros/ros.h>
#include <geometry_msgs/Twist.h>
```

These lines includes the headers that we are going to need. The <ros/ros.h> header is required for ROS functionality and the <geometry_msgs/Twist.h> is added so that we can create a message of that type.

```
ros::init(argc, argv, "random_husky_commands");
ros::NodeHandle nh;
```

The first line, ros::init, is used to initialize the ROS node, and name it "random_husky_commands", while ros:NodeHandle starts the node.

```
ros::Publisher pub=nh.advertise<geometry_msgs::Twist>("husky/cmd_vel", 100);
```

Publishing a message is done using ros:Publisher pub=nh.advertise, followed by the message type that we are going to be sending, in this case it is a geometry_msga::Twist, and the topic that we are going to be sending it too, which for us is husky/cmd_vel.

The 100 is the message queue size, that is, if you are publishing message faster then what roscpp can send, 100 messages will be saved in the queue to be sent. The larger the queue, the more delay in robot movement in case of buffering.

Therefore in a real life example, you will want to have a smaller queue in the case of robot movement, where delay in movement commands are undesirable and even dangerous, but dropped messages are acceptable. In the case of sensors, it is recommended to use a larger queue, since delay is acceptable to ensure no data is lost.

```
ros::Rate rate(10)
...
rate.sleep()
```


ROS is able to control the loop frequency using ros:Rate to dictate how rapidly the loop will run in Hz. rate.sleep will delay a variable amount of time such that your loop cycles at the desired frequency. This accounts for time consumed by other parts of the loop. All Clearpath robots require a minimum loop rate of 10Hz.

```
while(ros::ok())
```

The ros::ok function will return true unless it recevis a command to shut down, either by using the rosnode kill command, or by the user pusing Ctrl-C in a terminal.

```
geometry_msgs::Twist msg;
```

This creates the message we are going to send, msg, of the type geometry_msgs:Twist msg.linear.x=4*double(rand())/double(RAND_MAX)-2; msg.angular.z=6*double(rand())/double(RAND_MAX)-3;



These lines calculate the random linear x and angular z values that will be sent to Husky.

pub.publish(msg)

We are finally ready to publish the message! The pub.publish adds msg to the publisher queue to be sent.

Compiling the random Husky driver

Compilation in ROS in handled by the catkin build system. The first step would usually be to set up our package dependencies in the CMakeLists.txt and package.xml. However this has already been done for us when we created the package and specified our dependencies. The next step is then to declare our new node as a executable, this is done by adding the following two lines to the CMakeLists.txt files in ~/ros101/src/random husky driver

add_executable(random_driver src/random_driver.cpp)
target_link_libraries(random_driver \${catkin_LIBRARIES})

The first line creates the executable called random_driver, and directs ROS to it's source files. The second lines specifies what libraries will be used. Now we need to build our workspace using the catkin make command in the workspace directory

cd ~/ros101 catkin make

Let's bring up the husky visualization as we did in a previous blog post.

roslaunch husky_gazebo husky_empty_world.launch

The final step is to source your setup.bash file in the workspace you have created. This script allows ROS to find the packages that are contained in your workspace. **Don't forget this process** will have to be done on every new terminal instance!

source ~/ros101/devel/setup.bash

It's now time to test it out! Make sure you have a instance of roscore running in a separate terminal, then start the node.

rosrun random_husky_driver random_driver

You should now see Husky drive around! In a new terminal window, we can make sure that our node is publishing to the /husky/cmd_vel topic by echoing all messages on this topic

rostopic echo /husky/cmd_vel

```
linear:
    x: -0.988633466414
    y: 0.0
    z: 0.0
    angular:
    x: 0.0
    y: 0.0
    z: -1.2239688644
---
linear:
    x: -1.66241614919
    y: 0.0
    z: 0.0
    angular:
    x: 0.0
    y: 0.0
    z: 1.11694186093
---
linear:
    x: 0.497968052746
    y: 0.0
    z: 0.0
    angular:
    x: 0.0
    y: 0.0
    z: 0.237037784065
---
linear:
    x: 1.92314065267
    y: 0.0
    z: 0.0
    angular:
    x: 0.0
    y: 0.0
    z: 0.0
```

You should now see a stream of random linear x and angular z values.

Looking for other Clearpath tutorials? <u>Click here</u> for more ROS tutorials, or visit our <u>Knowledge Base</u> to browse all of our tutorials.



RELATED POSTS

ROBOTS 101 – LASERS HOW TO: UNPACK GRIZZLY ROBOTIC UTILITY VEHICLE WEBINAR RECORDING: TRANSFORM YOUR **HOLIDAY HACK DAY**

4 COMMENTS



Mark Jones on January 12, 2016 at 3:00 pm

Hey, great tutorials.

Just a note with the line "add_executable(random_driver random_driver.cpp)", it should be "add_executable(random_driver src/random_driver.cpp)".

Cheers

REPLY



Chris Bogdon on February 17, 2016 at 1:45 pm

Thanks Mark! And good catch. I've updated the tutorial with the correct line.

REPLY



S. Usama on March 22, 2016 at 4:39 pm

Really helpful.

After that, I tried to use a node to subscribe some data and then publish it to some other topic. I mean I want to use same node for publishing and subscribing. Can you help me with an example?

REPLY



Chris Bogdon on March 24, 2016 at 1:15 pm

Hi S. Usama. Check out our Subscriber tutorial here:
http://clearpathrobotics.com/guides/ros/Creating%20subscriber.html
Hope this helps! You can find all of our ROS tutorials at http://www.clearpathrobotics.com/guides/ros

REPLY

Trackbacks/Pingbacks

1. <u>ROS101: Creating a Subscriber Using GitHub</u> - [...] previously learned how to write a publisher node to move Husky randomly. BUT! What good is publishing all these messages...

SEARCH

Categories

Culture & Community

In the Field: Customer Spotlight

In the News

Robot Forge

ROS Spotlight

Teaching and Learning

Tradeshows & Conferences

Recent Posts

SIT Advances Autonomous Navigation Research Using Jackal UGV

Clearpath Robotics Attends ROSCon & iROS 2017

MIT Develops Autonomous "Socially Aware" Robot Using Jackal UGV

From Books to Bots: 2017 Summer Term Co-op

Clearpath Presents Jorge Cham and More at iROS 2017

SUBSCRIBE TO UPDATES

EMAIL*		

SUBMIT

Search...

ROBOTS **SERVICES** CUSTOMERS SUPPORT CENTRE COMPANY WARTHOG UGV COMPETENCIES CUSTOMER STORIESKNOWLEDGE BASEOUR STORY HUSKY UGV RESEARCH SERVICES SUBMITTICKET OUR TEAM INDUSTRIAL SERVICES JACKAL UGV ROS COMMUNITY CAREERS OTTO 1500 PR2 SUPPORT BLOG RIDGEBACK PR2 RESOURCES NEWS

TURTLEBOT EUCLID TUTORIALS PRESS INQUIRIES

TURTLEBOT 2 CONTACT US

HUMMINGBIRD UAV Clearpath Robotics Inc.

PELICAN UAV 1425 Strasburg Rd. Suite 2A HERON USV Kitchener, On N2R 1H2

ACCESSORIES

1 800 301 3863

info@clearpathrobotics.com

TALK TO A HUMAN

