

Chapter7 Engine Base System




Engine Proper System

Piston Parts

1. Piston Crown (Head)
2. Piston Skirt
3. Ring Lands
4. Compression Ring
5. Wiper Ring
6. Oil Control Ring
7. Ring Grooves
8. Piston Pin / Wrist Pin
9. Pin Boss
10. Piston Cooling Holes
11. Piston Dishing
12. Piston Center Mark
13. Connecting Rod Boss
14. Piston Oil Passages
15. Piston Land Gap
16. Small End Bearing
17. Big End Bearing
18. Connecting Rod
19. Connecting Rod Cap
20. Plunger



Piston Chapter6_Engine_Base_System >
Crown Engine_Proper_System >
(Head) Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)




Piston Chapter6_Engine_Base_System >
Skirt Engine_Proper_System > Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)



Ring Chapter6_Engine_Base_System >
Lands Engine_Proper_System > Piston_Parts


[View pictures ↗](#) [↻ Reload pictures](#)



Compression Ring

Chapter6_Engine_Base_System
> Engine_Proper_System >
Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)



Wiper Ring

Chapter6_Engine_Base_System >
Engine_Proper_System > Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)





Oil Control Ring

Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts

View pictures ↗

↻ Reload pictures






Ring Grooves

Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts

View pictures ↗

↻ Reload pictures



Piston Pin / Wrist Pin


Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts

View pictures ↗

↻ Reload pictures



Pin Chapter6_Engine_Base_System >
Boss Engine_Proper_System > Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)



Piston Chapter6_Engine_Base_System >
Cooling Engine_Proper_System >
Holes Piston_Parts


[View pictures ↗](#) [↻ Reload pictures](#)



Piston Chapter6_Engine_Base_System >

Dishing Engine_Proper_System > Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)




Piston Chapter6_Engine_Base_System >

Center Engine_Proper_System >

Mark Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)



Connecting Rod Boss

Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts



[View pictures ↗](#) [↻ Reload pictures](#)



Piston Oil Passages



Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)




Piston Chapter6_Engine_Base_System >
Land Engine_Proper_System >
Gap Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)



Small Chapter6_Engine_Base_System >
End Engine_Proper_System >
Bearing Piston_Parts




[View pictures ↗](#) [↻ Reload pictures](#)



Big End Bearing

Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)



Connecting Rod

Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts


[View pictures ↗](#) [↻ Reload pictures](#)



Connecting Rod Cap

Chapter6_Engine_Base_System >
Engine_Proper_System >
Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)



Plunger

Chapter6_Engine_Base_System >
Engine_Proper_System > Piston_Parts

[View pictures ↗](#) [↻ Reload pictures](#)

