
## SYNTHIMM



## **Assembly Instructions**

*Indoor Positioning System (E-39)* 

## Parts & Tools


#	Qty	Name
1	1	E-39 Indoor Positioning System
2	1	Visible Spectrum Camera
3	1	Infrared Camera
4	1	Tweezers




\*IMPORTANT\* Ensure the first camera you install in the top FPC connector has a black dot on the flex pcb. This is the Visible Spectrum camera.





**Step 1.** Open the black portion of the FPC connectors. Use Tweezers if needed.







**Step 2.** Insert the Visible Spectrum Camera into the top FPC connector until it is seated complete flat against the bottom of the FPC connector.







**Step 3.** Close the black portion of the FPC connector with tweezers.






**Step 4.** Use tweezers to remove the paper from the back of the Visible Spectrum Camera.







**Step 5.** Push the Visible Spectrum Camera down against the PCB to stick it in place.






**Step 6.** Insert the Infrared Camera into the bottom FPC connector until it is seated complete flat against the bottom of the FPC connector.







**Step 7.** Close the black portion of the FPC connector with tweezers.





**Step 8.** Use tweezers to remove the paper from the back of the Infrared Camera.





**Step 9.** Push the Infrared Camera down against the PCB to stick it in place. The Indoor Position System is complete.