## 2dof 支架安装文档/2 dof bracket installation manual

1.多功能支架 先装舵盘 拧上4颗M3\*6mm螺丝Multi-function bracket, first install the steering wheel, and lock it with 4pcs M3\*6mm screws.





2.长 U 支架,一边装上舵盘,另一边套轴承和螺丝 Long U bracket, install the steering wheel on one side and the bearing and screw on the another side.









3.套上多功能支架,用螺母锁住 2 个支架 Put on the multi-functional bracket and lock the two brackets with nuts.



4.舵机 4 个角上套上橡胶螺母 Put rubber nuts on the 4 corners of the steering gear.





5.舵机放进多功能支架,用螺母锁住 Put the steering gear into the multi-function bracket and lock it with a nut.





6.长 U 支架装舵盘的一边套上黑色螺丝 Put a black screw on one side of the long U bracket steering wheel.



7.最后装上第二个舵机。 Finally install the second steering gear.

