Getting Started with Zynq



Overview

This guide will provide a step by step walk-through of creating a hardware design using the Vivado IP Integrator for the Zybo board.

At the end of this tutorial you will have:

- Created a simple hardware design incorporating the on board LEDs and switches.
- Created a .C project in XIlinx Vivado SDK tieing the on board LEDs and switches together using the hardware design shown in the previous step.

Prerequisites

Hardware

• Digilent's Zybo Development Board and a Micro USB cable for UART communication and JTAG programming

Software

• Xilinx Vivado 2015.X with the SDK package.

Board Support Files

- · Zybo Support Files
 - These files will describe <u>GPIO ()</u> interfaces on your board and make it easier to select your board in the initial design setup and add <u>GPIO ()</u> IP blocks in the block design
 - Follow this Wiki guide <u>Vivado Board Files for Digilent 7-Series FPGA Boards</u>
 (https://reference.digilentinc.com/vivado/boardfiles) on how to install Board Support Files for Vivado 2015.X

Tutorial

General Design Flow

I. Vivado

- · Open Vivado and select Zybo board
- Create an new Vivado Project
- · Create empty block design workspace inside the new project
- Add required IP blocks using the IP integrator tool and build Hardware Design

- Validate and save block design
- Create HDL system wrapper
- Run design Synthesis and Implementation
- Generate Bit File
- · Export Hardware Design including the generated bit stream file to SDK tool
- Launch SDK

Now the Hardware design is exported to the SDK tool. The Vivado to SDK hand-off is done internally through Vivado. We will use SDK to create a Software application that will use the customized board interface data and FPGA hardware configuration by importing the hardware design information from Vivado.


II. SDK

- Create new application project and select default Hello World template
- Program FPGA and run application


1. Creating a New Project

When you first run Vivado this will be the main start window where you can create a new project or open a recent one.


1.1) Click on Create New Project.




1.2) You will be presented with the project creation wizard. Click **Next**.




1.3) Enter a project name and location the click Next.




1.4) Select **RTL Project** and click **Next**.



1.5) This demo does not use any existing sources, existing IP or constraints. Click through the next three screens.




1.6) Select **Boards** and select the **Zybo** board file. Click **Next** and then **Finish**.




2. Creating a New Block Design

2.1) Once the process has completed, click **Create Block Design** in the flow navigator.




2.2) Click **OK**.




3. Add the Zynq IP & GPIO Blocks

3.1) Click the **P** Add IP button and search for ZYNQ. Double click on **ZYNQ7 Processing System** to place the bare Zynq block.





3.2) Click the Run Block Automation link




Your Zynq block should now look like the picture below.

3.3) Click the **!** Add IP icon again, this time search for "gpio" and add the AXI **GPIO** () core.






3.4) Double-click on new **axi_gpio_0** core that was just added to bring up the customizing window. Under the **IP Configuration** tab check the **Enable Dual Channel** box. Click **OK**.




3.5) Add another GPIO () core by repeating step 3.3 but do not enable dual channel.




4. Run the Connection Automation Tool


4.1) The connection automation tool will add the required logic blocks for the demo. Select **Run Connection Automation** highlighted in blue.




4.2) Check the box by **All Automation**. Select **GPIO ()** under **axi_gpio_0** and select **btns_4bits** in the Board Part Interface drop-down box.




4.3) Select **GPIO2** under **axi_gpio_0** and select **swts_4bits** in the drop-down box.




4.4) Select **GPIO**() under **axi_gpio_1** and select **leds_4bits** in the drop-down box and hit **OK**.



- 4.5) This process will add:
 - * The AXI interconnect
 - * Processor System Reset
 - * The board parts for the buttons, switches and LEDs.




4.6) Next let's clean up our Block Design. Click the 龙 **Regenerate Layout** button to rearrange your block design.



5. Generate HDL Wrapper and Validate Design

5.1) Select **Validate Design**. This will check for design and connection errors.


5.2) After the design validation step we will proceed with creating a HDL System Wrapper. In the block design window, under the **Design Sources** tab, right-click on the block diagram file. We labeled it "design_1.bd" and select **Create HDL Wrapper**.



This will create a top module in VHDL and will allow you to generate a bitstream.


6. Generate the Bitstream

6.1) Click on **Generate Bitstream** at the bottom of the Flow Navigator. Wait for the process to complete and click OK.




7. Export hardware files for SDK

7.1) Go to file \rightarrow Export \rightarrow Export Hardware... Make sure to check the box for **Include bitstream** then click **OK**.




8. Launch SDK


8.1) Go to **File** → **Launch SDK** and click **OK**.



9. Create a new Hello World Application Project in SDK


9.1) Go to File \rightarrow New \rightarrow Application Project.





9.3) The Hello World demo is a good starting point for this demo. Click Next, select Hello World and click Finish. This process will add two directories to the project explorer.

9.4) Expand **getting_started_with_ZYBO** then open **src** and double click on "helloworld.c". This is the default Hello World C code.



10. Creating Our Own Hello World

10.1) Copy and paste the code below into the helloworld.c file.

```
Getting Started Guide for Zybo
This demo displays the status of the switches on the
LEDs and prints a message to the serial communication
when a button is pressed.
Terminal Settings:
  -Baud: 115200
  -Data bits: 8
  -Parity: no
  -Stop bits: 1
1/6/14: Created by MarshallW
#include <stdio.h>
#include "platform.h"
#include <xgpio.h>
#include "xparameters.h"
#include "sleep.h"
int main()
  XGpio input, output;
  int button data = 0;
  int switch_data = 0;
  XGpio_Initialize(&input, XPAR_AXI_GPIO_0_DEVICE_ID); //initialize input XGpio variable
  XGpio Initialize(&output, XPAR AXI GPIO 1 DEVICE ID); //initialize output XGpio variable
  XGpio_SetDataDirection(&input, 1, 0xF);
                                                          //set first channel tristate buffer
  XGpio SetDataDirection(&input, 2, 0xF);
                                                           //set second channel tristate buffer
                                                 //set first channel tristate buffer to outpu
  XGpio SetDataDirection(&output, 1, 0x0);
  init_platform();
  while(1){
     switch_data = XGpio_DiscreteRead(&input, 2);  //get switch data
                                                   //write switch data to the LEDs
     XGpio_DiscreteWrite(&output, 1, switch_data);
     button data = XGpio DiscreteRead(&input, 1);  //get button data
     //print message dependent on whether one or more buttons are pressed
     if(button_data == 0b0000){} //do nothing
     else if(button_data == 0b0001)
        xil printf("button 0 pressed\n\r");
     else if(button data == 0b0010)
        xil printf("button 1 pressed\n\r");
     else if(button data == 0b0100)
        xil printf("button 2 pressed\n\r");
     else if(button data == 0b1000)
        xil printf("button 3 pressed\n\r");
```

```
else
    xil_printf("multiple buttons pressed\n\r");

usleep(200000);    //delay

}
cleanup_platform();
return 0;
}
```


11. Run the Project

11.1) Make sure that the Zybo is connected to the host PC via the **UART** USB Port and that JP5 is set to JTAG. To program the FPGA, on the top toolbar, click the **Program** FPGA button.




 $(https://reference.digilentinc.com/_media/learn/programmable-logic/tutorials/zybo-getting-started-with-zynq-server/echo_server_zynq_9.jpg)$

- 11.2) Save the project. The project will automatically build.
- 11.3) Right click the **getting_started_with_ZYBO** directory and select run as → Launch on Hardware(System Debugger).



(https://reference.digilentinc.com/_media/learn/programmable-logic/tutorials/zybo-getting-started-with-zynq-server/echo_server_zynq_13.jpg) 11.4) The demo will be running on the ZYBO. Try playing around with the 4 switches (labeled SW0-SW3). Doing so should light its respective <u>LED_()</u>. Also over the serial port, pressing each button (labeled BTN0-BTN3) will produce the message "button x pressed".

11.5) Tera Term or any serial terminal will work as a Console for displaying the output of the BTN's. Set up the terminal as:



(https://reference.digilentinc.com/_media/learn/programmable-logic/tutorials/zybo-getting-started-with-zynq-server/echo_server_zynq_10.jpg)

Our Partners Help Customer Info Company Info

- Xilinx University Technical Support
 Program Forum
 (https://store.digilentinc.com/partners(xillpxx//forum.digilentinc.com)
 university-program/)
- Videos

 About Us
 (https://youtube.com/user/digilentinc)(https://store.digilentinc.com/j
- FAQ pageid=26) (https://resource.digilentinc.com/verify/faq)

- Technology Partners • Reference Wiki (https://store.digilentinc.com/technologytps://reference.digilentinc.com) Contact Us partners/)
- Distributors (https://store.digilentinc.com/ourdistributors/)
- - (https://store.digilentinc.com/contactus/)
- Store Info (https://store.digilentinc.com/storeinfo/)
- Shipping & Returns (https://store.digilentinc.com/s returns/)
 - Legal (https://store.digilentinc.com/l
 - Jobs (https://store.digilentinc.com/j
 - Internships (https://store.digilentinc.com/i

Connect With Us



(https://twitter.com/digilentinc)



(https://www.facebook.com/Digilent)



(https://www.youtube.com/user/DigilentInc)



(https://instagram.com/digilentinc)




(https://github.com/digilent)



(https://www.reddit.com/r/digilent)



(https://www.linkedin.com/company/1454013)



• (https://www.flickr.com/photos/127815101@N07)