洲江水学

本科实验报告

课程名称: 计算机网络基础

实验名称: 使用二层交换机组网

姓 名: 解雲暄

学院: 计算机学院

专业: 信息安全

学 号: 3190105871

指导教师: 郑扣根

2021年11月16日

浙江大学实验报告

实验名称:	使用二层交换机组网	实验类型:_	操作实验
同组学生:		实验地点:	计算机网络实验室

一、实验目的

- 1. 掌握交换机的工作原理、管理配置方法;
- 2. 掌握 VLAN 的工作原理、配置方法;
- 3. 掌握跨交换机的 VLAN Trunk 配置方法;
- 4. 掌握多个交换机的冗余组网、负载平衡的配置方法。

二、实验内容

- 使用网线连接 PC, 让 PC 彼此能够互相 Ping 通;
- 配置和管理交换机:使用 Console 线连接交换机,运行 Putty 等终端软件,对交换机进行配置;
- 通过 Telnet 远程管理交换机;
- 配置镜像端口,用 Wireshark 软件抓取交换机各端口的数据;
- 配置 VLAN Access 端口和 VLAN Trunk 端口;
- 配置交换机的冗余备份:
- 配置交换机的负载均衡。

三、 主要仪器设备

PC 机、路由器、交换机、Console 连接线、直联网络线、交叉网络线。

四、操作方法与实验步骤

IOS 软件的基本操作:

- 1. 进入特权模式: enable; 该模式下才能查看重要信息,并可进入配置模式;
- 2. 进入配置模式: configure terminal; 在这个模式下才可以修改配置;
- 3. 进入到某个接口的配置模式: interface 接口名 模块号/端口号, 例如 interface ethernet 0/1;
- 4. 命令可以不输全,只要能够被唯一识别;

- 5. 输入? 可以显示当前上下文环境下可用命令:
- 6. 在命令后面输入? 可以显示命令的参数提示;
- 7. 输入命令的前一部分,再按〈tab〉,可以自动完成完整的命令输入;
- 8. 按上箭头可以重复输入上次打过的命令;
- 9. 鼠标左键选择需要截取的文本内容, 鼠标右键粘贴复制好的文本的内容。

Part 1. 单交换机

- 1. 用 1 台二层交换机和 4 台 PC 组成一个小型局域网
 - a) 使用直联网络线,将每个 PC 机都连接到交换机的不同端口;
 - b) 使用 Console 线,连接到交换机的 Console 端口和控制台 PC 的串口,并在控制台 PC 上运行 Putty 等终端软件;
 - c) 观察交换机的每个端口状态指示,确认 PC 机都正确连接到了交换机的端口;
 - d) 查看当前哪些端口已连接,哪些端口未连接,连接的速率和模式,收发统计;
 - e) 在控制台输入命令查看当前设置了哪些 VLAN,缺省所有的端口都属于同一个 VLAN 1,如果有端口属于非默认 VLAN,输入命令取消该 VLAN;
 - f) 在每个 PC 机上互相用 Ping 来测试连通性,验证局域网已经建立;
 - g) 手工关闭某个端口,然后查看端口关闭后的效果,在对应的 PC 机上使用 Ping 测试连通性;
 - h) 给交换机配置一个 IP 地址,并在交换机上用 Ping 命令测试与 PC 间的连通性;
 - i) 在非控制台 PC 机上,通过 telnet 连接交换机,进行远程配置。

2. 设置交换机的镜像端口

- a) 确定某个 PC (假设为 PC1) 连接的端口为镜像端口;
- b) 在该 PC 机上运行包捕获软件, 抓取数据包;
- c) 在其他 2 个 PC 机上运行 Ping, 互相测试彼此的连通性;
- d) 查看是否能抓取到其他 2 个 PC 机之间的 Ping 响应包,正常情况下,由于交换 机是根据 MAC 地址直接转发的,所以 PC1 是收不到其他 PC 之间的响应包;
- e) 在交换机上将连接 PC1 的端口配置为镜像端口,被镜像的端口分别为另外 2 个 PC 连接的端口:
- f) 在 PC1 上再次启动包捕获软件, 抓取数据包:
- g) 在其他 PC 机上运行 Ping,测试彼此的连通性;

- h) 查看是否能抓取到其他 2 个 PC 机之间的 Ping 响应包。镜像端口设置后,交换 机将把被镜像的源端口收发数据复制一份给镜像目的端口。同时该端口的正常 收发功能关闭。
- 3. 在交换机上设置 VLAN
 - a) 输入命令, 在交换机上增加 1 个新的 VLAN;
 - b) 将 PC3 和 PC4 加入新的 VLAN;
 - c) 通过 PING 验证 PC 之间的连通性;
- 4. 如果交换机上有密码,请按照下面的步骤清除密码:
 - a) 用控制线连接 PC 和交换机的 Console 口, PC 上运行 Putty 软件;
 - b) 断开交换机电源,然后按住交换机的 mode 键不放,重新打开交换机电源,直到 mode 灯闪烁十秒左右后再放开 mode 键:
 - c) 在 Putty 软件上观察交换机启动过程,直到出现 Switch: 的提示符;
 - d) 输入 dir flash:查看是否存在 config. text 文件,如果不能列出目录,输入命令 flash_init,待 flash 加载成功后再输入命令 rename flash:config. text flash:configX. text 将配置文件改名:
 - e) 输入命令 reload 或 reset 重新启动。


Part 2. 多交换机

- 1. 用 2 台交换设备和 4 台 PC 组成一个小型局域网,每个交换机都连接 2 台 PC 机;
- 2. 在交换机上都设置 2 个 VLAN,将每个交换机上的 PC 都分成 2 组,各属于 1 个 VLAN;
- 3. 将两个交换机连起来,设置互联端口为 VLAN Trunk 模式,并测试同一组 VLAN 跨交换机的联通性;普通模式的端口只允许一个 VLAN 的数据通过, VLAN Trunk 模式允许 多个 VLAN 数据同时通过一个端口。
- 4. 用 2 条网线连接 2 个交换机,验证 Spanning-tree 的作用。交换机之间自动会运行 Spanning-tree 协议,避免产生转发回路。如果关闭 Spanning-tree,存在物理回路 的网络很容易产生广播风暴,从而导致网络瘫痪。
- 5. Spanning-tree 是按照 VLAN 进行管理的,不同 VLAN 的 Spanning-tree 可以有不同的设置,因此,可以利用这点实现在两个交换机上的负载平衡。测试 2条网线均连接时,数据是否从 2条网线分别传送,而当 1条网线断开时,数据是否全部改从另外 1条网线和传送。

五、 实验数据记录和处理

----- Part 1 -----

1. 在实验拓扑图上标记交换机的 IP 地址、PC 的 IP 地址及所属 VLAN、交换机的与 PC 的连接端口)



(交换机的 IP 地址是 192.168.0.10)

2. 找一台有串口的 PC 机和一根串口控制线,将控制线的一头连接交换机的 Console 口,另一头连接 PC 机的串口。

在 PC 机上运行 Putty 软件,选择 Serial 方式,默认为 9600, COM1。按两下回车,检查是否已经连上交换机。并输入 enable 命令进入到特权模式。如果有密码,请参考第四章的第 4 小节进行密码清除。

进行 switch 的配置:


- (1) enable 进入特权模式
- (2) configure terminal 进入全局配置模式



do show version 查看型号信息:

IOS Command Line Interface

Switch(config) #do show version Cisco IOS Software, C2960 Software (C2960-LANBASEK9-M), Version 15.0(2)SE4, RELEASE SOFTWARE (fcl) Technical Support: http://www.cisco.com/techsupport Copyright (c) 1986-2013 by Cisco Systems, Inc. Compiled Wed 26-Jun-13 02:49 by mnguyen ROM: Bootstrap program is C2960 boot loader BOOTLDR: C2960 Boot Loader (C2960-HBOOT-M) Version 12.2(25r) FX, RELEASE SOFTWARE (fc4) Switch uptime is 39 minutes System returned to ROM by power-on System image file is "flash:c2960-lanbasek9-mz.150-2.SE4.bin" This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately. A summary of U.S. laws governing Cisco cryptographic products may be found http://www.cisco.com/wwl/export/crypto/tool/stqrg.html



设备型号: <u>WS-C2960-24TT-L</u>, IOS 软件版本: <u>15.0(2)SE4</u>, 软件映像文件名: <u>C2960-LANBASEK9-M</u>, 端口数量: <u>24</u>。

3. 输入命令 show flash: 查看当前文件系统的内容:

```
Switch#dir flash
Directory of flash:/


1 -rw- 4670455 <no date> 2960-lanbasek9-mz.150-2.SE4.bin
64016384 bytes total (59345929 bytes free)
```

4. 显示交换机的 VLAN 数据(命令 show vlan),所有的端口应该都属于 VLAN 1。(如果存在其他 VLAN,先通过命令 no vlan id 删除)


VLAN	Name				Star	tus Po	orts			
1	defaul	Lt			act:	F; F; F;	a0/5, 1 a0/9, 1 a0/13, a0/17, a0/21,	Fa0/2, Fa0/6, Fa0/6, Fa0/10, Fa0/14, I Fa0/18, I Fa0/22, I Gig0/2	0/7, Fa(a0/11, 1 a0/15, a0/19,	0/8 Fa0/12 Fa0/16 Fa0/20
1002	fddi-	default			act:	ive				
1003	token-	-ring-defau	lt		act:	ive				
1004	fddine	et-default			act:	ive				
1005	trnet-	-default			act:	ive				
VLAN	Type	SAID	MTU	Parent	RingNo	BridgeN	Stp	BrdgMode	Transl	Trans2
1	enet	100001	1500	_	_	_	_	_	0	0
1002	fddi	101002	1500	-	-	-	_	_	0	0
1003	tr	101003	1500	-	-	-	-	_	0	0
1004	fdnet	101004	1500	-	-	-	ieee	-	0	0
1005	trnet	101005	1500	-	-	-	ibm	-	0	0
Mo	ore									

5. 用直连网线(straight through)将 PC 按照前述拓扑结构连接到交换机。然后给各 PC 配置 IP 地址,并用 Ping 检查各 PC 之间的联通性,确保都能 Ping 通,否则请检查 网线连接。

配置 IP 地址:



Ping 一例:



手工关闭某端口(命令: shutdown),输入命令查看该端口状态(命令: show interface 端口号,如 show interface e0/1),在其他 PC 上使用 Ping 命令检测连接在该端口的 PC 是否能够联通。

关闭端口:

```
Switch(config) #int FastEthernet 0/1
Switch(config-if) #shutdown


Switch(config-if) #
%LINK-5-CHANGED: Interface FastEthernet0/1, changed state to administratively down

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/1, changed state to down
```

查看端口状态:

```
Switch(config) #do show interface fa0/1
FastEthernet0/1 is administratively down, line protocol is down (disabled)
 Hardware is Lance, address is 0002.162c.b601 (bia 0002.162c.b601)
BW 100000 Kbit, DLY 1000 usec,
    reliability 255/255, txload 1/255, rxload 1/255
 Encapsulation ARPA, loopback not set
 Keepalive set (10 sec)
 Full-duplex, 100Mb/s
 input flow-control is off, output flow-control is off
 ARP type: ARPA, ARP Timeout 04:00:00
 Last input 00:00:08, output 00:00:05, output hang never
 Last clearing of "show interface" counters never
 Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
 Queueing strategy: fifo
 Output queue :0/40 (size/max)
 5 minute input rate 0 bits/sec, 0 packets/sec
 5 minute output rate 0 bits/sec, 0 packets/sec
    956 packets input, 193351 bytes, 0 no buffer
    Received 956 broadcasts, 0 runts, 0 giants, 0 throttles
     0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
     0 watchdog, 0 multicast, 0 pause input
     0 input packets with dribble condition detected
     2357 packets output, 263570 bytes, 0 underruns
 --More--
```

尝试 Ping 该端口上的机器,发现 Ping 不通:




6. 重新打开该端口(命令: no shutdown),输入命令查看交换机上端口状态。使用 Ping 命令检测连接在该端口的 PC 是否能够联通。

打开端口,查看端口状态:

```
Switch(config)#int FastEthernet 0/1
Switch (config-if) #no shutdown
Switch (config-if) #
%LINK-5-CHANGED: Interface FastEthernet0/1, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/1, changed
Switch(config-if) #do show inter
Switch(config-if #do show interface fa0/l
FastEthernet0/1 is up, line protocol is up (connected)
  Hardware is Lance, address is 0002.162c.b601 (bia 0002.162c.b601)
BW 100000 Kbit, DLY 1000 usec,
     reliability 255/255, txload 1/255, rxload 1/255
 Encapsulation ARPA, loopback not set
 Keepalive set (10 sec)
 Full-duplex, 100Mb/s
  input flow-control is off, output flow-control is off
 ARP type: ARPA, ARP Timeout 04:00:00
 Last input 00:00:08, output 00:00:05, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue :0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
```

尝试 Ping 该端口上的机器,发现可以 Ping 通:



7. 进入 VLAN1 接口配置模式(命令: interface vlan 1),给 VLAN 1 配置 IP 地址即是 给交换机配置管理 IP 地址(命令: ip address 地址 掩码)。测试 PC 是否能 Ping 通 交换机的 IP 地址;如果不通,查看 VLAN 1端口的状态是否是 up,如果不是,则打开 VLAN 端口(no shutdown)。

输入的命令:

```
Switch(config) #interface vlan 1
Switch(config-if) #ip address 192.168.0.10 255.255.255.0
Switch(config) #int Vlan 1
Switch(config-if) #no shutdown
Switch(config-if)#
%LINK-5-CHANGED: Interface Vlan1, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan1, changed state to up
C:\>ping 192.168.0.10
Pinging 192.168.0.10 with 32 bytes of data:
Reply from 192.168.0.10: bytes=32 time<1ms TTL=255
Ping statistics for 192.168.0.10:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
   Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

8. 输入以下命令: 打开虚拟终端(命令 line vty 0 4), 允许远程登录(命令: login), 设置登密码(命令: password 密码)

```
Switch(config) #line vty 0 4
Switch(config-line) # login
% Login disabled on line 1, until 'password' is set
% Login disabled on line 2, until 'password' is set
% Login disabled on line 3, until 'password' is set
% Login disabled on line 4, until 'password' is set
% Login disabled on line 5, until 'password' is set
Switch(config-line) # password 3190105871
```

9. 在 PC 上运行 Putty 软件,选择 telnet 协议,输入交换机的 IP 地址,通过网络远程连接交换机,并输入密码。

没有 Putty, 直接 telnet 就行了:


```
C:\>telnet 192.168.0.10
Trying 192.168.0.10 ...Open

User Access Verification


Password:
Switch>
```

10. 在 PC1 上运行 Wireshark,在另外 2 台(PC2、PC3)上互相持续的 Ping(运行"ping IP 地址-t"),观察在 PC1 上是否能抓取到 PC2 和 PC3 发出的 ARP 广播包以及 ICMP 响应包。如果不能抓取到 PC2、PC3 发送的 ARP 广播包,在 PC2、PC3 上先运行"arp —d*"删除所有主机的 ARP 缓存。正常情况下,ICMP 响应包是不能被抓取到的。

抓包截图:



以太网帧中的源地址与发送方的 MAC 地址一致。




11. 选择一个交换机端口配置为镜像端口(命令: monitor session 1 destination interface 端口),将 PC1 的网线切换到该端口,将 PC2 和 PC3 所连端口配置为被镜像端口(命令: monitor session 1 source interface 端口)。继续运行 Wireshark,观察在 PC1 上是否能抓取到 PC2 和 PC3 的 ICMP 响应包。

输入的命令:

```
Switch#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config) #monitor session 1 destination interface fa0/3
Switch(config) #monitor session 1 source interface fa0/1
Switch(config) #monitor session 1 source interface fa0/2
Switch (config) #do show monitor
Session 1
Type
                       : Local Session
Description
Source Ports
                       : Fa0/1,Fa0/2
   Both
Destination Ports
                       : Fa0/3
   Encapsulation
                      : Native
          Ingress
                       : Disabled
```

抓包截图:



12. 关闭 PC1 端口的镜像功能(命令: no monitor session 1 destination interface 端口), 否则该端口不能正常收发数据。

输入的命令:

Switch(config) #no monitor session 1 destination interface fa0/3


13. 在交换机上增加 VLAN 2(命令: vlan database 或 config terminal, vlan 2), 将 PC3、 PC4 所连端口加入到 VLAN 2(命令: interface 端口, switchport access vlan 2)。用 Ping 检查 PC 之间的联通性(同一 VLAN 的 PC 之间能够通,不同 VLAN 的 PC 之间不能通)。

输入的命令:


```
Switch(config) #vlan 2
Switch(config-vlan)#interface Fa0/3
Switch(config-if) #switchport access vlan 2
Switch (config-if) #exit
Switch(config) #vlan 2
Switch(config-vlan)#interface Fa0/4
Switch(config-if) #switchport access vlan 2
Switch(config-if) #do show vlan
VLAN Name
----
   default
                                        active Fa0/1, Fa0/2, Fa0/5, Fa0/6
                                                   Fa0/7, Fa0/8, Fa0/9, Fa0/10
Fa0/11, Fa0/12, Fa0/13, Fa0/14
                                                   Fa0/15, Fa0/16, Fa0/17, Fa0/18
                                                   Fa0/19, Fa0/20, Fa0/21, Fa0/22
Fa0/23, Fa0/24, Gig0/1, Gig0/2
    VLAN0002
                                                  Fa0/3, Fa0/4
                                        active
1002 fddi-default
                                       active
1003 token-ring-default
                                        active
1004 fddinet-default
                                       active
1005 trnet-default
                                        active
```

联通性检测截图:

$PC1 \rightarrow PC2$



$PC1 \rightarrow PC3$



PC4→PC2

192.168.0.7/24

```
Physical Config Desktop Programming Attributes

Command Prompt

C:\>ping 192.168.0.5

Pinging 192.168.0.5 with 32 bytes of data:

Request timed out.
Request timed out.
Request timed out.
Request timed out.
Ping statistics for 192.168.0.5:
Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
```

PC4→PC3

192.168.0.7/24

```
Command Prompt

C:\>ping 192.168.0.6

Pinging 192.168.0.6 with 32 bytes of data:

Reply from 192.168.0.6: bytes=32 time=llms TTL=128
Reply from 192.168.0.6: bytes=32 time=5ms TTL=128
Reply from 192.168.0.6: bytes=32 time<5ms TTL=128
Reply from 192.168.0.6: bytes=32 time<1ms TTL=128
Reply from 192.168.0.6: bytes=32 time=15ms TTL=128
Reply from 192.168.0.6: bytes=32 time=15ms TTL=128

Ping statistics for 192.168.0.6:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:


Minimum = 0ms, Maximum = 15ms, Average = 7ms
```

14. 查看交换机上的运行配置(命令 show running-config),复制粘贴本节相关的文本。

```
Switch#show running-config
Building configuration...
Current configuration: 1249 bytes
version 15.0
no service timestamps log datetime msec
no service timestamps debug datetime msec
no service password-encryption
hostname Switch
spanning-tree mode pvst
spanning-tree extend system-id
interface FastEthernet0/1
1
interface FastEthernet0/2
interface FastEthernet0/3
switchport access vlan 2
interface FastEthernet0/4
switchport access vlan 2
interface FastEthernet0/5
(省略了 6~23)
interface FastEthernet0/24
interface GigabitEthernet0/1
interface GigabitEthernet0/2
interface Vlan1
ip address 192.168.0.10 255.255.255.0
line con 0
line vty 0 4
password 3190105871
login
line vty 5 15
login
monitor session 1 source interface Fa0/1
monitor session 1 source interface Fa0/2
!
1
end
```

----- Part 2 -----

15. 增加一台交换机(Switch2),将 PC2、PC4 连接到该交换机,并用一根交叉网线 (Cross-over) 将两个交换机连接起来。在拓扑图上记录各 PC 的 IP 地址、连接端 口及所在 VLAN:



在 Switch2 上增加 VLAN 2,将 PC4 所连端口加入到 VLAN 2。

```
Switch(config) #vlan 2
Switch(config-vlan) #int fa0/3
Switch(config-if) #swi acc vlan 2 (PC3 所连端口也加入了 VLAN 2)
```


Switch>ena
Switch#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config) #vlan 2
Switch(config-vlan) #int fa0/4
Switch(config-if) #awitchp acc vlan 2

% Invalid input detected at '^' marker.


Switch(config-if) #switchp acc vlan 2

用 Ping 检查不同交换机上属于同一 VLAN 的 PC 之间的联通性(即 PC1 与 PC2 应该通, PC3 与 PC4 不能通)。然后显示 2 个交换机的 VLAN 数据(命令 show vlan)

Switch1 的 vlan 数据:




Switch2 的 vlan 数据:




联通性检测截图:

PC1→PC2




PC3→PC4






16. 将交换机之间的互联端口配置为 VLAN Trunk 模式(命令: switchport mode trunk, 部分型号的设备可能要先设置封装协议,命令: switchport trunk encapsulation dot1q), 再次用 Ping 检查属于同一 VLAN 但在不同交换机的 PC 之间的联通性(即 PC1 与 PC2 应该通,PC3 与 PC4 也应该通)。

输入的命令:




联通性检测截图:

PC1→PC2




PC3→PC4

PC3 - 192.168.0.6/24




17. 再增加一根网线,把 2 个交换机的另外 2 个端口连接起来。并将这 2 个端口都配置成 VLAN Trunk模式。稍等片刻,查看 4 个互联端口的状态(命令: show spanning-tree),分别在 2 个 VLAN 中标出:哪个交换机是根网桥?哪些端口处于转发状态(FWD),哪些端口处于阻塞状态(BLK)。

Spanning-tree 数据截图示例 (请替换成实际显示的):



Switch1



```
VLAN0002
 Spanning tree enabled protocol ieee
 Root ID
          Priority 32770
                     0001.978E.2BB6
           Address
           This bridge is the root
            Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority 32770 (priority 32768 sys-id-ext 2)
                      0001.978E.2BB6
           Address
           Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
           Aging Time 20
              Role Sts Cost
                               Prio.Nbr Type
        Altn BLK 19
                            128.24 P2p
Fa0/24
                               128.23
               Desg FWD 19
Fa0/23
               Desg FWD 19
Fa0/4
                                128.4
```

18. 关闭 2 个 VLAN 的 STP (命令: no spanning-tree vlan ID),观察两个交换机的端口状态指示灯(急速闪动),并在 PC 上用 Ping 测试网络的延迟是否加大(甚至可能出现超时或丢包)。

```
Switch>en
Switch#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#no spanning-tree vlan 1
Switch(config)#no spanning-tree vlan 2
```

Ping 结果截图:

```
C:\>ping 192.168.0.5

Pinging 192.168.0.5 with 32 bytes of data:

Request timed out.

Reply from 192.168.0.5: bytes=32 time<lms TTL=128

Reply from 192.168.0.5: bytes=32 time<lms TTL=128

Request timed out.

Reply from 192.168.0.5: bytes=32 time<lms TTL=128

Ping statistics for 192.168.0.5:

Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),

Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

19. 重新打开 2 个 VLAN 的 STP (命令: spanning-tree vlan ID),观察两个交换机的端口 状态指示灯 (缓慢闪动),并在 PC 上用 Ping 测试网络的延迟是否恢复正常。

Ping 结果截图:


```
C:\>ping 192.168.0.5

Pinging 192.168.0.5 with 32 bytes of data:


Reply from 192.168.0.5: bytes=32 time=7ms TTL=128
Reply from 192.168.0.5: bytes=32 time<1ms TTL=128
Reply from 192.168.0.5: bytes=32 time<1ms TTL=128
Reply from 192.168.0.5: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.0.5:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 7ms, Average = 1ms</pre>
```

20. 拔掉连接在 2 个处于 FWD 状态端口之间的网线,等待一会儿,查看 4 个互联端口的 状态 (命令: show spaning-tree) (有些端口可能已经消失)。标出原 BLK 状态的端口是否变成了 FWD 状态。

拔掉之前如 17 题所示; 刚刚拔掉时:



经过一段时间,线路之间有数据交流:



可见原 BLK 的端口已经变成了 FWD:



Physical Com	fig CLI Att	tributes
		IOS Command Line Interface
Switch>show	span	
VLAN0001		
		protocol ieee
Root ID	Priority	32769 0001.978E.2BB6
	Address	0001.978E.2BB6
	Cost	19
	Port	24 (FastEthernet0/24)
	Hello Time	2 sec Max Age 20 sec Forward Delay 15 sec
Bridge ID	_	32769 (priority 32768 sys-id-ext 1)
	Address	00E0.F76E.ED60
	Hello Time	2 sec Max Age 20 sec Forward Delay 15 sec
	Aging Time	20
Interface	Role St	ts Cost Prio.Nbr Type
Fa0/14	Desg rw	ND 19 128.1 P2p ND 19 128.24 P2p
140/21	KOOU IN	120.21 F2p
VLAN0002		
	ree enabled	protocol ieee
Spanning t		
Spanning t		
Spanning t		32770 0001.978E.2BB6
Spanning t	Priority Address Cost	32770 0001.978E.2BB6 19
Spanning t	Priority Address Cost Port	32770 0001.978E.2BB6
Spanning t Root ID	Priority Address Cost Port Hello Time	32770 0001.978E.2BB6 19 24(FastEthernet0/24) 2 sec Max Age 20 sec Forward Delay 15 sec
Spanning t Root ID	Priority Address Cost Port Hello Time	32770 0001.978E.2BB6 19 24(FastEthernet0/24) 2 sec Max Age 20 sec Forward Delay 15 sec 32770 (priority 32768 sys-id-ext 2)
Spanning t Root ID	Priority Address Cost Port Hello Time Priority Address	32770 0001.978E.2BB6 19 24(FastEthernet0/24) 2 sec Max Age 20 sec Forward Delay 15 sec 32770 (priority 32768 sys-id-ext 2) 00E0.F76E.ED60
Spanning t Root ID	Priority Address Cost Port Hello Time Priority Address Hello Time	32770 0001.978E.2BB6 19 24(FastEthernet0/24) 2 sec Max Age 20 sec Forward Delay 15 sec 32770 (priority 32768 sys-id-ext 2) 00E0.F76E.ED60 2 sec Max Age 20 sec Forward Delay 15 sec
Spanning t Root ID	Priority Address Cost Port Hello Time Priority Address	32770 0001.978E.2BB6 19 24(FastEthernet0/24) 2 sec Max Age 20 sec Forward Delay 15 sec 32770 (priority 32768 sys-id-ext 2) 00E0.F76E.ED60 2 sec Max Age 20 sec Forward Delay 15 sec
Spanning t Root ID	Priority Address Cost Port Hello Time Priority Address Hello Time Aging Time	32770 0001.978E.2BB6 19 24(FastEthernet0/24) 2 sec Max Age 20 sec Forward Delay 15 sec 32770 (priority 32768 sys-id-ext 2) 00E0.F76E.ED60 2 sec Max Age 20 sec Forward Delay 15 sec
Spanning t Root ID Bridge ID	Priority Address Cost Port Hello Time Priority Address Hello Time Aging Time Role St	32770 0001.978E.2BB6 19 24(FastEthernet0/24) 2 sec Max Age 20 sec Forward Delay 15 sec 32770 (priority 32768 sys-id-ext 2) 00E0.F76E.ED60 2 sec Max Age 20 sec Forward Delay 15 sec 20



		IOS Command Line Interface
Switch>show	span	
/LAN0001		
Spanning t	ree enabled p	protocol ieee
Root ID	Priority	32769
	Address	0001.978E.2BB6
	This bridge	is the root
	Hello Time	2 sec Max Age 20 sec Forward Delay 15 sec
Bridge ID	-	32769 (priority 32768 sys-id-ext 1) 0001.978E.2BB6
	Hello Time Aging Time	2 sec Max Age 20 sec Forward Delay 15 sec 20
Interface	Role Sts	s Cost Prio.Nbr Type
 Fa0/24	Desg FWD	19 128.24 P2p
Fa0/2	Desg FWD) 19 128.2 P2p

```
VLAN0002
 Spanning tree enabled protocol ieee
 Root ID
            Priority 32770
            Address
                        0001.978E.2BB6
            This bridge is the root
            Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority
                        32770 (priority 32768 sys-id-ext 2)
                        0001.978E.2BB6
            Address
            Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
            Aging Time 20
Interface
                Role Sts Cost
                                   Prio.Nbr Type
              Desg FWD 19
Fa0/24
                                   128.24
                                           P2p
                Desg FWD 19
Fa0/4
                                   128.4
                                           P2p
```

21. 配置 2 个交换机的互联端口优先级(默认优先级 128),使 VLAN1 的数据优先通过第 1 对互联端口传送(命令: interface 端口, spanning-tree vlan 1 port-priority 16)。使 VLAN2 的数据优先通过第 2 对互联端口传送(命令: interface 端口, spanning-tree vlan 2 port-priority 16)。此处只记录 2 个交换机各自所使用的命令及参数即可。


输入的命令:

```
Switch#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#inter fa0/23
Switch(config-if)#span vlan 1 port-pr 16
Switch(config-if)#exit
Switch(config)#inter fa0/24
Switch(config-if)#span vlan 2 port-pr 16


Switch>en
Switch+conf t
Enter configuration commands, one per line. End with CNTL/:
Switch(config)#int fa0/23
Switch(config-if)#span vl 1 port-p 16
Switch(config-if)#exit
Switch(config-if)#exit
Switch(config-if)#span vl 2 port-p 16
```

22. 拔掉剩下的 1 根连接互联端口的网线,稍后 2 根网线重新插上,等待一会儿,查看 4 个互联端口的状态,分别在 2 个 VLAN 中标出:各端口的优先级,哪些端口处于转发状态,哪些端口处于阻塞状态。

刚插上:









可以看到,两个 VLAN 根据优先级的不同选用了不同的接口进行转发。

23. 拔掉其中 1 根连接互联端口的网线,查看 4 个互联端口中原先处于 BLK 状态的端口, 是否变成了 FWD 状态(哪个 VLAN 发生了变化)

刚拔掉:







24. 记录 2 个交换机上的运行配置(命令:show running-config),复制粘贴本节相关的文本(完整的内容请放在文件中,每个交换机一个文件,分别命名为 S1.txt、S2.txt)。运行配置文本:

Switch1: (见 S1.txt)

Switch2: (见 S2.txt)


六、 实验结果与分析

根据你观察到的实验数据和对实验原理的理解,分别解答以下问题:

- 端口状态显示为 administratively down, 意味着什么意思? 即端口被管理员的 shutdown 人为关闭了。
- 在交换机配置为镜像端口前,为什么可以抓取到其他 PC 之间的 ARP 请求包,而不能 抓取 ARP 响应包?

ARP 请求包是广播的,从实验中也可以看到其目的地址是 FFFF: FFFF: FFFF, 即广播。 而 ARP 响应包是发回给请求包的发送方的,而且此时交换机也已经得知了请求方在哪个端口,因此可以直接转发到那个端口,无需广播。

- PC属于哪个 VLAN,是由 PC 自己可以配置的,还是由交换机决定的?通过配置交换机可以指定若干端口处于同一 VLAN 下。
- 同一个 VLAN 的 PC,如果配置了不同长度的子网掩码,能够互相 Ping 通吗?



经过测试,实际上取决于是否实际处于子网掩码更长的视角下的同一子网。

- 为什么在划分为 2 个 VLAN 后,两组 PC 之间就不能进行 IP 通信了呢? 交换机只会将数据包转发给与来源端口处于同一 VLAN 的端口。
- 交换机在 VLAN Trunk 模式下使用的封装协议是什么? 802.1Q
- 未启用 STP(Spanning Tree Protocol)协议时,交换机之间连接了多条网线后,为什么 Ping 测试的响应会延迟很大甚至超时?




Figure 4-43. Bridges with two parallel links.

这样的冗余引入了拓扑环路。考虑这样的情形:如上图,刚开始,B1 和 B2 的哈希表都是空的。此时 A 给 B1 发送了一帧 F0,B1 将帧从它的所有端口发送了出去,但是由于它到 B2 有两条链路,因此它在这两条链路上分别发送了帧 F1 和 F2。此时 B2 收到了这两个帧,并不知道这两个帧是同一个帧的副本,因此它分别对这两个帧进行 flooding;这样就会导致 F1 的副本从 F2 的链路被发回 B1,F2 的副本从 F1 的链路发回 B1,从此造成这个循环无限进行下去。

如果发送的是广播帧,这样的广播风暴更会导致网络瘫痪,因此 Ping 的延迟就会越来越大。

● 从插上网线后开始,交换机的端口状态出现了哪些变化?
LSN(监听)→ LRN(学习)→ FWD(转发)
大约需要多少时间才能成为 FWD 状态? 大约 30s 左右
期间,连接在该端口的计算机是否能够 Ping 通? 不能

七、讨论、心得

- 交换机 CLI 遇到 Translating "XXXX"...domain server (255.255.255.255) 可以用 Ctrl+Shift+6 终止。
- Sniffer 的使用讲解 https://www.youtube.com/watch?v=gsCSKQAVT2M
- 对"端口镜像"还没有很理解
- 交换机可以自己学习到 VLAN 吗?
- 交换机在 VLAN Trunk 模式下使用的封装协议是什么?