Spartan 3 FPGA Kit




ISE Project Navigator (P.68d) - D:\B2\b2\b2.xise - [fulladder.ucf]
File Edit View Project Source Process Tools Window Layout Help
Design
View: Implementation Simulation
Hierarchy
b2
xc3s400-4pq208
fulladder (D:\B2\b2\b2.v)
D:\B2\b2\fulladder.ucf
Running: Map
Processes: fulladder.ucf
User Constraints
Start Design Files Libraries
1 2 # PlanAhead Generated physical constraints
3
4 NET "a" LOC = P34;
5 NET "b" LOC = P35;
6 NET "cin" LOC = P36;
7 NET "c" LOC = P71;
8 NET "s" LOC = P72;
9
b2.v
fulladder.ucf
Console


ISE iMPACT (P.68d) - [Boundary Scan]
File Edit View Operations Output Debug Window Help
iMPACT Flows
Boundary Scan
SystemACE
Create PROM File (PROM File Format...
WebTalk Data
TDI
xc3s400
bypass
TDO
iMPACT Processes
Available Operations are:
Get Device ID
Get Device Signature/Usercode
Read Device Status
Identify Succeeded
Boundary Scan


ISE iMPACT (P.68d) - [Boundary Scan]
File Edit View Operations Output Debug Window Help
iMPACT Flows
Boundary Scan
SystemACE
Create PROM File (PROM File Format...
WebTalk Data
TDI
xc3s400
fulladder.bit
TDO
iMPACT Processes
Available Operations are:
Program
Get Device ID
Get Device Signature/Usercode
Read Device Status
One Step SVF
One Step XSVF
Program Succeeded
Boundary Scan
Errors