




Install Keil MDK Version 5			
•			-
Add Software Pack			
Keil::LPC1800_DFP			
Power up the board			
•	Power		
•	Trace Connector		þro
Verify Installation			
•			
•			
More Information			
•			
•			
Related Information			
•			
•			
•			



ULINKpro Debugger and Trace Adapter




Trace Settings (SWO trace)

Trace Core Clock

Trace Enable

Serial Wire Output-Manchester Autodetect SWO Clock Prescaler 2



Quick Links Tracing ULINKpro User's Guide NXP LPC18xx Devices

Configure Cortex-M Devices for