Heat Press Settings Cheat Sheet

heatpress-settings.co.uk · Celsius for UK crafters

These are published starting points from the manufacturer charts named in each row, checked 7 October 2026. Follow the instructions for the product in your hand and test on a scrap or spare blank first. The number on a heat press dial is often not the true platen temperature.

Heat transfer vinyl

Product / blank	Temp	Time	Pressure	Peel	Source
Siser EasyWeed	**150°C** (305°F)	10–15 seconds	Medium	Hot or cold	Siser EasyWeed
Garment Films One Flex	**140°C** (284°F)	8 seconds	Not listed on this chart	Hot, warm or cool	Garment Films application guidelines
Siser EasyWeed Sub Block	**130°C** (265°F)	10–15 seconds	Medium	Hot or cold	Siser EasyWeed Sub Block
Siser EasyWeed Extra	**150°C** (305°F)	10–15 seconds	Medium	Hot or cold	Siser HTV application instructions
Siser HI-5	**120°C** (248°F)	5 seconds	High (about 4–5 bar)	Hot or cold	Siser HI-5
Garment Films One Flex, cooler press	**120°C** (248°F)	15 seconds	Not listed on this chart	Hot, warm or cool	Garment Films application guidelines
Siser Glitter	**160°C** (320°F)	15–20 seconds	Medium	Warm	Siser Glitter
Garment Films Premium Glitter	**160–170°C** (320–338°F)	15 seconds	Not listed on this chart	Hot, warm or cool	Garment Films application guidelines
Siser StripFlock Pro	**155°C** (310–311°F)	15 seconds	Medium	Warm	Siser StripFlock Pro
Garment Films Flock	**150°C** (302°F)	10 seconds	Not listed on this chart	Cool	Garment Films application guidelines
Siser EasyWeed EcoStretch	**120°C** (250°F)	10–15 seconds	Medium	Hot	Siser HTV application instructions
Garment Films Stretch Flex	**150°C** (302°F)	10 seconds	Not listed on this chart	Cool	Garment Films application guidelines
Siser EasyWeed Stretch	**160°C** (320°F)	20 seconds	Firm	Hot or cold	Siser EasyWeed Stretch
Siser Metal	**150°C** (305°F)	10–15 seconds	Medium	Cold	Siser HTV application instructions
Garment Films Stretch Metallic	**140°C** (284°F)	7–10 seconds	Not listed on this chart	Warm or cool	Garment Films application guidelines
Siser Holographic	**160°C** (320°F)	15–20 seconds	Medium to firm	Cold	Siser, working with holographic
Garment Films Holo PU Black	**140°C** (284°F)	8–10 seconds	Not listed on this chart	Cold	Garment Films application guidelines
Garment Films Metallic and Holographic	**140–150°C** (284–302°F)	10–15 seconds	Not listed on this chart	Hot, warm or cool	Garment Films application guidelines

Sublimation

Product / blank	Temp	Time	Pressure	Peel	Source
Sawgrass, polyester fabric	**205°C** (400°F)	45 seconds	Medium	Remove the paper when the press opens	Sawgrass sublimation heat press settings
Xpres, polyester T-shirt	**190°C** (374°F)	60–70 seconds	Medium	Hot	Xpres, how to sublimate T-shirts
Sawgrass, ceramic mug	**180–205°C** (350–400°F)	150–300 seconds	Medium	Take the paper off as the mug press instructions say	Sawgrass sublimation heat press settings
Sawgrass, MDF board	**205°C** (400°F)	60 seconds	Medium	Lift the paper straight off after pressing	Sawgrass sublimation heat press settings
Sawgrass, metal	**205°C** (400°F)	60 seconds	Medium	Lift the paper straight off after pressing	Sawgrass sublimation heat press settings
Sawgrass, slate	**205°C** (400°F)	420 seconds (7 minutes)	Medium	Lift the paper straight off after pressing	Sawgrass sublimation heat press settings
Sawgrass, acrylic	**190°C** (375°F)	60 seconds	Medium	Lift the paper straight off after pressing	Sawgrass sublimation heat press settings

DTF transfer

Product / blank	Temp	Time	Pressure	Peel	Source
Xpres DTF information sheet	**160°C** (320°F)	15 seconds, then repress 15 seconds	Light to medium	Cold	Xpres DTF information sheet
Xpres DTF how-to guide	**150–160°C** (302–320°F)	10–15 seconds	Medium	Cold	Xpres, how to DTF
Garment Films, basic DTF figure	**140–150°C** (284–302°F)	8–10 seconds	Medium	Follow the film's data sheet	Garment Films FAQ

Fahrenheit in brackets is the manufacturer's figure where they print one, otherwise the usual conversion. Full notes, cautions and links to each source chart: heatpress-settings.co.uk