AIB Camera — Field guide

Document version	2 November 2026
Reference app version	1.0.2
Language	English
Site	smnl.dev/aib-camera
Privacy	smnl.dev/aib-camera/privacy
Terms	smnl.dev/aib-camera/terms
PDF	smnl.dev/docs/aib-camera-field-guide.pdf

Contents

1. Purpose of this guide
2. What AIB Camera is
3. What it does and does not do
4. Requirements and install
5. Permissions
6. Main screens
7. Camera
8. Stamp settings
9. Gallery (Photos tab)
0. Capture log
1. EXIF metadata
2. Offline use and place
3. Sharing
4. Limits and responsibility
5. Field checklist
6. Contact

1. Purpose of this guide

This guide explains, in English, how AIB Camera works in the field: permissions, capture, stamping photos, gallery, capture log, and use without a network.

It is for **anyone** who uses the app — citizens, volunteers, or others — to document a wildfire (AIB) or similar situation. It describes the real behavior of version **1.0.2**.

2. What AIB Camera is

AIB Camera is an **independent, unofficial** mobile app for field photography in wildfire response and similar situations. It is **open to anyone**: not limited to a specific organization or only to professional operators. It lets you:

- take photos with the rear camera;
- print on the JPEG (visual stamp) date, time, position, and — when available — place and other context;
- keep photos in an **in-app gallery**;
- share them with the system share sheet (WhatsApp, Telegram, Mail, …);
- keep a local **capture log** with an identifier for each shot.

Typical uses: document a fire, send the shot to whoever needs it, or read coordinates and other details to emergency responders (e.g. 112).

It is designed to stay usable **even without network, GPS, or Photos library access**: in an emergency it must always be possible to capture and share.

> **Notice — not institutional**
>
> The app is **not** built, endorsed, or affiliated with Civil Protection, the Fire Service, Regione Lombardia, or other public institutions. It does not use institutional logos, seals, or acronyms. It is an independent tool available to the public; any use in official contexts remains the responsibility of the person using it.

---

3. What it does and does not do

What it does

Feature	Detail
Stamp on JPEG	Date/time (**Europe/Rome** timezone), coordinates, accuracy, altitude, heading, place, and custom text, per Stamp settings
Aimed target	Distance + compass heading from GPS: estimates coordinates of what you point at; Me ↔ Target toggle; “estimated” label on the stamp
Live preview	The viewfinder shows the same block that will be burned into the photo
Fast capture	You can take several photos in a row; the stamp is processed in a queue, one photo at a time
In-app gallery	Source of truth: photos stay in the app even without Photos library permission
System album	Copy into the “AIB Camera” album if Photos permission is granted (not guaranteed)
Capture log	Local append-only list: capture ID, date/time, coordinates; exportable as CSV with `install_id`
Install ID	Stable UUID per install (Settings, tap to copy); matches the CSV column
EXIF	Best-effort write of identifier, GPS, and machine comment on the JPEG (not always available)
Offline	Capture, stamp, gallery, log, and share do not require a network

What it does not do

- Does not require an account, login, or cloud sync.
- Does not send photos, location, or the log to developer servers.
- Does not replace institutional archival procedures, reports, or command-and-control systems.
- Does not guarantee GPS accuracy or EXIF completeness: those depend on device, permission, signal, and app build.
- Does not offer a front camera or flash “auto” mode. UI language (Italian by default, or English) is switched in Settings.

---

4. Requirements and install

- **iOS** or **Android** phone with a rear camera.
- A **physical device** is recommended (not only a simulator or emulator).
- Supported orientation: **portrait**.
- UI language: **Italian** (default) or **English**, selectable in **Settings** and stored on the device.
- Stamp timezone: always **Europe/Rome**, independent of the phone timezone.

Up-to-date availability and distribution: smnl.dev/aib-camera. For organized rollouts (many devices, dedicated builds), contact the developer (see § 16).

---

5. Permissions

Permission	Required?	What it is for
Camera	Yes	Taking photos. Without it the app cannot capture images.
Location (while using)	No	Coordinates, accuracy, altitude, heading, and place on the stamp and, when possible, in EXIF.
Photos / media library	No	Copy photos into the system “AIB Camera” album and remove them there when deleted in the app.

Without GPS you can still shoot. The stamp keeps date/time and any custom text; geo lines show *Coordinates unavailable* / *Place unavailable*.

Without Photos library images stay in the **in-app gallery**, which is the source of truth.

Permissions can be reviewed from **Settings** and the phone’s system Settings.

---

6. Main screens

Three tabs in the bottom bar:

1. **Camera** — capture and stamp preview
2. **Photos** — in-app gallery
3. **Settings** — language (Italiano / English), permissions, version and install ID (tap to copy), capture log, links to this guide and the privacy policy. Stamp settings open from the icon at the top right of the camera.

---

7. Camera

7.1 Viewfinder and letterbox bands

The live preview has **black bands** above and below. Top: **flash** on the left, **Aim** next to flash, **stamp configuration** on the right. Bottom: shutter in the center, last-shot preview on the left, **zoom** on the right. Beyond 2× the tele button shows the live factor (3×, 4×, …).

7.2 Live stamp preview

The viewfinder shows the same block that will be **burned** into the JPEG:

- top: date/time, optional **Aimed target (estimated)** line, coordinates, meta (estimated distance / accuracy / altitude / heading), place — per Stamp settings toggles;
- bottom: custom text, if filled in.

Font, text size, and background opacity follow **Stamp settings** (top-right icon on the camera). The preview matches what will land on the photo.

7.3 Controls

Control	Behavior
Shutter	White circle in the center of the bottom band: captures the photo.
Last-shot preview	Square on the left: opens the detail of the last ready photo. A loading indicator appears while processing is still running.
Flash	Lightning icon **top left**: **on / off** only (no auto mode).
Aim	Crosshair icon next to flash, or **press and hold** the viewfinder (~0.5 s): full-width content-height sheet; dismiss with × or tap outside; distance and **Lock target**.
Me / Target	With a sticky point active, selector at top center: switches between your GPS position and the aimed target without losing it.
Stamp settings	Sliders icon **top right**: full-width bottom sheet (full height); dismiss with × or tap outside.
Zoom	Buttons **bottom right** (e.g. 0.5× / 1× / 2× when available) and **pinch**; beyond 2× the active button shows 3×, 4×, …. **Double-tap** the viewfinder resets zoom to 1×.
Swipe	Swipe **left** from the viewfinder to open the gallery.

Only the **rear** camera is used.

7.4 Aimed target (distance + heading)

To stamp the coordinates of what you are **pointing at** (e.g. a hotspot 200 m away), not your position:

1. Make sure GPS and compass are available.
2. Point the camera at the point of interest.
3. Tap **Aim** (or press and hold the viewfinder): a full-width sheet opens (dismiss with × or tap outside).
4. Choose or type the distance in meters, then **Lock target**.
5. The stamp shows estimated coordinates and the label **Aimed target (estimated)**.
6. Use **Me** ↔ **Target** to return to your position or re-enable the sticky point; **Clear target** removes it.

It is a ground estimate along the compass heading (no altimetry / DEM): useful in the field, not a GNSS fix on the target. Without GPS or heading, lock fails; capture remains available in Me mode.

7.5 Capture and background processing

After the shutter:

1. The raw JPEG is acquired immediately; the shutter stays available for more shots.
2. In a queue, **one photo at a time**, the app: applies the stamp, writes EXIF if possible, saves to the in-app gallery, updates the capture log, and tries to copy into the “AIB Camera” album.

You can shoot in sequence without waiting for the stamp to finish: the indicator on the left preview shows that processing is still running.

For the stamp the app prefers the **position already available** on the viewfinder (live GPS or locked aimed target), so the shutter is not blocked waiting for a more precise fix.

---

8. Stamp settings

Path: sliders icon on the **camera** — full-width, full-height bottom sheet (**Stamp settings**); dismiss with ✕ or tap outside.

8.1 Visible fields (toggles)

- Date and time
- Coordinates
- Place (label from reverse geocode or local cache)
- GPS accuracy
- Altitude
- Heading (compass)

8.2 Custom text

Up to **4** free lines (e.g. crew name or shift). Empty by default: no bottom block appears. Suggested in-app placeholder: *Squadra Nord · Turno A*.

8.3 Date format

Option	Description
Full	Weekday and extended date
Short	Compact date and time (**default**)
ISO	ISO format with Europe/Rome timezone

8.4 Text size

Small / **Medium** (default) / Large.

8.5 Stamp background opacity

From **0%** (text only; with shadow for readability) to **100%**, in 25% steps. Default: **0%**.

Changes apply immediately to the live preview and later shots. Photos already taken are not modified.

---

9. Gallery (Photos tab)

- Photos are grouped by day (Europe/Rome timezone), with headers like *Today* / *Yesterday*.
- Tap a thumbnail for detail (**Share** / **Delete**).
- Selection mode: **Select** button or long-press a thumbnail; then multi share or delete.

In-app gallery vs system album

Comparison	In-app gallery	“AIB Camera” album
Role	**Source of truth**	Copy in the phone library (if permission allows)
Needs Photos permission?	No	Yes, if you want the copy
Delete in app	Removes the local file and, when present, the Photos library copy	—

> **Capture log:** deleting a photo from the gallery does **not** remove the matching capture-log row.

---

10. Capture log

Access: **Settings** → **Capture log**.

- Each successful shot adds a row with: **ID** (UUID), date/time, coordinates when available (otherwise *No GPS*).
- The log is **append-only** (entries are not deleted from the app): rows stay on the device after gallery deletions.
- Tap a row to **copy the ID** and compare it with EXIF on a shared JPEG (`ImageUniqueID` / JSON comment), when EXIF was written.
- **Export CSV** (top): builds a local file with columns `install_id`, `id`, `taken_at`, `latitude`, `longitude` and opens the system share sheet (Mail, Files, AirDrop, …). No automatic upload.
- In **Settings**, tap **Version** or **Install ID** to copy the value to the clipboard.
- **Install ID:** UUID created on first launch. Same value as the `install_id` CSV column; reinstalling creates a new one.

The log is **not** sent to any server; CSV export leaves the device only if you choose a share app or service.

---

11. EXIF metadata

After stamping the app tries to write on the JPEG, among other fields:

- `Software` / `Artist`
- `ImageUniqueID` (capture UUID)
- capture date/time (Europe/Rome)
- GPS tags, if position is available
- `ImageDescription` and `UserComment` (JSON for machine use)

> **Caution — EXIF not guaranteed:** if the native module is unavailable on the installed build, **stamped photo, gallery, and log remain valid**. Only metadata write into the file is missing. Do not treat EXIF as automatic legal proof: always also check the visual stamp and the log.

---

12. Offline use and place

- Capture, stamp, gallery, log, and share **do not require a network**.
- Network is only needed for **reverse geocoding** (coordinates → place label), if Place is enabled and there is connectivity.
- Recent labels stay in a **local cache** and can be reused offline nearby (about **2.5 km** radius).

Without network or GPS, the stamp shows fallback text (*Coordinates unavailable*, *Place unavailable*) without blocking the shutter.

On older or constrained devices, the app **degrades quietly**: if Skia stamp fails the unstamped JPEG stays in the gallery; without native EXIF, photo + gallery + log remain; without Photos permission only the in-app gallery remains; fonts and haptics use system fallbacks. The shutter must not block for these details.

---

13. Sharing

From detail or gallery selection the **system share sheet** opens (Messages, Mail, WhatsApp, Files, etc.).

The shared file is the already stamped JPEG, with EXIF if it was written. After sending, handling and retention depend on the app or service chosen by the sharer (outside AIB Camera's control).

---

14. Limits and responsibility

Anyone using the app should keep these points in mind:

1. **Support tool**, not a substitute for official documentation or archival procedures.
2. **Position accuracy** depends on the device, Location permission, and signal; the app does not correct or certify GPS. **Aimed target** is an estimate (GPS + compass + entered distance), not a fix on the target.
3. **Date and time on the stamp** always use Europe/Rome; check that the phone clock is set correctly.
4. **"AIB Camera" album** is a convenience copy: the reliable copy on the device is the **in-app gallery**.
5. **Privacy:** photos, settings, and log stay on the device; there is no developer-managed cloud sync. Sharing with third parties is the user's choice.
6. **Updates:** this guide refers to app version **1.0.2**; for later releases check for differences on smnl.dev/aib-camera.

---

15. Field checklist

1. Grant at least **Camera** permission; Location and Photos when useful.
2. Check **Stamp settings** (active fields, custom text, date format, size, opacity) before shooting.
3. Verify on the **live preview** what will land on the JPEG. 3b. If you need to document a distant point (e.g. a hotspot), use **Aim** (tap or press-and-hold the viewfinder) with an estimated distance and check the **Aimed target (estimated)** label before shooting.
4. In a capture sequence, do not wait for the processing indicator: you can keep photographing.
5. If you need the Photos library copy, confirm the **AIB Camera** album updates (Photos permission granted).
6. To trace a shot after deleting the photo, use the **capture log** and ID; to link CSVs across devices, compare **Install ID** in Settings with the `install_id` column.
7. Before sharing externally, ensure content and destination comply with applicable law.

---

16. Contact

App questions	stefano@smnl.dev
Privacy policy	smnl.dev/aib-camera/privacy
Terms of use	smnl.dev/aib-camera/terms
This guide (web)	smnl.dev/aib-camera/guide
This guide (PDF)	smnl.dev/docs/aib-camera-field-guide.pdf

Unofficial document · Reference app version 1.0.2 · Printable · © Stefano Monolo — smnl.dev