

Pedro Pathing Constants Explained (Pinpoint)

Oct 5, 2026 · @Girish

Version 3 (7 Oct 2026). Cleaned up: the step-by-step work now lives in the Tuning Checklist and the number checks in the Pedro Tuning Checker. See *Version history* near the end.

How to use this guide

This guide explains **why**: what each value in our `Constants.java` measures and what it does to the robot. It is written for students who are new to Pedro Pathing. Our setup: a mecanum drivetrain, a goBILDA Pinpoint with two goBILDA 4-bar pods, and Pedro Pathing 3 with its path-following algorithm, **Foresight**.

Use this	When
This guide	To understand a value, or why a check matters
Tuning Checklist	To do the tuning, in order, with a gate after each stage and a sign-off log
Pedro Tuning Checker	To check the tuned numbers, compare tuner runs, check the offset signs and get an averaged config
Staged <code>Tuning.java</code>	Switches the tuners and tests on stage by stage, as the checklist says

Reading order: *Start here* first, then *The big picture*. Use *Every parameter, explained* as a lookup table, and *Fixing the Line Test* when the robot misbehaves.

The one rule of this guide: every explanation points to a source: the Pedro Pathing paper, the official Pedro Pathing docs, the Pedro tuner code on GitHub, or the goBILDA Pinpoint user guide. When the sources do not explain something, the guide says so. Worked examples marked **Our numbers** plug our values into a sourced formula; only the arithmetic is ours.

Start here: pod directions and offsets

Four settings decide whether the robot knows where it is: `xPodDirection`, `yPodDirection`, `xPodOffset` and `yPodOffset`. **Get these right before touching any other number in this guide.** If they are wrong, no amount of tuning will fix the path following.

Why this matters most

- **Following depends on localization.** Foresight steers using the pose that Pinpoint reports (paper, §3.1–§3.5). A wrong pose means the robot corrects toward the wrong place.
- **Pedro says so directly.** "Ensure that your localization is fully accurate before running automatic tuners" ([Pedro docs: Troubleshooting](#)).
- **Every Foresight number was measured through the Pinpoint.** The Foresight tuner reads all of its speeds, slow-downs and braking distances from the localizer ([ForesightTuner.java](#)). Bad localization during tuning can carry into those values.
- **Wrong directions or offsets are known causes.** Reversed encoder directions and inaccurate or switched offsets are both on Pedro's list of causes of inaccurate localization (Pedro docs: Troubleshooting).
- **We have an open question here.** Our `yPodOffset` (−6.65 in) says the strafe pod is *behind* the centre, but our pods are mounted at the front. See *Does pod placement matter?* below.

First: which way is "forward" and "left"?

Every sign below depends on this, so settle it first.

1. Run **Tests → Driving** and push the stick forward. The side of the robot that leads is the robot's **forward** ([Pedro docs: Mecanum](#)).
2. Stand behind the robot facing that way. Your left hand points to the robot's **left**. For the robot, forward is +x and left is +y ([Pedro docs: Types of Velocities](#)).
3. Write "FRONT" on that side with tape so everyone uses the same forward.

Encoder directions

Setting	goBILDA's rule	How the tuner sets it	Our value
xPodDirection	The X (forward) pod count must go up when the robot moves forward (goBILDA guide, p. 2)	You push the robot forward. If x ends positive → FORWARD ; negative → REVERSED (PinpointTuner.java)	FORWARD
yPodDirection	The Y (strafe) pod count must go up when the robot moves left (goBILDA guide, p. 2)	You push the robot left. If y ends positive → FORWARD ; negative → REVERSED (PinpointTuner.java)	FORWARD

Where it can go wrong (from reading the tuner code):

- The tuner only checks whether the final number is positive or negative, not how far you pushed. Make a clear, straight push of a foot or more.
- "Forward" is whichever way you pushed. If that is not the side that leads when driving, the Pinpoint and the motors disagree. Wrong directions can make a robot "move infinitely" during tuning (Pedro docs: Troubleshooting).
- The forward pod must be in the Pinpoint's **X** port and the strafe pod in the **Y** port ([Pedro docs: Pinpoint](#)).

Check: this is Gate 2a of the Tuning Checklist. In **Tests → Localization**, push toward the robot's forward and x must go up; push to its left and y must go up ([Pedro docs: Localization](#)).

Offsets

Offsets tell the Pinpoint where each pod sits compared with the robot's centre. Pedro measures them from the robot's centre of rotation (Pedro docs: Pinpoint). Our file uses inches.


Setting	What it measures (goBILDA guide, p. 2)	+ means	– means	Our value	So our pod is...
xPodOffset	How far sideways the X (forward) pod is from the centre	Left of centre	Right of centre	–3.06 in	About 3.1 in right of centre
yPodOffset	How far forward the Y (strafe) pod is from the centre	In front of centre	Behind centre	–6.65 in	About 6.7 in behind centre

Offsets are measured from the centre: left and in front are +

Top view. Pod positions are drawn from our file's values, not measured.

FRONT (the side that leads when driving forward)

In front of centre = + for yPodOffset



Our file: xPodOffset = -3.06 (right), yPodOffset = -6.65 (behind). Check against the real robot.

Offset signs, top view · drawn from our file's values

If our pods are really at the front, the Y pod in this picture is on the wrong side, which is the open question above.

Only one direction counts for each pod. For the X pod, measure sideways only; how far forward it sits does not matter. For the Y pod, measure forward or back only (goBILDA guide, p. 2). Measure to the line the pod's wheel rolls along, as in Pedro's diagram (Pedro docs: Pinpoint, Manual Offset Tuning).

Example	Value to enter
X pod 3 in left of centre	xPodOffset = 3.0
X pod 3 in right of centre	xPodOffset = -3.0
Y pod 6 in in front of centre	yPodOffset = 6.0
Y pod 6 in behind centre	yPodOffset = -6.0
Pod exactly on the centre line	0.0

Does pod placement matter?

Our two pods sit in one line at the front of the robot. **Where they sit matters less than whether the offsets match where they are.**

- goBILDA only asks for one pod tracking forward (X) and one tracking sideways (Y). It gives no distance rules ([goBILDA guide, p. 5](#)).
- Heading comes from the Pinpoint's built-in IMU, not from the pods (same guide, p. 1).
- We found nothing in the goBILDA or Pedro docs saying front-mounted pods are a problem.

Our `yPodOffset` (-6.65 in) says the strafe pod is *behind* the centre, which does not match pods at the front. Two possible explanations:

1. **The robot's forward is the side we call the back.** If the side that leads when driving forward is our "back", a negative `yPodOffset` would be correct.
2. **The tuner result is off.** A sloppy turn or wheel slip during the offsets step gives wrong numbers (see the next section). Our file also holds two older, commented-out Pinpoint configs with different offsets.

How the tuner finds offsets, and how it can go wrong

The tuner sets both offsets to 0. You turn the robot 180° counterclockwise in place, then stop the OpMode (Pedro docs: Pinpoint). The robot did not really move, but with zero offsets the Pinpoint thinks it did. The tuner then sets $xPodOffset = -y \div 2$ and $yPodOffset = -x \div 2$ from that fake movement (PinpointTuner.java).

That only works for a clean spin. These risks follow from the formula; the error sizes are our own arithmetic:

- **The robot slides while turning.** Real movement of the centre is mixed into the result. Every 1 in of slide adds about 0.5 in of offset error.
- **It spins around the wrong point.** The tuner treats whatever point you spun around as the centre.
- **The directions were wrong.** The direction steps come first, so their errors carry into the offsets.
- Being a few degrees short of 180° matters much less (about 1–2% error).

Tuner or ruler?

Both are allowed: the Pedro docs say offsets "can also be found manually" (Pedro docs: Pinpoint).

	Built-in tuner	Ruler measurement
How	Calculates offsets from a 180° spin	Measure from the centre to each pod

	Built-in tuner	Ruler measurement
Main risks	Sliding, wrong spin point, wrong directions	Guessing the centre, wrong sign
Signs	Worked out for you	You apply the + / – rules above
Best use	First estimate	Checking the tuner


Doing it

The steps are **Stage 2** of the Tuning Checklist: run the Pinpoint tuner, then pass Gate 2a (directions), Gate 2b (offsets match a ruler) and Gate 2c (accuracy and the spin test). Section 4 of the Pedro Tuning Checker checks the offset signs against where you say the pods are. If the directions change, re-run the Foresight tuner (Stage 3), because all its measurements came through the Pinpoint (ForesightTuner.java).

The big picture

To drive an autonomous path, the robot has two jobs. **Job 1:** know where it is (the Pinpoint does this). **Job 2:** push itself along the path (the Foresight algorithm does this). Job 2 can only be as good as Job 1. The Pedro docs say to make sure localization is fully accurate before running the automatic tuners ([Pedro docs: Troubleshooting](#)).

Pinpoint says where the robot is; Foresight adds four pushes to move it



How the robot follows a path · 2 jobs, 4 pushes

Read it top to bottom: Pinpoint finds the pose, Foresight turns it into four pushes, and the motors carry them out.

Job 1: How Pinpoint knows where the robot is

- The robot has two **odometry pods**. These are small wheels with no motor that roll on the floor and count how far they turn.
- The **X pod** (forward pod) measures forward and backward motion. The **Y pod** (strafe pod) measures sideways motion ([goBILDA Pinpoint User Guide, p. 2](#)).
- The Pinpoint also has a factory-calibrated sensor for turning (yaw), so it knows the robot's heading (same guide, p. 2).
- It combines all of this about 1,500 times per second (same guide, p. 1).
- The answer is called the robot's **pose**: x, y and heading. For the robot itself, forward is +x and left is +y ([Pedro docs: Types of Velocities](#)). Turning counterclockwise is a positive heading change ([Pedro docs: Coordinates](#)).
- How good is it? goBILDA says a robot driven around and brought back should read within about 10 mm (~0.5 inch) of where it started (goBILDA guide, p. 7).

Job 2: How Foresight follows a path

The paper describes Pedro Pathing's method as a **guiding vector field**. Picture an arrow drawn at every spot near the path. Each arrow tells the robot which way to speed up so it moves onto the path and along it (paper, Abstract and §3). The arrow is built by adding four separate pushes:

Push (paper section)	What it does, in plain words	Settings in our file that belong to it
Translational correction (§3.2)	Pulls the robot sideways back onto the path, along the shortest line to it	<code>forwardTranslational</code> , <code>strafeTranslational</code>
Heading correction (§3.3)	Turns the robot to face the direction the path asks for	<code>headingFeedback</code> , <code>headingBrakeCoefficients</code>
Centripetal force (§3.4)	Extra push toward the inside of a curve so the robot does not slide outward	None in our file. On a straight line the formula gives zero, because the path does not bend
Tangential drive (§3.5)	The main push along the path. It also plans when to slow down so the robot stops at the end	<code>maxAchievable...Velocity</code> , <code>natural...Deceleration</code> , <code>linearBrakeCoefficients</code> , <code>quadraticBrakeCoefficients</code> , <code>coast</code> , <code>brake</code>

Two more ideas from the paper help with everything below:

- **The closest point and "t" (§3.1).** The robot keeps finding the point on the path closest to itself. Positions along the path are numbered with t, from 0 at the start to 1 at the end.
- **Planning the stop (§3.5).** Basic physics says the robot can still stop in time if its speed is below $\sqrt{2 \times \text{deceleration} \times \text{distance left}}$. The paper notes that friction and other forces change this. So Pedro instead measures how far the robot slides while braking at different speeds, then works backward to find the right speed (paper, footnote 2). The brake coefficients in our file are exactly that measurement.

The paper proves the robot will settle onto the path "with sufficiently well-chosen scalar gains" (paper, Theorem 4.6). The gains are the tuned numbers in our file. That is why tuning matters.

Every parameter, explained

Our file has four parts: the `create` method, the drivetrain settings, the Pinpoint settings and the Foresight settings ([Pedro docs: Constants](#)). Blocks wrapped in `/* ... */` are comments. Java ignores them, so only the active blocks below matter.

Part A: The `create` method (putting the robot together)

Line in our file	What it means	What it does to the robot
<code>new PinpointLocalizer(h, localizerConfig)</code>	Job 1: use the Pinpoint with our Pinpoint settings	Gives the follower the robot's pose
<code>new Mecanum(h, drivetrainConfig)</code>	Use our four mecanum motors with our motor settings	Lets the follower send power to the wheels
<code>null //new Foresight(foresightConfig)</code>	Job 2 is switched off. The Pedro docs show this spot must be <code>new Foresight(foresightConfig)</code> (Pedro docs: Constants)	Every tuned Foresight number in our file is never handed to a follower made by <code>create</code> . The docs only use <code>null</code> here for the localization test (Pedro docs: Localization)

Our file still passes `null` here. **Stage 4** of the Tuning Checklist fixes it, after the Foresight values are tuned and checked.

Part B: Drivetrain (`MecanumConfig`)

Setting	Our value	What it means
<code>frontLeftName</code> , <code>backLeftName</code> , <code>frontRightName</code> , <code>backRightName</code>	Names from <code>HardwareNames</code>	Must match the motor names in the Driver Hub configuration (Pedro docs: Mecanum)

Setting	Our value	What it means
<code>frontLeftDirection</code> , <code>backLeftDirection</code>	<code>REVERSE</code>	Left motors are flipped so "forward power" spins every wheel forward. The tuner checks each motor and you confirm it spun the right way (same page)
<code>frontRightDirection</code> , <code>backRightDirection</code>	<code>FORWARD</code>	Same check for the right side
<code>manualBrakeMode</code>	Not in our file	Optional. The docs say to add it for TeleOp if you want brake mode (same page)

Part C: Pinpoint (PinpointConfig)

Setting	Our value	What it means	What a wrong value does
<code>name</code>	<code>"pinpoint"</code>	The Pinpoint's name in the Driver Hub configuration (Pedro docs: Pinpoint)	The robot code cannot find the Pinpoint
<code>podType</code>	<code>goBILDA_4_BAR_POD</code>	Tells the Pinpoint how many encoder ticks equal one millimetre. The 4-bar pod has a 2000-count encoder and a 32 mm wheel, which is 19.894 ticks per mm (goBILDA guide, p. 2)	Every distance comes out too big or too small
<code>xPodDirection</code> , <code>yPodDirection</code>	<code>FORWARD</code> , <code>FORWARD</code>	Which way each pod counts. Explained in <i>Start here: Encoder directions</i>	Pushing forward or left makes x or y go down

Setting	Our value	What it means	What a wrong value does
<code>xPodOffset</code> , <code>yPodOffset</code>	-3.06 in, -6.65 in	Where each pod sits compared with the robot's centre. Explained in <i>Start here: Offsets</i>	When the robot only turns, the pose looks like it moved
<code>globalDistanceUnit</code> , <code>offsetUnits</code>	INCH	Positions and offsets are in inches. The tuner writes both lines (PinpointTuner.java)	Numbers are read in the wrong unit

Part D: Foresight — top speed and stopping (the tangential drive push)

These numbers let the robot plan when to slow down so it stops on the end point (paper, §3.5).

Setting	Our value	What it is and how the tuner measured it	What it does to the robot
<code>maxAchievableForwardVelocity</code>	57.6 in/s	Top forward speed. The tuner drives at full power and averages the last 10 speed readings (ForesightTuner.java)	The paper models a robot with a different top speed in each direction (paper, §2.3)
<code>maxAchievableStrafeVelocity</code>	45.2 in/s	Top sideways speed, measured the same way while driving left	Same, for sideways motion
<code>naturalForwardDeceleration</code>	34.6 in/s ²	How fast the robot slows down by itself. The tuner drives to 30 in/s, cuts the power and averages the slow-down (ForesightTuner.java)	Used to work out how far the robot will coast with no power (Pedro docs: Deceleration)
<code>naturalStrafeDeceleration</code>	70.7 in/s ²	Same, while strafing	Same, for sideways motion

Setting	Our value	What it is and how the tuner measured it	What it does to the robot
<code>linearBrakeCoefficients</code>	forward 0.0518, strafe 0.0361	Braking distance = linear $\times$ speed + quadratic $\times$ speed ² . The tuner drives, brakes at several powers, and fits this curve (ForesightTuner.java). In <code>Matrix.diag(a, b)</code> , <code>a</code> is forward and <code>b</code> is strafe (the tuner writes them in that order)	This is the "measured braking distance" from paper footnote 2. The robot uses it to decide when to start braking
<code>quadraticBrakeCoefficients</code>	forward 0.00244, strafe 0.00271	The speed ² part of the same curve	Same
<code>coast</code>	kV = 0.01776	A feedforward: output = target speed $\times$ kV (Pedro docs: Controllers). The tuner drives at 40% power for 1.2 s, finds the steady speed per unit of power, and sets kV = $1 \div$ that (ForesightTuner.java)	Turns "I want this speed" into "send this much power"
<code>brake</code>	kV = 0.01510	The tuner sets it to 0.85 $\times$ the coast kV (ForesightTuner.java)	Same idea, used for braking. The docs do not explain exactly when Foresight switches between coast and brake

Our numbers — braking distance. Using the formula above: at full forward speed (57.6 in/s) the robot needs about $0.0518 \times 57.6 + 0.00244 \times 57.6^2 \approx 11.1$ in to stop. At 30 in/s it needs about 3.8 in. At full strafe speed (45.2 in/s) it needs about 7.2 in.

Check it: the [Pedro Tuning Checker](#) tests these values for you: brake kV should be $0.85 \times$ coast kV, $1 \div$ coast kV should be close to the top forward speed (ours: 56.3 vs 57.6 in/s), and braking should stop the robot sooner than coasting.

Part E: Foresight — staying on the line (the translational push)

Setting	Our value	What it is	What it does to the robot
<code>forwardTranslational</code>	small kP 0.1337, large kP 0.3619, switch at 2.5 in	A piecewise controller: the small controller is used when the error is under 2.5 in, the large one when it is over (Pedro docs: Controllers). Each is proportional : output = error $\times$ kP (same page)	Corrects position error in the robot's forward direction. The large controller corrects big errors quickly; the small one avoids overshoot near the path (same page)
<code>strafeTranslational</code>	small kP 0.1367, large kP 0.3699, switch at 2.5 in	Same, for the sideways direction	Pulls the robot sideways back onto the line

In the code, "primary" is the large controller and "secondary" is the small one. This matches the paper's translational push with gain k_p (paper, §3.2). The paper also includes a damping gain k_d ; our file has no setting with that name.

Check it: the tuner computes both kPs from one test using factors 10.2 and 6.2, so large $\div$ small is always $(10.2 \div 6.2)^2 \approx 2.71$ (ForesightTuner.java). A different ratio means a value was edited by hand. The Pedro Tuning Checker tests this; ours pass.

If it misbehaves: overshooting or jittery means kP is too high; slow or weak correction means kP is too low ([Pedro docs: Troubleshooting](#)).

Part F: Foresight — facing the right way (the heading push)

Setting	Our value	What it is	What it does to the robot
<code>headingFeedback</code>	kP 4.776	Proportional controller on heading error. The tuner spins the robot in place at 40% power and calculates kP from how it speeds up (ForesightTuner.java). The docs advise against a piecewise controller here (Pedro docs: Controllers)	Turns the robot back to the target heading. Matches the paper's heading gain (paper, §3.3)
<code>headingBrakeCoefficients</code>	linear 0.0439, quadratic 0.00813	Turning braking distance = linear × turn speed + quadratic × turn speed ² (ForesightTuner.java). The tuner spins back and forth and brakes	Predicts how far the robot keeps turning after it starts braking. The tuner also uses it to hold heading during the braking tests. The docs do not explain more

Our numbers. Turning at 3 rad/s, the robot keeps turning about $0.0439 \times 3 + 0.00813 \times 3^2 \approx 0.205$ rad (about 12°) while braking.

Part G: Settings not in our file (the defaults are used)

These do not appear in our active `ForesightConfig`, so the default values from the docs apply.

Setting	Default	What it means
<code>parametricTConstraint</code>	0.025	The path is "parametrically complete" at $t \geq 0.975$ (Pedro docs: End Constraints). The Line Test turns around at this point (Tests.java)

Setting	Default	What it means
<code>velocityConstraint</code>	0.1 in/s	Robot must be slower than this to count as stopped (End Constraints)
<code>translationalConstraint</code>	0.1 in	Robot must be this close to the end point (End Constraints)
<code>headingConstraint</code>	0.007 rad (~0.4°)	Heading must be this close to the target (End Constraints)
<code>timeoutConstraint</code>	100 ms	How long it may keep correcting at the end before giving up (End Constraints)
<code>brakeAggression</code>	1.0	Above 1 allows overshoot, below 1 aims to undershoot (Pedro docs: Path Constraints)
<code>maxBrakingPower</code>	0.2	Cap on power pushing against the direction of motion (Path Constraints)
<code>maxAccelerationConstraint</code> , <code>maxVelocityConstraint</code> , <code>maxDecelerationConstraint</code>	None	No extra limits; the drivetrain's own abilities apply (Path Constraints)
<code>headingDriveRatio</code>	0.5	Higher gives heading correction more priority over driving forward (Pedro docs: Foresight Options)
<code>brakeAtEnd</code>	true	Brake before the final end point instead of coasting (Foresight Options)
<code>translationalDeviationTolerance</code>	2.5 in	Beyond this error, the follower fixes position before carrying on (Foresight Options)
<code>headingDeviationTolerance</code>	11.25°	Beyond this error, the follower fixes heading before carrying on (Foresight Options)
<code>cosineScale</code>	false	If on, slows forward speed when errors get large (Foresight Options)

Fixing the Line Test

Most Line Test problems start earlier. **First make sure Gates 0–4 of the** Tuning Checklist **pass, in order.** Stage 2 (Pinpoint) is the most likely cause: a wrong pose makes every tuned number look wrong. Then use this section.

What a working Line Test looks like. The robot drives forward 48 in in a straight line, then back to the start, again and again, always facing the same way ([Pedro docs: Test](#)). It is not designed to stop and settle at 48 in: it turns around as soon as it reaches $t \geq 0.975$ on the path, because `parametricTConstraint` defaults to 0.025 ([Tests.java](#); [Pedro docs: End Constraints](#)). So some carry-past is expected; what matters is **how far** past, and whether the screen agrees with the floor. In the Quickstart code dated 30 Sep 2026, the Line Test always uses 48 in, even if you type another distance (a line in `Tests.java` sets `distance = 48`).

Setting up the robot for a test

The Pinpoint reports the position of the robot's centre. Our pod offsets are measured from that point ([Pedro docs: Pinpoint](#); [goBILDA guide, p. 2](#)). The Line Test sets the position to (0, 0) when Start is pressed, so "48" means the centre has moved 48 in (`Tests.java`).

1. Put a small tape mark on top of the robot at its centre.
2. Line that mark up with the 0 tape line, directly over a straight centre-line tape.
3. Point the robot exactly along the tape line. The test drives in whatever direction the robot faces at Start.
4. Do not touch the robot after pressing Start, because that is when (0, 0) is set.

If the centre is hard to see, line up the front bumper with 0 and judge the front bumper against 48 instead. The robot does not turn on this path, so the bumper moves the same distance as the centre. Never mix the two (for example, bumper at the start and centre at the end).

Compare the screen with the floor

Watch the robot and the Driver Hub telemetry (x, y, heading) together. Hand-adjust only after the checklist gates pass, and change one setting at a time.

What you see	What it means	Where to look
Robot is clearly off the tape line, but y reads about 0	The robot does not know it moved (localization drift)	<i>Start here</i> ; Checklist Stage 2 (Pedro docs: Pinpoint)

What you see	What it means	Where to look
Position slowly drifts over many laps	The localizer's estimate drifts over time	Checklist Stage 2 (Pedro docs: Troubleshooting)
y matches the real offset, and the robot swings left and right across the line	Over-correcting	Lower <code>strafeTranslational kP</code> (Troubleshooting)
y matches, and the robot slowly drifts one way without coming back	Correcting too weakly	Raise <code>strafeTranslational kP</code> (Troubleshooting)
Robot does not keep facing the same way	Heading correction off	<code>headingFeedback kP</code> (Troubleshooting)
Robot goes well past 48 in, but x says about 48	Distances are measured wrong	<code>podType</code> and the pods (Part C)
x itself reads well past 48	Braking is too weak	Re-run the deceleration and braking tuners (Checklist Stage 3). Then <code>maxBrakingPower</code> (default 0.2); <code>brakeAggression</code> below 1 biases toward undershooting (Pedro docs: Path Constraints)
Robot takes too long to finish at the end	End constraints	Check the final position, heading and speed errors before changing them (Pedro docs: End Constraints)

A note on the docs. The Path Constraints page first says values of `brakeAggression` below 1 bias toward undershooting. It then says "If your robot is undershooting, lower this value," which seems to say the opposite. Ask on the Pedro Discord before relying on that second sentence.

Filming the test

A video can be checked frame by frame. It shows how far past 48 in the robot goes, when sideways drift starts, and whether the robot turns. It is weak at very fast wiggles and exact speeds.

1. Keep the camera still (propped up, not handheld). Show the whole 48 in plus about a foot, from above or from the side.

2. Tape a start line, a 48 in line, a straight centre line along the path, and marks every 6 in.
3. Put a strip of tape on top of the robot pointing forward, so turning is easy to see.
4. Record enough laps to catch when any drift starts.
5. Get the Driver Hub telemetry in the same shot, or film it at the same time.
6. Keep clips to about a minute; split long recordings.

When asking for help

Post in the Pedro Discord **#tuning-help** channel with a video, our constants, and telemetry (Pedro docs: Troubleshooting). The follower's debug strings, such as `follower.debug().algorithm().toString()`, are made for this ([Pedro docs: Debugging](#)).

Our Line Test investigation (5–7 Oct 2026)

What we saw: the robot does not stop at 48 in, and after a few laps it starts strafing, sometimes left and sometimes right. Record results in the checklist's sign-off log.

Finding	Status	Next step
Robot does not stop at 48 in	Partly expected: the Line Test turns around at $t \geq 0.975$	Measure the carry-past (Checklist Stage 5)
Strafing starts after a few laps, not on the first	Points to localization drift: errors that grow lap after lap fit a drifting position reading. Our reasoning; it matches Pedro's advice for drift in the Line Test (Troubleshooting)	Gates 2a–2c
<code>yPodOffset</code> is -6.65 in (behind centre), but the pods are at the front	Open	Gate 2b; see <i>Start here: Does pod placement matter?</i>
<code>Tuning.java</code> passes Foresight to <code>tests()</code>	Checked 5 Oct: correct, so the Line Test uses our tuned values	None
<code>create()</code> passes <code>null</code>	Not the Line Test cause, but our own OpModes get no Foresight	Checklist Stage 4

Glossary

Word	Meaning in this guide
Odometry pod	A small unpowered wheel with an encoder that measures how far the robot rolled
Encoder	A sensor that counts small steps (ticks) as a wheel turns
Localization	Working out where the robot is on the field
Pose	The robot's position (x, y) plus its heading
Heading	The direction the robot is facing
Strafe	Driving sideways, which a mecanum robot can do
Offset	How far a pod is from the robot's centre
Error	The gap between where the robot is and where it should be
Controller	A rule that turns an error into motor power (Pedro docs: Controllers)
kP (proportional gain)	Multiplier in a proportional controller: $\text{output} = \text{error} \times \text{kP}$
Feedforward, kV	Power sent based on the target, not the error: $\text{output} = \text{target} \times \text{kV}$
Piecewise controller	Uses one controller for small errors and another for large errors
Deceleration	How quickly speed drops, in inches per second per second (in/s^2)
Coefficient	A fixed number that multiplies something in a formula
Parametric t	A number from 0 (start of path) to 1 (end of path) that marks a spot on the path
Guiding vector field	An arrow at every spot near the path showing how the robot should speed up to reach and follow it (paper, §3)
Gain	Another word for a tuned multiplier such as kP

Version history

Version	Date	What changed
3	7 Oct 2026	Cleanup. Added a <code>guide/checklist/checker/ Tuning.java</code> table at the top. Step-by-step procedures moved to the Tuning Checklist and number checks to the Pedro Tuning Checker. Pod placement folded into <i>Start here</i> . The two symptom tables merged into one. <i>Our Line Test investigation</i> condensed to a findings table
2.3	7 Oct 2026	Only <code>Tuning.java</code> is staged now (version 2). <code>Constants.java</code> stays our normal file; the checklist says which block to paste over at each stage
2.2	7 Oct 2026	Added staged <code>Constants.java</code> and <code>Tuning.java</code> (version 1). Replaced by 2.3
2.1	7 Oct 2026	Added the <i>Tuning Checklist</i> tab: stages 0–5 with a gate after each, and a sign-off log
2	5 Oct 2026	Added <i>Start here: pod directions and offsets</i> at the top
1.1	5 Oct 2026	Added <i>Our Line Test investigation</i> ; confirmed <code>Tuning.java</code> passes Foresight to the Line Test
1	5 Oct 2026	First version: big picture, every parameter, fixing the Line Test, glossary, sources

Sources

All web pages were opened on 5 Oct 2026. The Pedro docs pages match the Pedro-Pathing/Docs GitHub repository as of 2 Oct 2026.

1. H. Sripada and B. Henderson, *Second-Order Multidimensional Guiding Vector Field for Parametric Path-Following Under Holonomic Constraints* (the attached PDF; contact info@pedropathing.com). Sections used: §2.3, §3.1–§3.5, footnote 2, Theorem 4.6.
2. [Pedro docs: Tuning](#)
3. [Pedro docs: Mecanum](#)
4. [Pedro docs: Localization](#)
5. [Pedro docs: Pinpoint](#)

6. [Pedro docs: Foresight](#)
7. [Pedro docs: Constants](#)
8. [Pedro docs: Test](#)
9. [Pedro docs: Controllers](#)
10. [Pedro docs: Deceleration](#)
11. [Pedro docs: End Constraints](#)
12. [Pedro docs: Path Constraints](#)
13. [Pedro docs: Foresight Options](#)
14. [Pedro docs: Types of Velocities](#)
15. [Pedro docs: Coordinates](#)
16. [Pedro docs: Troubleshooting](#)
17. [Pedro docs: Debugging](#)
18. [ForesightTuner.java](#), Pedro Quickstart, commit 2df9646 (30 Sep 2026)
19. [PinpointTuner.java](#), same commit
20. [Tests.java](#), same commit
21. [goBILDA Pinpoint Odometry Computer User Guide \(3110-0002-0001\)](#)