

Operating Procedure — Field Generator Set FGS-12 (Fictional)

1 Scope

This fictional procedure covers first-line operation and servicing of the FGS-12 field generator set used by demonstration units. It exists solely to exercise document ingestion during testing.

2.1 Start-Up Sequence

Confirm the fuel isolation valve is open. Prime the lift pump with twelve strokes. Set the load selector to OFF and crank for no longer than fifteen seconds. Once running, allow the set to stabilise for four minutes before applying load.

2.4 Operating Limits

The continuous rated output of the FGS-12 is 12.5 kVA at 50 Hz. Do not exceed 14 kVA even briefly. Coolant temperature must remain below 96 degrees Celsius; shut the set down if it is exceeded.

3.2 Scheduled Servicing

Change the lubricating oil every 250 running hours using grade OMD-90. Replace air filter element AF-771 every 500 running hours, or sooner in dusty conditions. Record every service in the set log book.

4.1 Fault — Output Voltage Low

If output falls below 210 V on load, check the automatic voltage regulator fuse first. If the fuse is intact, replace regulator module AVR-30 and re-test on a half load for ten minutes before returning the set to use.