INPUT-OUTPUT ORGANIZATION

- Peripheral Devices
- Input-Output Interface
- Asynchronous Data Transfer
- Modes of Transfer
- Priority Interrupt
- Direct Memory Access
- Input-Output Processor
- Serial Communication

PERIPHERAL DEVICES

Input Devices

- Keyboard
- Optical input devices
 - Card Reader
 - Paper Tape Reader
 - Bar code reader
 - Digitizer
 - Optical Mark Reader
- Magnetic Input Devices
 - Magnetic Stripe Reader
- Screen Input Devices
 - Touch Screen
 - Light Pen
 - Mouse
- Analog Input Devices


Output Devices

- Card Puncher, Paper Tape Puncher
- CRT
- Printer (Impact, Ink Jet, Laser, Dot Matrix)
- Plotter
- Analog
- Voice

INPUT/OUTPUT INTERFACE

- Provides a method for transferring information between internal storage (such as memory and CPU registers) and external I/O devices
- Resolves the differences between the computer and peripheral devices
 - Peripherals Electromechanical Devices
 - CPU or Memory Electronic Device
 - Data Transfer Rate
 - » Peripherals Usually slower
 - » CPU or Memory Usually faster than peripherals
 - Some kinds of Synchronization mechanism may be needed
 - Unit of Information
 - » Peripherals Byte, Block, ...
 - » CPU or Memory Word
 - Data representations may differ

I/O BUS AND INTERFACE MODULES



Each peripheral has an interface module associated with it

Interface

- Decodes the device address (device code)
- Decodes the commands (operation)
- Provides signals for the peripheral controller
- Synchronizes the data flow and supervises the transfer rate between peripheral and CPU or Memory


Typical I/O instruction

Op. code	Device address	Function code	
		(Command)	

CONNECTION OF I/O BUS

Op. Device Function code address CPU Op. Device Function code address CPU Data lines Function code lines Device address lines

Connection of I/O Bus to One Interface



I/O BUS AND MEMORY BUS

Functions of Buses

- * MEMORY BUS is for information transfers between CPU and the MM
- * I/O BUS is for information transfers between CPU and I/O devices through their I/O interface

Physical Organizations

- * Many computers use a common single bus system for both memory and I/O interface units
 - Use one common bus but separate control lines for each function
 Use one common bus with common control lines for both functions
- * Some computer systems use two separate buses, one to communicate with memory and the other with I/O interfaces

I/O Bus

- Communication between CPU and all interface units is via a common I/O Bus
- An interface connected to a peripheral device may have a number of data registers, a control register, and a status register
- A command is passed to the peripheral by sending to the appropriate interface register Function code and sense lines are not needed (Transfer of data, control, and status information is always via the common I/O Bus)

ISOLATED vs MEMORY MAPPED I/O

Isolated I/O


- Separate I/O read/write control lines in addition to memory read/write control lines
- Separate (isolated) memory and I/O address spaces
- Distinct input and output instructions

Memory-mapped I/O

- A single set of read/write control lines (no distinction between memory and I/O transfer)
- Memory and I/O addresses share the common address space
 - -> reduces memory address range available
- No specific input or output instruction
 - -> The same memory reference instructions can be used for I/O transfers
- Considerable flexibility in handling I/O operations

8

INTERFACE



Programmable Interface

- Information in each port can be assigned a meaning depending on the mode of operation of the I/O device
 → Port A = Data; Port B = Command; Port C = Status
- CPU initializes(loads) each port by transferring a byte to the Control Register

 → Allows CPU can define the mode of operation of each port

 → Programmable Port: By changing the bits in the control register, it is possible to change the interface characteristics

Status register

ASYNCHRONOUS DATA TRANSFER

Synchronous and Asynchronous Operations

Synchronous - All devices derive the timing information from common clock line

Asynchronous - No common clock

Asynchronous Data Transfer

Asynchronous data transfer between two independent units requires that control signals be transmitted between the communicating units to indicate the time at which data is being transmitted

Two Asynchronous Data Transfer Methods

Strobe pulse


- A strobe pulse is supplied by one unit to indicate the other unit when the transfer has to occur

Handshaking

- A control signal is accompanied with each data being transmitted to indicate the presence of data
- The receiving unit responds with another control signal to acknowledge receipt of the data

STROBE CONTROL

- * Employs a single control line to time each transfer
- * The strobe may be activated by either the source or the destination unit



Input-Output Organization

HANDSHAKING

Strobe Methods

Source-Initiated


The source unit that initiates the transfer has no way of knowing whether the destination unit has actually received data

Destination-Initiated

The destination unit that initiates the transfer no way of knowing whether the source has actually placed the data on the bus

To solve this problem, the *HANDSHAKE* method introduces a second control signal to provide a *Reply* to the unit that initiates the transfer

SOURCE-INITIATED TRANSFER USING HANDSHAKE



- * Allows arbitrary delays from one state to the next
- * Permits each unit to respond at its own data transfer rate
- * The rate of transfer is determined by the slower unit

* Handshaking provides a high degree of flexibility and reliability because the successful completion of a data transfer relies on active participation by both units

* If one unit is faulty, data transfer will not be completed

(initial state).

Invalidate data on bus

-> Can be detected by means of a timeout mechanism

Computer Organization


ASYNCHRONOUS SERIAL TRANSFER

Four Different Types of Transfer

Asynchronous serial transfer Synchronous serial transfer Asynchronous parallel transfer Synchronous parallel transfer

Asynchronous Serial Transfer

- Employs special bits which are inserted at both ends of the character code
- Each character consists of three parts; Start bit; Data bits; Stop bits.




A character can be detected by the receiver from the knowledge of 4 rules;

- When data are not being sent, the line is kept in the 1-state (idle state)
- The initiation of a character transmission is detected by a *Start Bit*, which is always a 0
- The character bits always follow the Start Bit
- After the last character, a Stop Bit is detected when the line returns to the 1-state for at least 1 bit time

The receiver knows in advance the transfer rate of the bits and the number of information bits to expect

UNIVERSAL ASYNCHRONOUS RECEIVER-TRANSMITTER - UART -

A typical asynchronous communication interface available as an IC



Transmitter Register

- Accepts a data byte(from CPU) through the data bus
- Transferred to a shift register for serial transmission

Receiver

- Receives serial information into another shift register
- Complete data byte is sent to the receiver register

Status Register Bits


- Used for I/O flags and for recording errors

Control Register Bits

 Define baud rate, no. of bits in each character, whether to generate and check parity, and no. of stop bits

FIRST-IN-FIRST-OUT(FIFO) BUFFER

- * Input data and output data at two different rates
- * Output data are always in the same order in which the data entered the buffer.
- * Useful in some applications when data is transferred asynchronously
- 4 x 4 FIFO Buffer (4 4-bit registers Ri),
- 4 Control Registers(flip-flops Fi, associated with each Ri)



MODES OF TRANSFER - PROGRAM-CONTROLLED I/O -


3 different Data Transfer Modes between the central

computer(CPU or Memory) and peripherals;

Program-Controlled I/O
Interrupt-Initiated I/O
Direct Memory Access (DMA)

Program-Controlled I/O(Input Dev to CPU)

program



MODES OF TRANSFER - INTERRUPT INITIATED I/O & DMA

Interrupt Initiated I/O

- Polling takes valuable CPU time
- Open communication only when some data has to be passed -> Interrupt.
- I/O interface, instead of the CPU, monitors the I/O device
- When the interface determines that the I/O device is ready for data transfer, it generates an *Interrupt Request* to the CPU
- Upon detecting an interrupt, CPU stops momentarily the task it is doing, branches to the service routine to process the data transfer, and then returns to the task it was performing

DMA (Direct Memory Access)

- Large blocks of data transferred at a high speed to or from high speed devices, magnetic drums, disks, tapes, etc.
- DMA controller
 Interface that provides I/O transfer of data directly to and from the memory and the I/O device
- CPU initializes the DMA controller by sending a memory address and the number of words to be transferred
- Actual transfer of data is done directly between the device and memory through DMA controller
 -> Freeing CPU for other tasks

PRIORITY INTERRUPT

Priority

- Determines which interrupt is to be served first when two or more requests are made simultaneously
- Also determines which interrupts are permitted to interrupt the computer while another is being serviced
- Higher priority interrupts can make requests while servicing a lower priority interrupt


Priority Interrupt by Software(Polling)

- Priority is established by the order of polling the devices(interrupt sources)
- Flexible since it is established by software
- Low cost since it needs a very little hardware
- Very slow

Priority Interrupt by Hardware

- Require a priority interrupt manager which accepts all the interrupt requests to determine the highest priority request
- Fast since identification of the highest priority interrupt request is identified by the hardware
- Fast since each interrupt source has its own interrupt vector to access directly to its own service routine

HARDWARE PRIORITY INTERRUPT - DAISY-CHAIN -




- * Serial hardware priority function
- * Interrupt Request Line
- Single common line
- * Interrupt Acknowledge Line - Daisy-Chain

Interrupt Request from any device(>=1)


- -> CPU responds by INTACK <- 1
- -> Any device receives signal(INTACK) 1 at PI puts the VAD on the bus Among interrupt requesting devices the only device which is physically closest to CPU gets INTACK=1, and it blocks INTACK to propagate to the next device

One stage of the daisy chain priority arrangement



<u>PI</u>	RF	РО	Enable
0	0	0	0
0	1	0	0
1	0	1	0
1	1	0	1

PARALLEL PRIORITY INTERRUPT



IEN:

Set or Clear by instructions ION or IOF
Represents an unmasked interrupt has occurred. INTACK enables IST: tristate Bus Buffer to load VAD generated by the Priority Logic

Interrupt Register:

- Each bit is associated with an Interrupt Request from different Interrupt Source - different priority level
- Each bit can be cleared by a program instruction Mask Register:
 - Mask Register is associated with Interrupt Register
 - Each bit can be set or cleared by an Instruction

INTERRUPT PRIORITY ENCODER

Determines the highest priority interrupt when more than one interrupts take place

Priority Encoder Truth table

	Inp	uts			Outputs		uts	_
I ₀	I ₁	I,	2	I ₃	Х	у	IST	Boolean functions
1	d	d	d		0	0	1	
0	1	d	d		0	1	1	
0	0	1	d		1	0	1	$\mathbf{x} = \mathbf{I_0'} \ \mathbf{I_1'}$
0	0	0	1		1	1	1	$y = I_0'' I_1 + I_0' I_2'$
0	0	0	0		d	d	0	$(IST) = I_0 + I_1 + I_2 + I_3$

INTERRUPT CYCLE

At the end of each Instruction cycle

- CPU checks IEN and IST
- If IEN IST = 1, CPU -> Interrupt Cycle

SP ← SP - 1 Decrement stack pointer

M[SP] ← PC Push PC into stack

INTACK ← 1 Enable interrupt acknowledge


PC ← VAD Transfer vector address to PC

IEN ← 0 Disable further interrupts

Go To Fetch to execute the first instruction

in the interrupt service routine

INTERRUPT SERVICE ROUTINE



Each interrupt service routine must have an initial and final set of operations for controlling the registers in the hardware interrupt system


Initial Sequence
[1] Clear lower level Mask reg. bits
[2] IST <- 0
[3] Save contents of CPU registers
[4] IEN <- 1
[5] Go to Interrupt Service Routine

Final Sequence
[1] IEN <- 0
[2] Restore CPU registers
[3] Clear the bit in the Interrupt Reg
[4] Set lower level Mask reg. bits
[5] Restore return address, IEN <- 1


DIRECT MEMORY ACCESS

- * Block of data transfer from high speed devices, Drum, Disk, Tape
- * DMA controller Interface which allows I/O transfer directly between Memory and Device, freeing CPU for other tasks
- * CPU initializes DMA Controller by sending memory address and the block size(number of words)

CPU bus signals for **DMA** transfer



Block diagram of DMA controller



Computer Organization

DMA I/O OPERATION

Starting an I/O

- CPU executes instruction to

Load Memory Address Register

Load Word Counter

Load Function(Read or Write) to be performed Issue a GO command

Upon receiving a GO Command DMA performs I/O operation as follows independently from CPU

Input

[1] Input Device <- R (Read control signal)

[2] Buffer(DMA Controller) <- Input Byte; and assembles the byte into a word until word is full

[4] M <- memory address, W(Write control signal)

[5] Address Reg <- Address Reg +1; WC(Word Counter) <- WC - 1

[6] If WC = 0, then Interrupt to acknowledge done, else go to [1]

Output

[1] M <- M Address, R M Address R <- M Address R + 1, WC <- WC - 1

[2] Disassemble the word

[3] Buffer <- One byte; Output Device <- W, for all disassembled bytes

[4] If WC = 0, then Interrupt to acknowledge done, else go to [1]

CYCLE STEALING

While DMA I/O takes place, CPU is also executing instructions

DMA Controller and CPU both access Memory -> Memory Access Conflict

Memory Bus Controller

- Coordinating the activities of all devices requesting memory access
- Priority System


Memory accesses by CPU and DMA Controller are interwoven, with the top priority given to DMA Controller

-> Cycle Stealing

Cycle Steal

- CPU is usually much faster than I/O(DMA), thus CPU uses the most of the memory cycles
- DMA Controller steals the memory cycles from CPU
- For those stolen cycles, CPU remains idle
- For those slow CPU, DMA Controller may steal most of the memory cycles which may cause CPU remain idle long time


DMA TRANSFER



INPUT/OUTPUT PROCESSOR - CHANNEL -

Channel

- Processor with direct memory access capability that communicates with I/O devices
- Channel accesses memory by cycle stealing
- Channel can execute a Channel Program
 - Stored in the main memory
 - Consists of Channel Command Word(CCW)
 - Each CCW specifies the parameters needed by the channel to control the I/O devices and perform data transfer operations
- CPU initiates the channel by executing an channel I/O class instruction and once initiated, channel operates independently of the CPU



CHANNEL / CPU COMMUNICATION

