


Author: Bharat Acharya Sem V – EXTC Mumbai 2018

PIN DIAGRAM OF 8051



BHARAT ACHARYA EDUCATION



Videos | Books | Classroom Coaching E: bharatsir@hotmail.com M: 9820408217

8051 has 40 pins.

The function of these pins is briefly explained as follows.

XTAL1 & XTAL2 These are connected to the **crystal oscillator**.

The typical operating frequency is 12 MHz.

In **Serial communication** based applications, the operating frequency is chosen to be **11.0592 MHz**, in order to derive the standard universal baud rates. This will be discussed in detail in the further chapters.

Reset

It is used to **reset** the 8051 microcontroller.

On reset PC becomes 0000H.

This address is called the **reset vector address**.

From here, 8051 executes the **BIOS program** also called the Booting program or the monitor program. It is used to **set-up the system** and make it **ready**, to be used by the **end-user**.

ALE
Address
Latch Enable

It is used to enable the latching of the address.

The address and data buses are multiplexed.

This is done to **reduce the number of pins** on the 8051 IC.

Once out of the chip, address and data have to be separated that is called de-multiplexing.

This is done by a latch, with the help of ALE signal.

ALE is "1" when the bus carries address and "0" when the bus carries data.

This informs the latch, when the bus is carrying address so that the latch captures only address and not the data.

EAEnable External Access

It decides whether the first 4 KB of program memory space (0000H... 0FFFH) will be assigned to internal ROM or External ROM.

If EA = 0, the External ROM begins from 0000H.

In this case the Internal ROM is discarded. 8051 now uses only External ROM.

If EA = 1, the External ROM begins from 1000H.

In this case the Internal ROM is used. It occupies the space 0000H... 0FFFH.

In modern **FLASH ROM versions**, this pin also acts as **VPP** (12 Volt programming voltage) to write into the FLASH ROM.

MICROPROCESSORS 8051 & ARM



Author: Bharat Acharya Sem V – EXTC Mumbai 2018

PSEN

Program Status Enable 8051 has a **16-bit address bus** $(A_{15} - A_0)$.

This should allow 8051 to access **64 KB of external Memory** as $2^{16} = 64$ KB. Interestingly though, 8051 can access **64 KB of External ROM and 64 KB of External RAM**, making a total of 128 KB.

Both have the same address range **0000H to FFFFH**.

This does not lead to any confusion because there are separate control signals

for External RAM and External ROM.

RD and WR are control signals for External RAM.

PSEN is the READ signal for External ROM.

It is called Program Status Enable as it allows reading from ROM also known as Program Memory. Having separate control signals for External RAM and External ROM actually **allows us to double the size of the external memory** to a total of 128 KB from the original 64 KB.

Vcc & GND These are **power supply** pins. 8051 works at **+5V / 0V** power supply.

P0.0... P0.7

These are **8 pins** of Port 0.

We can perform a **byte operation** (8-bit) on the whole port 0.

We can also access every bit of port 0 individually by performing bit operations like set, clear, complement etc.

The bits are called P0.0... P0.7.

Additionally, Port 0 also has an **alternate function**.

It carries the multiplexed address data lines.

A0-A7 (the lower 8 bits of address) and D0-D7 (8 bits of data) are multiplexed into AD0-AD7.

In any operation address and data are not issued simultaneously.

First, address is given, then data is transferred.

Using a common bus for both, reduces the number of pins.

To identify if the bus is carrying address or data, we look at the ALE signal.

If **ALE = 1**, the bus carries **address**,

If ALE = 0, the bus carries data.

P1.0... P1.7

These are **8 pins** of Port 1.

We can perform a **byte operation** (8-bit) on the whole port 1.

We can also **access every bit of port 1 individually** by performing bit operations like set, clear, complement etc. on **P1.0... P1.7**.

Port 1 also has NO alternate function.

BHARAT ACHARYA EDUCATION



Videos | Books | Classroom Coaching E: bharatsir@hotmail.com M: 9820408217

P2.0... P2.7

These are **8 pins** of Port 2.

We can perform a **byte operation** (8-bit) on the whole port 2. We can also **access every bit of port 2 individually** by performing bit operations like set, clear, complement etc. on **P2.0... P2.7**. Additionally, Port 2 also has an **alternate function**. It carries the **higher order address lines A8-A15**.

P3.0... P3.7

These are **8 pins** of Port 3.

We can perform a **byte operation** (8-bit) on the whole port 3.

We can also access every bit of port 3 individually.

The bits are called **P0.0... P0.7**.

The various pins of Port 3 have a lot of alternate functions.

P3.0 (**Rxd**) and P3.1 (**Txd**): They are used to **receive and transmit serial data**.

This forms the **serial port of 8051**.

P3.2 (INTO) and P3.3 (INT1): They are external hardware interrupts of 8051.

If they occur simultaneously, INTO is by default higher priority.

P3.4 (**T0**) and P3.5 (**T1**): They are used **timer clock inputs**.

They provide external clock inputs to Timer 0 and Timer 1.

P3.6 (WR) and P3.7 (RD): They are used as control signals for External RAM.

8051 can access 64 KB External RAM from 0000H to FFFFH...