
SENSOR RESET TEST


Log Share

```
UVM_INFO sensor_checker.sv(157) @ 84: uvm_test_top.alarm_env.sensor_chk [SENSOR_AHB_DEBUG] AHB TRANSACTION | ADDR=00000020 | WRITE=0 | RDATA=00000000 | RESP=0
UVM_INFO sensor_checker.sv(190) @ 84: uvm_test_top.alarm_env.sensor_chk [SENSOR_RESET] ZONE_STATUS RESET CHECK | TIME=84 | EXPECTED=00 | ACTUAL=00
UVM_INFO sensor_checker.sv(215) @ 84: uvm_test_top.alarm_env.sensor_chk [SENSOR_RESET] RESET CHECK PASSED | ZONE_STATUS is zero
UVM_INFO ahb_zone_status_sequence.sv(26) @ 84: uvm_test_top.alarm_env.ahb_agent.ahb_sequencer@@zone_status_seq [AHB_ZONE_STATUS] ZONE_STATUS READ | TIME=84 | ADDR=00000020
UVM_INFO sensor_reset_test.sv(89) @ 85: uvm_test_top [SENSOR_RESET_TEST] ========== SENSOR RESET TEST PASSED ==========
UVM_INFO /apps/vcsmx/vcs/X-2025.06-SP1//etc/uvm-1.2/src/base/uvm_objection.svh(1276) @ 85: reporter [TEST_DONE] 'run' phase is ready to proceed to the 'extract' phase
UVM_INFO /apps/vcsmx/vcs/X-2025.06-SP1//etc/uvm-1.2/src/base/uvm_report_server.svh(904) @ 85: reporter [UVM/REPORT/SERVER]
--- UVM Report Summary ---
```




SENSOR BASIC TEST

```
UVM_INFO sensor_basic_test.sv(105) @ 756: uvm_test_top [SENSOR_BASIC] Basic sensor test completed
```




SENSOR DEBOUNCE TEST

```
UVM_ERROR sensor_checker.sv(287) @ 324: uvm_test_top.alarm_env.sensor_chk [SENSOR_DEBOUNCE] DEBOUNCE CHECK FAILED | TIME=324 | EXPECTED=01 | ACTUAL=00 | FAILURE_RECORDED=1
```



MOTION ACTIVATION TEST

```
UVM_INFO alarm_output_passive_monitor.sv(71) @ 1245: uvm_test_top.alarm_env.alarm_output_mon [ALARM_DEBUG] siren=0 strobe=0 alarm_active=0
UVM_INFO sensor_monitor.sv(42) @ 1253: uvm_test_top.alarm_env.sensor_agent.sensor_monitor [SENSOR_MON] Observed sensor_in = 00000001
UVM_INFO alarm_reference_model.sv(212) @ 1253: uvm_test_top.alarm_env.ref_model [REF_MODEL] SENSOR: Raw Input=00000001 Sync Sample=00000001 Expected Zone Level=00000001
UVM_ERROR motion_qualification_test.sv(192) @ 1253: uvm_test_top [MOTION_TEST] FAIL: Motion did NOT trigger alarm in ARMED_AWAY. Expected=1 Actual=0
UVM_INFO /apps/vcsmx/vcs/X-2025.06-SP1//etc/uvm-1.2/src/base/uvm_objection.svh(1276) @ 1253: reporter [TEST_DONE] 'run' phase is ready to proceed to the 'extract' phase
UVM_INFO /apps/vcsmx/vcs/X-2025.06-SP1//etc/uvm-1.2/src/base/uvm_report_server.svh(904) @ 1253: reporter [UVM/REPORT/SERVER]
--- UVM Report Summary ---
```



SENSOR FAULT TEST

```
UVM_INFO sensor_checker.sv(127) @ 441: uvm_test_top.alarm_env.sensor_chk [SENSOR_FAULT] SENSOR SAMPLE | Input=00000000 | Expected Fault=00000000 | Actual Fault=00000000
```