Digital Systems

Lecture 12

Operating Systems

Mark van der Wilk

Hilary Term 2025

UNIVERSITY OF OXFORD

Department of COMPUTER SCIENCE

Following the course of past years by Mike Spivey

Problems with Previous Programs

```
static int row = 0;
void advance(void) {  // Called by an interrupt
  row++;
  if (row == 3) row = 0;
  GPIO_OUT = heart[row];
}
```

- Efficient but inflexible: No waiting around, but needed to manually add code to the interrupt (what if another piece of code wanted to use timer?)
- No control structures inside `advace()`. Effectively, we had to implement a program counter ourselves (`row`).

Problems with Previous Programs

Use interrupts to overlap printing with the search, but

- When the serial buffer is full, wastes time waiting in a loop.
- Disables interrupts to protect the buffer from concurrent modification – hard to get right.

Problems with Previous Programs

Use interrupts to overlap printing with the search, but

- When the serial buffer is full, wastes time waiting in a loop.
- Disables interrupts to protect the buffer from concurrent modification – hard to get right.

To illustrate inflexibility: Consider writing a program that simultaneously runs beating `heart` and `primes`.

List of Demands

Why concurrency?

- Sharing one machine between several tasks
- Responding to several sources of events
- Genuinely parallel machines (modern multicore)
- Decomposing one task clearly

- Many different ways of designing an OS, with pros/cons.
-
-
-
-

- Many different ways of designing an OS, with pros/cons.
- micro:bian's design is based on "message passing".
-
-
-

- Many different ways of designing an OS, with pros/cons.
- micro:bian's design is based on "message passing".
- Other structures are arguably more efficient.
-
-

- Many different ways of designing an OS, with pros/cons.
- micro:bian's design is based on "message passing".
- Other structures are arguably more efficient.
- You will discuss these structures next year (Concurrency), but you *won't* see low-level implementation of what allows concurrent processes to run.
-

- Many different ways of designing an OS, with pros/cons.
- micro:bian's design is based on "message passing".
- Other structures are arguably more efficient.
- You will discuss these structures next year (Concurrency), but you *won't* see low-level implementation of what allows concurrent processes to run.
- We will discuss low-level mechanisms for allowing concurrent processes.

OS Constructs

- Processes: embedded programs are conveniently structured as a set of independent processes.
- Messages: processes can cooperate by exchanging messages in a way that synchronises their behaviour.
- Shared variables are best avoided by using messages instead (error-prone, and can be eliminated… at a cost)

OS Constructs

- Processes: embedded programs are conveniently structured as a set of independent processes.
- Messages: processes can cooperate by exchanging messages in a way that synchronises their behaviour.
- Shared variables are best avoided by using messages instead (error-prone, and can be eliminated… at a cost)

In this lecture, we use these concepts to build a concurrent program.

A Process: Heart

```
static void heart_task(int arg) {
  while (1) {
    show(heart, 70); show(small, 10);
    show(heart, 10); show(small, 10);
} }

void show(const unsigned *img, int n){
  while (n-- > 0) {  /* Takes 15msec per iteration */
    for (int p = 0; p < 3; p++) {
      GPIO_OUT = img[p]; timer_delay(5);
} } }
```

Another Process: Prime

```
static void prime_task(int arg) {
  int p = 2, n = 0;
  while (1) {
    if (prime(p)) {
      n++;
      // printf will yield by calling serial_putc()
      printf("prime(%d) = %d\n", n, p);
    }
  }
  p++;
}
```

Processes

- Run until no more progress can be made
  (co-operative multitasking vs pre-emptive multitasking)
-
-
-
-
-
-

Processes

- Run until no more progress can be made
  (co-operative multitasking vs pre-emptive multitasking)
- When this happens, process *yields* control of CPU, so other process can make progress.
-
-
-
-
-

Processes

- Run until no more progress can be made
  (co-operative multitasking vs pre-emptive multitasking)
- When this happens, process *yields* control of CPU, so other process can make progress.
- OS will decide which process to devote time to next.
-
-
-
-

Processes

- Run until no more progress can be made
  (co-operative multitasking vs pre-emptive multitasking)
- When this happens, process *yields* control of CPU, so other process can make progress.
- OS will decide which process to devote time to next.
- After 5ms, “operating system” wakes up process again, and continues.
-
-
-

Processes

- Run until no more progress can be made
  (co-operative multitasking vs pre-emptive multitasking)
- When this happens, process *yields* control of CPU, so other process can make progress.
- OS will decide which process to devote time to next.
- After 5ms, “operating system” wakes up process again, and continues.
- Interrupts can still occur, and interrupt a process.
-
-

Processes

- Run until no more progress can be made
  (co-operative multitasking vs pre-emptive multitasking)
- When this happens, process *yields* control of CPU, so other process can make progress.
- OS will decide which process to devote time to next.
- After 5ms, “operating system” wakes up process again, and continues.
- Interrupts can still occur, and interrupt a process.
- Yield could happen in a subroutine.
-

Processes

- Run until no more progress can be made
  (co-operative multitasking vs pre-emptive multitasking)
- When this happens, process *yields* control of CPU, so other process can make progress.
- OS will decide which process to devote time to next.
- After 5ms, “operating system” wakes up process again, and continues.
- Interrupts can still occur, and interrupt a process.
- Yield could happen in a subroutine.
- So, each process needs its own subroutine stack.

Startup

```
void init(void) {
  SERIAL = start("Serial", serial_task, 0, STACK);
  TIMER = start("Timer", timer_task, 0, STACK);
  HEART = start("Heart", heart_task, 0, STACK);
  PRIME = start("Prime", prime_task, 0, STACK);
}
```

- a fixed collection of processes created before concurrent execution begins.
- our two processes, plus device drivers for the timer (`timer_delay`) and serial port (`serial_putc`);
- plus an idle task: Only place where CPU gets put to sleep.

Processes

We saw:

- Each process is a main program in its own right
- It can pause itself (or be interrupted) at any point to give others a go.

We will see implementation:

- Processes have interleaved access to CPU
- Each has its own stack

micro:bian supports a fixed set of processes.

? How can processes communicate amongst them?

Let's rewrite the prime example to split calculating, and handing the "UI" (printing to terminal).

Sending Messages

```
void prime_task(int arg) { int n = 2;
  message m;
  while (1) {
    if (prime(n)) {
      m.int1 = n;
      send(USEPRIME, PRIME, &m);
    }
    n++;
  }
}
```

Receiving Messages

```
void summary_task(int arg) {
  int count = 0, limit = arg; message m;
  while (1) {
    receive(PRIME, &m);
    while (m.int1 >= limit) {
      printf("There are %d primes less than %d\n",
             count, limit);
      limit += arg;
    }
    count++;
  }
}
```

Message Communication

- Messages not buffered.
-
-
-
-
-

Message Communication

- Messages not buffered.
- If process wants to receive: It waits for the other process to send.
-
-
-
-

Message Communication

- Messages not buffered.
- If process wants to receive: It waits for the other process to send.
- If process wants to send: It waits for other process to receive.
-
-
-

Message Communication

- Messages not buffered.
- If process wants to receive: It waits for the other process to send.
- If process wants to send: It waits for other process to receive.
- If message not ready, process yields, and OS runs another process.
-
-

Message Communication

- Messages not buffered.
- If process wants to receive: It waits for the other process to send.
- If process wants to send: It waits for other process to receive.
- If message not ready, process yields, and OS runs another process.
- If message **is** ready, OS transfers when both processes are frozen.
-

Message Communication

- Messages not buffered.
- If process wants to receive: It waits for the other process to send.
- If process wants to send: It waits for other process to receive.
- If message not ready, process yields, and OS runs another process.
- If message **is** ready, OS transfers when both processes are frozen.
- If two processes send to same receiver, OS determines ordering.

Message Format

Both sender and receiver have a message buffer (16 bytes).

- Message type (2 bytes, `short`)
- Sender (2 bytes, `short`)
- Data (3 `ints`, 12 bytes)

Alternatives to messages

Message passing:

- no “shared variables” between processes.
- all communication by messages

Shared variables with semaphores:

- like the serial output buffer.
- more efficient, but hard to get right.

Other OSs

- Processes with communication
- Drivers for I/O devices
- Dynamically and unloading processes
- Memory management (protection/segmentation, virtual memory)
- File system
- Networking

Summary

- Why we need an OS
- How independent processes operate
- How processes can communicate by messages
- Danger of shared variables, safetey of messages

Example

Heart & Primes example.

Sequence of events, and when CPU sleeps, and wakes.