Featurephone Keycode

1. Please be aware that the camera , going back and chatting buttons are not indicated.



2. and the calling button point to the same keycode 0.



Button	Keycode	Button	Keycode
1	49	*	170
2	50	#	163
3	51	Calling	0
4	52	Hanging up	95
5	53	Тор	38
6	54	Right	39
7	55	Down	40
8	56	Left	37
9	57	С	8
0	48		