

pwm_axi_0
S00_AXI
s00_axi_aclk
s00_axi_aresetn
pwm_0
pwm_1
pwm_2
pwm_axi_v1.0 (Pre-Production)
reset_rtl_0
clk100
axi_gpio_1
S_AXI
s_axi_aclk
s_axi_aresetn
GPIO
GPIO2
AXI GPIO
axi_gpio_0
AXI GPIO
axi_uartlite_0
UART
interrupt
AXI Uartlite
microblaze_0
INTERRUPT
DEBUG
Clk
Reset
DLMB
ILMB
M_AXI_DP
MicroBlaze
MicroBlaze
clk_wiz_1
resetn
clk_in1
clk_out1
locked
Clocking Wizard
mdm_1
MBDEBUG_0
Debug_SYS_Rst
MicroBlaze Debug Module (MDM)
rst_clk_wiz_1_100M
slowest_sync_clk
ext_reset_in
aux_reset_in
mb_debug_sys_rst
dcm_locked
mb_reset
bus_struct_reset[0:0]
peripheral_reset[0:0]
interconnect_aresetn[0:0]
peripheral_aresetn[0:0]
Processor System Reset
microblaze_0_local_memory
DLMB
ILMB
LMB_Clk
SYS_Rst
axi_timer_0
capturetrig0
capturetrig1
freeze
generateout0
generateout1
pwm0
interrupt
AXI Timer
microblaze_0_xlconcat
In0[0:0]
In1[0:0]
dout[1:0]
Concat (Discontinued)
microblaze_0_axi_periph
M00_AXI
ACLK
ARESETN
M00_ACLK
M00_ARESETN
M01_ACLK
M01_ARESETN
M02_ACLK
M02_ARESETN
M03_ACLK
M03_ARESETN
M04_ACLK
M04_ARESETN
M05_ACLK
M05_ARESETN
M00_AXI
M01_AXI
M02_AXI
M03_AXI
M04_AXI
M05_AXI
AXI Interconnect (Discontinued)
microblaze_0_axi_intc
s_axi
s_axi_aclk
s_axi_aresetn
irq[1:0]
processor_clk
processor_rst
interrupt
AXI Interrupt Controller
seg
an
sw
uart_rtl_0
led
pwm_b
pwm_g
pwm_r