# Fusion Compiler™ Tool Invocation Commands

Version T-2022.03-SP4, September 2022



# **Copyright Notice and Proprietary Information**

© 2022 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

#### **Destination Control Statement**

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

#### Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

#### Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at <a href="http://www.synopsys.com/company/legal/trademarks-brands.html">http://www.synopsys.com/company/legal/trademarks-brands.html</a>. All other product or company names may be trademarks of their respective owners.

# Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

# **Third-Party Links**

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

www.synopsys.com

Contents	
fc_shell	4

Contents 3

# fc\_shell

Runs the Fusion Compiler tool.

#### **SYNTAX**

#### fc shell

\_-tile file\_name]
[-x command\_string]
[-no\_init]
[-version]

# **Data Types**

file\_name string
display\_env\_var string
command\_string string

# **ARGUMENTS**

## -file file\_name

Runs the specified script before before displaying the initial fc shell prompt.

If the last command in the script file is quit, no prompt is displayed and the command shell exits after running the script.

# -x command\_string

Runs the specified commands before displaying the initial fc\_shell prompt.

You can enter multiple commands by separating the commands with a semicolon and enclosing the entire set of commands with quotation marks.

If you also use the **-file** option, the tool runs the commands specified in the **-x** option first, and then runs the script specified in the **-file** option.

If the last command in the set of commands is quit, no prompt is displayed and the command shell exits after running the commands.

## -no\_init

Does not run any .synopsys\_fc.setup startup files before displaying the initial fc\_shell prompt.

## -version

Displays the version number and build date information, and then exits.

# **DESCRIPTION**

This command starts the Fusion Compiler shell, fc\_shell, which interprets and executes Fusion Compiler commands. The fc\_shell command interpreter is based on Tcl (Tool Command Language).

fc\_shell 4

The shell executes commands until it is terminated by a **quit** or **exit** command. In interactive mode, you can also terminate the fc\_shell session by typing Ctrl+d.

To cancel (interrupt) the command currently executing in fc\_shell, type Ctrl+c. The time it takes for a command to process an interrupt (stop what it is doing and continue with the next command) depends upon the size of the design and the type of command. If you type Ctrl+c three times before a command responds to the interrupt, fc\_shell displays the following message and exits:

Information: Process terminated by interrupt.

# **SEE ALSO**

Im\_shell(1)

fc\_shell 5