Operations Manual 2023

Harbor Lights Shipping, internal edition. Issued January 2023.

This manual covers drills, fuel planning and crew rules for the fleet of 14 vessels.

Safety drills

Lifeboat drills are held every 30 days on every vessel.

Fire extinguishers are inspected every 6 months.

The muster station is where crew assemble in an emergency.

Fuel planning

At 14 knots a container ship burns 42 tonnes of fuel per day. At 10 knots it burns 18 tonnes per day.

Slow steaming is approved by the Operations Desk only.