# Norwegian University of Science and Technology

# TTK4135 – Lecture 11 Practical use of MPC: Output feedback, target calculation and offset-free control

Lecturer: Lars Imsland

#### **Outline**

Recap: Model Predictive Control (MPC), Feasibility&stability

Common (necessary) features in practical MPC implementations:

- Output feedback
- Target calculation
- Offset-free MPC (integral action in MPC)

Reference: F&H Ch. 4.2.3-4.2.4

(Two articles containing more information on Blackboard – not curriculum)



#### Open-loop optimization with linear state-space model

$$\min_{z \in \mathbb{R}^n} f(z) = \sum_{t=0}^{N-1} \frac{1}{2} x_{t+1}^{\top} Q_{t+1} x_{t+1} + d_{x,t+1} x_{t+1} + \frac{1}{2} u_t^{\top} R_t u_t + d_{u,t} u_t + \frac{1}{2} \Delta u_t^{\top} S \Delta u_t$$

subject to

$$x_{t+1} = A_t x_t + B_t u_t, \quad t = \{0, \dots, N-1\}$$

$$x^{\text{low}} \le x_t \le x^{\text{high}}, \quad t = \{1, \dots, N\}$$

$$u^{\text{low}} \le u_t \le u^{\text{high}}, \quad t = \{0, \dots, N-1\}$$

$$-\Delta u^{\text{high}} \le \Delta u_t \le \Delta u^{\text{high}}, \quad t = \{0, \dots, N-1\}$$

QP

where


$$x_0$$
 and  $u_{-1}$  is given
$$\Delta u_t := u_t - u_{t-1}$$

$$z^\top := (u_0^\top, x_1^\top, \dots, u_{N-1}^\top, x_N^\top)$$

$$n = N \cdot (n_x + n_u)$$


$$Q_t \succeq 0 \quad t = \{1, \dots, N\}$$

$$R_t \succ 0 \quad t = \{0, \dots, N-1\}$$






#### Model predictive control principle



#### **Open-loop vs closed-loop trajectories**

$$\min \sum_{t=0}^{4} x_{t+1}^2 + 4 u_t^2$$
 s.t. 
$$x_{t+1} = 1.2x_t + 0.5u_t, \quad t = 0, \dots, 4$$



- Closed-loop trajectories different from open-loop (optimized) trajectories!
- It is the closed-loop trajectories that must analyzed for feasibility and stability.

#### MPC and feasibility

Is there always a solution to the MPC open-loop optimization problem?

- Not necessarily state constraints may become infeasible, for example after a disturbance
- Practical solution: Soft constraints (aka "exact penalty" formulations)
  - "Soften" state constraints by adding "slack variables"

$$\min_{z \in \mathbb{R}^n} f(z) = \sum_{t=0}^{N-1} \frac{1}{2} x_{t+1}^{\top} Q_{t+1} x_{t+1} + \frac{1}{2} u_t^{\top} R_t u_t + \rho^{\top} \epsilon$$
s.t. 
$$x_{t+1} = A_t x_t + B_t u_t, \quad t = \{0, \dots, N-1\}$$

$$x^{\text{low}} - \epsilon \le x_t \le x^{\text{high}} + \epsilon, \quad t = \{1, \dots, N\}, \qquad \epsilon > 0$$

$$\vdots$$

#### MPC optimality implies stability?

$$\min \sum_{t=0}^{1} x_{t+1}^2 + r \, u_t^2$$
 
$$\text{s.t.} \quad x_{t+1} = 1.2x_t + u_t, \quad t = 0, 1$$
 
$$\text{MPC closed loop} \quad x_{t+1} = \left(1.2 - \frac{1.2 + 2.64r}{1 + 3.2r + r^2}\right) x_t$$



0

2

#### **MPC** and stability


#### Requirements for stability:

- Stabilizability ( (A,B) stabilizable )
- Detectability ( (A,D) detectable )
  - D is a matrix such that  $Q = D^TD$  (that is, "D is matrix square root of Q")
  - Detectability: No modes can grow to infinity without being "visible" through Q


#### How to design MPC schemes with guaranteed *nominal* stability:


- Choose prediction horizon equal to infinity (usually not possible)
- For given *N*, choose *Q* and *R* such that MPC is stable (cf. example)
  - Difficult, and not always possible!
- Change the optimization problem add terminal cost/terminal constraints such that
  - The new problem is an "upper approximation" of infinite horizon problem
  - The constraints holds after the prediction horizon
- Typically, in practice: Choose horizon N "large enough"
  - Usually works well!
  - What is "large enough"? Longer than dominating dynamics, but shorter can be OK.
  - Good practice: Choose N large enough such that open-loop predictions resembles closed-loop (test in simulations!)


















#### **MPC** controller – state feedback



## **Output feedback MPC controller**



# Reference tracking (regulation)




# Reference tracking, cont'd



# Reference tracking – target calculation



# Offset-free control (= "integral action")



Recall role of "I" in PID control:

Removing effect of unknown (constant) disturbances

No such "integral action" in MPC so far. How can we achieve the same?




# Offset-free control (= "integral action")



# Offset-free control (= "integral action"), cont'd



#### Offset-free MPC (or MPC with integral action)



#### From description:

- MPC with nonlinear model and a linear (input) disturbance model with one disturbance state: x<sub>t</sub> = f(x<sub>t</sub>,u<sub>t</sub>) + A<sub>d</sub> d<sub>t</sub>. All states are measured (y<sub>t</sub> = x<sub>t</sub>).
- A linear observer is designed as a steady-state Kalman filter for the linearized augmented model at the final equilibrium.
- The forward-looking nature of the MPC controller allows to react to disturbances by considering obstacles in the environment and drastic replanning when necessary.
- From "Offset-free MPC explained: novelties, subtleties, and applications" G. Pannocchia, M. Gabiccini, A. Artoni, NMPC 2015 Seville, Spain September 17 20, 2015.