4L60 & E, 200-4R


PART NUMBERS 77777M-K, 77777L-K, 77777K-K

Accumulator Valve Train Assembly

77777M-K	.341"
77777L-K	.330"
77777K-K	.315"


Each includes the following

- 1 Accumulator Valve
- 1 Accumulator Sleeve
- 1 Accumulator Plug
- 3 Accumulator Springs



Installation Instructions

- 1. Remove the existing accumulator sleeve, plug, valve and spring from the valve body and discard.
- 2. Lube all four parts of the replacement assembly.
- 3. Push the accumulator sleeve into the valve body bore until the roll pin hole in the sleeve and valve body line up.
- 4. Install the roll pin just enough to prevent the sleeve from moving.
- 5. Select one of the three replacement springs to obtain the desired shift quality.
- 6. Push the accumulator valve into the sleeve, oriented as shown below.
- 7. Push the plug into the sleeve until seated, with the recessed diameter facing out the back of the sleeve.
- 8. Push the entire assembly into the valve bore just far enough to push the roll pin all the way into place.



Vehicle Type	Accumulator Valve Assembly	Yellow 3 lb.	White 5 lb.	Pink 7 lb.	
Heavy Cars & Trucks	"M" Version	Light Shift	Medium Shift	Firm Shift	
with High Axle Ratio (3.08-3.23-3.42)					
Medium Weight Cars	"L" Version	Light Shift	Medium Shift	Firm Shift	
(such as Camaro & Firebird) with Mid Axle Ratio (3.42-3.55-3.73)					
Lighter Weight Cars	"K" Version	Light Shift	Medium Shift	Firm Shift	

(under 3,200 lbs) with Mid to Low Axle Ratio (3.73-4.11-4.33)

